

# **MITSUBISHI 3000GT**

## **WORKSHOP MANUAL ELECTRICAL WIRING**

### **FILING INSTRUCTION**

Please keep these manual pages in the binder which is keeping the manual PHUE9201.

File these pages according to the signs "ADDED" and "REVISED" on the "List of effective pages" which are interpreted below.

**ADDED:** File the pages with this sign additionally in your manual.

**REVISED:** Replace the existing pages with the corresponding pages with this sign.

Missing sheets will be supplied upon request.

Group/ Page	Revision code	Date	Remarks	Group/ Page	Revision code	Date	Remarks				
<b>LIST OF EFFECTIVE PAGES</b>											
1	C	Jul. 1994	REVISED	1	A	Aug. 1993					
2	C	Jul. 1994	ADDED	2	B	Dec. 1993					
<b>&lt;1993 models&gt;</b>											
Foreword		May. 1992		<b>3A-SINGLE PART INSTALLATION POSITION</b>							
<b>1-HOW TO READ THE WIRING DIAGRAMS</b>											
1	A	Aug. 1993		1 thru 2	B	Dec. 1993					
2 thru 3		May. 1992		3 thru 6	A	Aug. 1993					
4 thru 5	A	Aug. 1993		7	B	Dec. 1993					
6 thru 8		May. 1992		8 thru 9	A	Aug. 1993					
9 thru 10	A	Aug. 1993		10	B	Dec. 1993					
11		May. 1992		11	A	Aug. 1993					
<b>2-WIRING HARNESS CONFIGURATION DIAGRAMS</b>											
1 thru 22		May. 1992		12	B	Dec. 1993					
<b>3-SINGLE PART INSTALLATION POSITION</b>											
1 thru 19		May. 1992		13 thru 16	A	Aug. 1993					
<b>4-CIRCUIT DIAGRAM</b>											
1 thru 211		May. 1992		17	B	Dec. 1993					
<b>WIRING DIAGRAM &lt;L.H. drive vehicles&gt;</b>											
1 thru 4		May. 1992		18 thru 157	A	Aug. 1993					
<b>WIRING DIAGRAM &lt;R.H. drive vehicles&gt;</b>											
5 thru 8		May. 1992		158	B	Dec. 1993					
<b>&lt;1994 models&gt;</b>											
Foreword	B	Dec. 1993		159 thru 160	A	Aug. 1993					
<b>1A-HOW TO READ THE WIRING DIAGRAMS</b>											
1 thru 2	A	Aug. 1993		160-1 thru 160-4	B	Dec. 1993					
<b>2A-WIRING HARNESS CONFIGURATION DIAGRAMS</b>											
1 thru 3	A	Aug. 1993		161	B	Dec. 1993					
4 thru 7	B	Dec. 1993		162 thru 163	A	Aug. 1993					
8 thru 10	A	Aug. 1993		163-1 thru 163-4	B	Dec. 1993					
11 thru 13	B	Dec. 1993		164 thru 185	A	Aug. 1993					
14	A	Aug. 1993		186	B	Dec. 1993					
15	B	Dec. 1993		187	A	Aug. 1993					
16	A	Aug. 1993		187-1 thru 187-2	B	Dec. 1993					
17	B	Dec. 1993		188	B	Dec. 1993					
18 thru 22	A	Aug. 1993		189	A	Aug. 1993					
<b>WIRING DIAGRAM &lt;L.H. drive vehicles&gt;</b>											
1 thru 4	A	Aug. 1993		189-1 thru 189-2	B	Dec. 1993					
<b>WIRING DIAGRAM &lt;R.H. drive vehicles&gt;</b>											
5 thru 8	A	Aug. 1993		190 thru 209	A	Aug. 1993					


# LIST OF EFFECTIVE PAGES

2

Group/ Page	Revision code	Date	Remarks
<b>&lt;1995 models&gt;</b>			
Foreword	C	Jul. 1994	ADDED
<b>1B-HOW TO READ THE WIRING DIAGRAMS</b>			
1 thrn 2	C	Jul. 1994	ADDED
<b>2B-WIRING HARNESS CONFIGURATION DIAGRAMS</b>			
1 thrn 22	C	Jul. 1994	ADDED
<b>3B-SINGLE PART INSTALLATION POSITION</b>			
1 thrn 18	C	Jul. 1994	ADDED
<b>4B-CIRCUIT DIAGRAM</b>			
1 thrn 193	C	Jul. 1994	ADDED
<b>INDEX</b>			
1 thrn 16	C	Jul. 1994	ADDED

RJCR410022-260  
RJCR312028-54  
RJCR308028-270  
RJCR205038-270

ADDED




# **MITSUBISHI 3000GT'95**

## **WORKSHOP MANUAL ELECTRICAL WIRING**

### **FILING INSTRUCTION**

Please keep these manual pages in the binder  
No.BN890001 to be sent under separate  
cover.

Missing sheets will be supplied upon request.



# MITSUBISHI 3000GT

## ELECTRICAL WIRING

### FOREWORD

This Electrical Wiring Manual contains information necessary for inspection and servicing of electrical wiring in the Mitsubishi 3000GT edited in the form of wiring harness configuration diagrams and function-separated circuit diagrams.

It is recommended that all service mechanics engaged in the servicing of the vehicle refer to the following publications as well as this manual.

#### TECHNICAL INFORMATION MANUAL

PYUE9201

#### WORKSHOP MANUAL

Chassis Group

PWUE9119  
(Loose-leaf edition)

Engine Group

PWEETE□□□□  
(Loose-leaf edition)

#### PARTS CATALOGUE

B608K405A□

All information, illustrations and product descriptions contained in this manual are current as of time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

### GROUP INDEX

HOW TO READ THE WIRING DIAGRAMS .....	1B
WIRING HARNESS CONFIGURATION DIAGRAMS .....	2B
SINGLE PART INSTALLATION POSITION .....	3B
CIRCUIT DIAGRAM .....	4B
INDEX .....	



# HOW TO USE THIS MANUAL

## CONTENTS

The preceding page contains GROUP INDEX which lists the group title and group number.

## PAGE NUMBERS

All page numbers consist of two sets of digits separated by a dash. The digits preceding the dash identify the number of the group. The digits following the dash represent the consecutive page number within the group. The page numbers can be found on the top left or right of each page.

## OPERATION AND TROUBLESHOOTING HINTS

In the GROUP 4A circuit diagrams, the operation and troubleshooting hints are given on the previous page or following page for each circuit where necessary.

# **1 HOW TO READ THE WIRING DIAGRAMS**

<b>MODELS .....</b>	<b>1-2</b>
<b>COMPOSITION AND CONTENTS OF WIRING DIAGRAMS .....</b>	<b>1-2</b>
<b>HOW TO READ CONFIGURATION DIAGRAMS .....</b>	<b>1-3</b>
<b>HOW TO READ CIRCUIT DIAGRAMS .....</b>	<b>1-4</b>
<b>MARKINGS FOR CONNECTOR EARTHING .....</b>	<b>1-6</b>
<b>SYMBOLIC MARKS .....</b>	<b>1-8</b>
<b>WIRE COLOUR CODES .....</b>	<b>1-8</b>
<b>ABBREVIATION SYMBOLS .....</b>	<b>1-9</b>
<b>APPLICABLE MODEL CATEGORIES .....</b>	<b>1-10</b>
<b>HOW TO READ WIRING DIAGRAM .....</b>	<b>1-11</b>

**MODELS**

Model code	Engine model	Transmission model
Z16AMNGFL6	6G72-DOHC-TURBOCHARGER	W5MG1 (5M/T)
Z16AMNGFR6	6G72-DOHC-TURBOCHARGER	W5MG1 (5M/T)


**COMPOSITION AND CONTENTS OF WIRING DIAGRAMS**

- (1) This manual consists of wiring harness diagrams, installation locations of individual parts, circuit diagrams and wiring diagram.
- (2) In each of the sections, all specifications are listed, including optional specifications.  
Accordingly, some specifications may not be applicable for individual vehicles.


Section	Basic contents
Wiring harness configuration diagrams	Connector locations and harness wiring configurations on actual vehicles are illustrated.
Single part installation position	Locations are shown for earth points of relays, control units, sensors, diodes, check terminals, spare terminals, fusible links, fuses, etc. In the parts lists, parts are listed in alphabetical order.
Circuit diagrams	<p>Circuits from power supply to earth are shown completely, classified according to system. There is a main division into power circuits, and circuits classified by system. The circuits classified by system also include operation and troubleshooting hints.</p> <ul style="list-style-type: none"> <li>• Power supply circuits Circuits from the battery to fusible link, dedicated fuses, ignition switch, general purpose fuses, etc.</li> <li>• Circuits classified by system For each system, the circuits are shown from fuse to earth, excluding the power supply sections.</li> <li>• Operation The normal operation of each system is briefly described, following the route of current flow.</li> <li>• Troubleshooting hints This is a brief explanation of the inspection points that serve as hints when troubleshooting. Explanations of the circuits controlled by the electronic control unit are omitted. Refer to the related publications as required.</li> <li>• Junction block Here is the circuit for the entire junction block since only the part of the junction block needed is normally show in each circuit diagram.</li> </ul>
Wiring diagram	All the harnesses and connectors are shown together so that the circuit diagrams and wiring harnesses of the entire vehicle can be seen at a glance.

## HOW TO READ CONFIGURATION DIAGRAMS

The wiring harness diagrams clearly show the connector locations and harness routings at each site in actual vehicles.



The mark ★ shows the standard mounting position of wiring harness.





Denotes earth point.  
Same earth number is used throughout circuit diagrams to facilitate search of earth point. Refer to GROUP 3 SINGLE PART INSTALLATION POSITION-EARTH MOUNTING LOCATIONS for details of earth points.

Denotes a section covered by a corrugated tube.


## HOW TO READ CIRCUIT DIAGRAMS












The circuit of each system from fuse (or fusible link) to earth is shown. The power supply is shown at the top and the earth at the bottom to facilitate understanding of the current flow.





## MARKINGS FOR CONNECTOR EARTHING



	No	Item	Symbol	Contents
Connector marking	①	Male 		Double connector contour lines indicate male connector terminals and single contour line indicates female terminals as illustrated here.
	-	Female 		
Connector symbol marking	②	Device  Intermediate connector		The symbol indicates the connector as viewed from illustrated direction. At the connection with a device, the connector symbol on the device side is shown, and for an intermediate connector, male connector symbol is shown.
Connector connection marking	③	Direct connection type 		A connection between a device and connector on the harness side is either by direct insertion in the device (direct connection type) or by connection with a harness connector on the device side furnished (harness connection type). The two types are indicated as illustrated.
	④	Harness connection type 		
	⑤	Intermediate connector 		
Earth markings	⑥	Body earth 		Earth is either by body earth, device earth or control unit interior earth. These are indicated as illustrated.
	⑦	Device earth 		
	⑧	Earth in control unit 		

# 1-8 HOW TO READ THE WIRING DIAGRAMS — Symbolic Marks/Wire Colour Codes

## SYMBOLIC MARKS

Devices appearing in circuit diagrams are indicated by the following symbols.

Battery	Body earth	Single bulb	Resistor	Diode	Capacitor
Fuse	Equipment earth	Dual bulb	Variable resistor	Zener diode	Crossing of wires without connection
Fusible link	ECU interior earth	Speaker	Coil	Transistor	Crossing of wires with connection
Connector	Motor	Horn	Pulse generator	Buzzer	Chime
Female side Male side					
Thyristor	Piezoelectric device	Thermistor	Light emitting diode	Photo diode	Photo transistor

## WIRE COLOUR CODES


Wire colours are identified by the following colour codes.

Code	Wire colour	Code	Wire colour
B	Black	P	Pink
BR	Brown	R	Red
G	Green	SB	Sky blue
GR	Gray	V	Violet
L	Blue	W	White
LG	Light green	Y	Yellow
O	Orange		

### NOTE

If a cable has two colours, the first of the two colour code characters indicates the basic colour (colour of the cable coating) and the second indicates marking colour.

Example: <F> 1.25 G - B



## ABBREVIATION SYMBOLS

The abbreviation symbols used in wiring diagrams are defined below.

Abbreviation symbol	Meaning	Abbreviation symbol	Meaning
4WS	4 wheel steering system	GND	Earth
ABS	Anti-lock brake system	ILL	Illumination lamp
DRL	Daytime running lamp	IND	Indicator lamp
ECS	Electronic control suspension	J/B	Junction block
ETACS	Electronic time and alarm control system	SRS	Supplemental restraint system

### Abbreviation symbols used for combination meters

Abbreviation symbol	Meaning	Abbreviation symbol	Meaning
4WS	4WS warning lamp	O/GA	Oil pressure gauge
ABS	Anti-lock brake system warning lamp	OIL	Oil pressure warning lamp
AERO	Active aero system warning lamp	OIL LEVEL	Low engine oil warning lamp
ASC ON	Cruise control ON indicator lamp	REAR FOG	Rear fog lamp indicator lamp
BEAM	Upper beam indicator lamp	SECURITY	Security indicator lamp
BOOST	Boost meter	SPEED	Speedometer
BRAKE	Brake warning lamp	SPORT	Sport mode indicator lamp
CHECK ENGINE	Check engine warning lamp	SRS	Supplemental restraint system warning lamp
CHG	Charging warning lamp	TACHO	Tachometer
CRUISE	Cruise control indicator lamp	T/GA	Engine coolant temperature gauge
DOOR	Door-ajar warning lamp	TOUR	Tour mode indicator lamp
F/GA	Fuel gauge	TURN (LH)	Turn signal indicator lamp (L.H.)
FUEL	Low fuel warning lamp	TURN (RH)	Turn signal indicator lamp (R.H.)
HAZARD	Hazard warning indicator lamp	WASHER	Low washer fluid warning lamp

### Abbreviation symbols used for switches and relays

Name of switches and relays	Abbreviation symbol	Operation	Name of switches and relays	Abbreviation symbol	Operation
Dimmer passing switch	LO	Low beams ON	Room lamp switch	DOOR	Room lamp ON when a door is open
	HI	High beams ON			
Lighting switch	TAIL	Position, tail, licence plate and instrument panel lamps ON	Turn signal switch	LH	L.H. turn signal lamps ON
	HEAD	Headlamps ON		RH	R.H. turn signal lamps ON
Headlamp pop up switch	UP	Headlamps extended	Power window switch	UP	Window closed
	DOWN	Headlamps retracted		DOWN	Window opened
	UP	Headlamps extended	Door lock actuator/Door lock power relay	LOCK	Door locked
	DOWN	Headlamps retracted		UN-LOCK	Door unlocked

Name of switches and relays	Abbreviation symbol	Operation	Name of switches and relays	Abbreviation symbol	Operation
Wiper switch	LO	Wipers operate at low speed	Power seat switch	SLIDE FR	Seat is moved forward.
	HI	Wipers operate at high speed		SLIDE RR	Seat is moved backward.
	INT	Wipers operate intermittently		FRONT HEIGHT UP	Front part of seat cushion is tilted up.
Remote controlled mirror switch	LH	L.H. mirror operates		FRONT HEIGHT DOWN	Front part of seat cushion is tilted down.
	RH	R.H. mirror operates		REAR HEIGHT UP	Rear part of seat cushion is tilted up.
Power seat switch	LUMBER SUPPORT PUSH	Seat back is stood upright.		REAR HEIGHT DOWN	Rear part of seat cushion is tilted down.
	LUMBER SUPPORT RELEASE	Seat back is leaned backward.	Others	ON	Switched on
	SIDE SUPPORT CLOSE	Side support of seat back is closed.		OFF	Switched off
	SIDE SUPPORT SPREAD	Side support of seat back is spread.			

## APPLICABLE MODEL CATEGORIES

The applicable model categories are indicated below for easy identification.

Division	Contents
MPI	Indicates vehicles with multi-point injection
LHD	Indicates L.H. drive vehicles
RHD	Indicates R.H. drive vehicles

## HOW TO READ WIRING DIAGRAM


Indicates the connector No.  
The same No. as the wiring diagram  
and circuit diagram is used.

Indicates the  
harness entry  
location number.

Junction points indicated by  
a square (—□—) indicate cir-  
cuits with differences in  
specifications.

Indicates the harness  
name and harness  
entry location.  
(In this case, this indicates that the harness  
is the roof harness, and that it is entered in  
the harness entry location number of 5.)  
Example: <5-2>

Classification num-  
ber  
Harness entry loca-  
tion number



Indicates the connector ter-  
minal No.  
Identical symbols are en-  
tered to indicate which  
harness corresponds to which  
connector terminal.

Indicates  
size of wire  
(mm<sup>2</sup>)

Indicates  
wire colour  
code.

The connector symbol shows the  
harness-side connector as seen  
from front-on (from the direction shown  
in the illustration).

---

**NOTES**

## **1B HOW TO READ THE WIRING DIAGRAMS**

<b>MODELS .....</b>	<b>1B-2</b>
<b>COMPOSITION AND CONTENTS OF WIRING DIAGRAMS .....</b>	<b>1B-2</b>
<b>HOW TO READ CONFIGURATION DIAGRAMS</b>	
<b>HOW TO READ CIRCUIT DIAGRAMS</b>	
<b>MARKINGS FOR CONNECTOR EARTHING</b>	{ Refer to '93 models' Electrical wiring
<b>WIRE COLOUR CODES</b>	
<b>ABBREVIATION SYMBOLS</b>	

## MODELS

Model code		Engine model	Transmission model	Fuel supply system
Z16A	MNGFL6	6G72 (3000-DOHC-24V-twin turbocharger)	W5MG1 (4WD-5M/T)	MPI
	MNGFR6			
	MJGFL6			
	MJGFR6		W6MG1 (4WD-6M/T)	

## COMPOSITION AND CONTENTS OF WIRING DIAGRAMS

- (1) This manual consists of wiring harness diagrams, installation locations of individual parts, circuit diagrams and index.
- (2) In each of the sections, all specifications are listed, including optional specifications. Accordingly, some specifications may not be applicable for individual vehicles.

Section	Basic contents
Wiring harness configuration diagrams	Connector locations and harness wiring configurations on actual vehicles are illustrated.
Single part installation position	Locations are shown for earth points of relays, control units, sensors, solenoids, solenoid valves, diodes, inspection connectors, spare connectors, fusible links, fuses, etc. In the parts lists, parts are listed in alphabetical order.
Circuit diagrams	<p>Circuits from power supply to earth are shown completely, classified according to system. There is a main division into power circuits, and circuits classified by system. The circuits classified by system also include operation and troubleshooting hints.</p> <ul style="list-style-type: none"> <li>• Power supply circuits Circuits from the battery to fusible link, dedicated fuses, ignition switch, general purpose fuses, etc.</li> <li>• Circuits classified by system For each system, the circuits are shown from fuse to earth, excluding the power supply sections.</li> <li>• Operation The normal operation of each system is briefly described, following the route of current flow.</li> <li>• Troubleshooting hints This is a brief explanation of the inspection points that serve as hints when troubleshooting. Explanations of the circuits controlled by the electronic control unit are omitted. Refer to the related publications as required.</li> <li>• Junction block Here is the circuit for the entire junction block since only the part of the junction block needed is normally shown in each circuit diagram.</li> </ul>
Index	All components used are listed by connector number and component name.

## **2 WIRING HARNESS CONFIGURATION DIAGRAMS**

### **1 OVERALL WIRING DIAGRAM**

1-1 L.H. drive vehicles .....	2-3
1-2 R.H. drive vehicles .....	2-3

### **2 ENGINE COMPARTMENT [A]**

2-1 L.H. drive vehicles .....	2-4
2-2 R.H. drive vehicles .....	2-6

### **3 ENGINE AND TRANSMISSION [B] ..... 2-8**

### **4 DASH PANEL [C]**

4-1 L.H. drive vehicles .....	2-10
4-2 R.H. drive vehicles .....	2-12

### **5 INSTRUMENT PANEL AND FLOOR CONSOLE [D]**

5-1 L.H. drive vehicles .....	2-14
5-2 R.H. drive vehicles .....	2-16

### **6 INTERIOR [E]**


6-1 L.H. drive vehicles .....	2-18
6-2 R.H. drive vehicles .....	2-20

### **7 LUGGAGE COMPARTMENT [F] ..... 2-22**


**NOTES**

# 1 OVERALL WIRING DIAGRAM

## 1-1 L.H. drive vehicles



## 1-2 R.H. drive vehicles





### NOTE

- (1) This illustration shows only the major wiring harness.
- (2) \*indicates also equipped at the right side.

## 2 ENGINE COMPARTMENT

### 2-1 L.H. drive vehicles




- |       |   |
|-------|---|
| A-01X | Headlamp relay  |
| A-02X | ABS power relay   |
| A-03X | Driving lamp relay  |
| A-04X | Radiator fan motor relay (LO)                                 |
| A-05X | Tail lamp relay   |
| A-06X | Horn relay  |
| A-07X | Radiator fan motor relay (HI)                                 |
| A-08X | Pop-up motor relay  |
| A-09X | Starter relay   |
| A-10X | Alternator relay  |
| A-11X | Storage connector   |
| A-12  | ABS front speed sensor (RH)                                   |
| A-13  | Side turn signal lamp (RH)                                    |
| A-14  | ECS front shock absorber (RH)                                 |
| A-15  | Washer fluid level sensor                                     |
| A-16  | Front wiper motor   |
| A-17  | Engine speed detection connector                              |
| A-18  | Fuel pump check connector                                     |
| A-19  | Ignition timing adjustment connector                          |
| A-20  | Front washer motor  |
| A-21  | Resistor  |
| A-22  | Control wiring harness and solenoid valve harness combination |
| A-23  | Waste gate solenoid valve                                     |
| A-24  | Fuel pressure solenoid valve                                  |
| A-25  | Purge control solenoid valve                                  |
| A-26  | EGR control solenoid valve                                    |
| A-27  | Brake fluid level sensor                                      |
| A-28  | ECS front shock absorber (LH)                                 |
| A-29  | Side turn signal lamp (LH)                                    |
| A-30  | Auto-cruise vacuum pump                                       |
| A-31  | Theft-alarm horn  |
| A-32  |   |

Refer to  
CENTRALIZED  
JUNCTION



A-74 A-73 A-72 A-71 A-70 A-69 A-68 A-67 A-66 A-65 A-64 A-63 A-62 A-61

- |       |                                   |
|-------|-----------------------------------|
| A-33  | ABS front speed sensor (LH)       |
| A-34  | 4WS fluid level sensor            |
| A-35  | Daytime running lamp relay 1.2    |
| A-36  |                                   |
| A-37  | Daytime running lamp control unit |
| A-38  | —                                 |
| A-39  | —                                 |
| A-40  | —                                 |
| A-41  | Condenser fan motor relay (HI)    |
| A-42  | Radiator fan motor control relay  |
| A-43  | Magnetic clutch relay             |
| A-44X | Condenser fan motor relay (LO)    |
| A-45X | Radiator fan motor control relay  |
| A-46X | Magnetic clutch relay             |
| A-47X | Condenser fan motor relay (LO)    |
| A-48  | Dual pressure switch              |
| A-49  | Air conditioner relay box         |
| A-50  |                                   |

Refer to  
CENTRALIZED  
JUNCTION




### ENGINE HOOD





- |      |   |
|------|---|
| A-51 | SRS front impact sensor (LH)                                      |
| A-52 | Front combination lamp (LH)                                       |
| A-53 | Inspection lamp switch  |
| A-54 | Headlamp (LH)   |
| A-55 | Headlamp leveling unit (LH)                                       |
| A-56 | Driving lamp (LH)   |
| A-57 | Front wiring harness and headlamp wiring harness (LH) combination |
| A-58 | Pop-up motor (LH)   |
| A-59 | Condenser fan motor   |
| A-60 |   |
| A-61 | Horn  |
| A-64 |   |
| A-65 | Fuel pump resistor  |
| A-66 | Radiator fan motor  |
| A-67 | Headlamp washer motor   |
| A-68 | Engine coolant level sensor                                       |

- |      |   |
|------|---|
| A-69 | Active aero front venturi skirt                                   |
| A-70 | Driving lamp (RH)   |
| A-71 | Pop-up motor (RH)   |
| A-72 | Front wiring harness and headlamp wiring harness (RH) combination |
| A-73 | Headlamp leveling unit (RH)                                       |
| A-74 | Headlamp (RH)   |
| A-75 | Front combination lamp (RH)                                       |
| A-76 | SRS front impact sensor (RH)                                      |
| A-77 | ABS hydraulic unit  |
| A-78 |   |
| A-79 | Hood switch   |
| A-80 | Front wiring harness and control wiring harness combination       |
| A-81 | —   |
| A-82 |   |
| A-83 |   |
| A-84 |   |
| A-85 |   |
| A-86 | Diode (for ABS circuit)   |
|      | No connection   |
|      | Inspection lamp   |

**2-2 R.H. drive vehicles**




**Vehicles with dim-dip lamp**



A-01X	Headlamp relay
A-02X	ABS power relay
A-03X	Driving lamp relay
A-04X	Radiator fan motor relay (LO)
A-05X	Tail lamp relay
A-06X	Horn relay
A-07X	Radiator fan motor relay (HI)
A-08X	Pop-up motor relay
A-09X	Starter relay
A-10X	Alternator relay
A-11X	Storage connector
A-12	ABS front speed sensor (RH)
A-13	Side turn signal lamp (RH)
A-14	ECS front shock absorber (RH)
A-15	Washer fluid level sensor
A-16	Front wiper motor
A-17	Engine speed detection connector
A-18	Fuel pump check connector
A-19	Ignition timing adjustment connector


Refer to  
CENTRALIZED  
JUNCTION

A-20	Front washer motor
A-21	Resistor
A-22	Control wiring harness and solenoid valve harness combination
A-23	Waste gate solenoid valve
A-24	Fuel pressure solenoid valve
A-25	Purge control solenoid valve
A-26	EGR control solenoid valve
A-27	Brake fluid level sensor
A-28	ECS front shock absorber (LH)
A-29	Side turn signal lamp (LH)
A-30	Auto-cruise vacuum pump
A-31	Theft-alarm horn
A-32	
A-33	ABS front speed sensor (LH)
A-34	4WS fluid level sensor
A-35	
A-36	
A-37	—





- A-38 } Diode (for dim-dip lamp)
- A-41 }
- A-42 Resistor <Vehicles with dim-dip lamp>
- A-43 Jumper connector <Vehicles with dim-dip lamp>
- A-44X Condenser fan motor relay (HI)
- A-45X Radiator fan motor control relay
- A-46X Magnetic clutch relay
- A-47X Condenser fan motor relay (LO)
- Refer to CENTRALIZED JUNCTION
- A-48 Dual pressure switch
- A-49 }
- A-50 Air conditioner relay box
- A-51 SRS front impact sensor (LH)
- A-52 Front combination lamp (LH)
- A-53 Inspection lamp switch

### ENGINE HOOD




- A-54 Headlamp (LH)
- A-55 Headlamp leveling unit (LH)
- A-56 Driving lamp (LH)
- A-57 Front wiring harness and headlamp wiring harness (LH) combination
- A-58 Pop-up motor (LH)
- A-59 Condenser fan motor
- A-60 Horn
- A-61 thru A-64
- A-65 Fuel pump resistor
- A-66 Radiator fan motor
- A-67 Headlamp washer motor
- A-68 Engine coolant level sensor
- A-69 Active aero front venturi skirt
- A-70 Driving lamp (RH)
- A-71 Pop-up motor (RH)
- A-72 Front wiring harness and headlamp wiring harness (RH) combination
- A-73 Headlamp leveling unit (RH)
- A-74 Headlamp (RH)
- A-75 Front combination lamp (RH)
- A-76 SRS front impact sensor (RH)
- A-77 ABS hydraulic unit
- A-78 Hood switch
- A-79 Front wiring harness and control wiring harness combination
- A-80
- A-81 Dim-dip lamp relay 1.2.3
- A-82
- A-83
- A-84 Diode (for ABS circuit)
- A-85 —
- A-86 Inspection lamp

## 3 ENGINE AND TRANSMISSION



- |      |   |      |                    |
|------|---|------|--------------------|
| B-01 | Engine coolant temperature gauge unit                                 | B-09 | Injector No. 5     |
| B-02 | Engine coolant temperature sensor                                     | B-10 | Injector No. 3     |
| B-03 | Engine coolant temperature switch<br>(for air conditioner circuit)    | B-11 | Oxygen sensor (LH) |
| B-04 | —   | B-12 | Injector No. 1     |
| B-05 | Throttle position sensor  | B-13 | Ignition coil      |
| B-06 | Control wiring harness and oil<br>pressure wiring harness combination | B-14 | Noise capacitor    |
| B-07 | Control wiring harness and injector<br>wiring harness combination     | B-15 | Alternator         |
| B-08 | Detonation sensor   | B-16 |                    |
|      |   | B-17 | Oxygen sensor (RH) |
|      |   | B-18 | Magnetic clutch    |




36F0034

B-19	Power transistor	B-28	Injector No. 4
B-20		B-29	Injector No. 6
B-21	Starter motor	B-30	Speed sensor
B-22		B-31	Idle speed control servo (stepper motor)
B-23	Back-up lamp switch	B-32	Engine oil pressure level sensor
B-24	Fuel pump relay	B-33	Oil pressure gauge unit
B-25	Air flow sensor (with intake air temperature sensor and atmospheric sensor)	B-34	Oil pressure switch
B-26	Control wiring harness and battery cable combination	B-35	Power steering oil pressure switch
B-27	Injector No. 2	B-36	Cam position sensor
		B-37	Crank angle sensor


## 4 DASH PANEL

### 4-1 L.H. drive vehicles





#### JUNCTION BLOCK

Front side




Rear side




- |       |  |
|-------|--|
| C-01  | Body wiring harness (main)   |
| C-02  | and front wiring   |
| C-03  | harness combination  |
| C-04X | Door lock relay  |
| C-05X | Rear fog lamp relay  |
| C-06X | Defogger relay   |
| C-07X | Power window relay   |
| C-08  | Diode (for daytime running lamp)   |
| C-09  | Column switch  |
| C-10  | Diode (for theft-alarm circuit)  |
| C-11  | Control wiring harness and instrument panel wiring harness combination     |
| C-12  | Body wiring harness (main) and instrument panel wiring harness combination |
| C-13  | Blend air damper control motor   |
| C-14  | Mode selection damper control motor  |
| C-15  | Air conditioner control panel  |
| C-16  | Power transistor (for air conditioner circuit)                             |
- Refer to CENTRALIZED JUNCTION

- |      |  |
|------|--|
| C-19 | Air-inlet sensor                             |
| C-20 | Air selection damper control motor           |
| C-21 | Body wiring harness (main) and control       |
| C-22 | wiring harness combination                   |
| C-23 | Body wiring harness (main) and front wiring  |
| C-24 | harness combination                          |
| C-25 | Body wiring harness (sub) and front wiring   |
| C-26 | harness combination                          |
| C-27 | Body wiring harness (main) and body wiring   |
| C-28 | harness (sub) combination                    |
| C-29 | Foot lamp (RH)                               |
| C-30 | Body wiring harness (sub) and control wiring |
| C-31 | harness combination                          |
| C-32 | Auto-cruise control unit                     |
| C-33 | Blower motor                                 |
| C-34 | Blower motor relay (HI)                      |
| C-35 | Air conditioner compressor lock controller   |
| C-36 | Air-thermo sensor                            |
| C-37 | Engine coolant temperature sensor            |
| C-38 | Engine control relay                         |




- |      |   |
|------|---|
| C-37 | Diode (for daytime running lamp)                          |
| C-38 | Diode (for rear fog lamp circuit)                         |
| C-39 | —   |
| C-40 | Lighting monitor buzzer                                   |
| C-41 | Headlamp washer relay                                     |
| C-42 | Engine oil level sensor relay                             |
| C-43 | Front wiring harness and junction block combination       |
| C-44 | Engine control unit                                       |
| C-45 | Adapter wiring harness and junction block combination     |
| C-46 | Theft-alarm horn relay                                    |
| C-47 | Steering wheel angle speed sensor                         |
| C-48 | Diagnosis connector                                       |
| C-49 | Blower motor relay  |
| C-50 | Roof wiring harness and junction block combination        |
| C-51 | Body wiring harness (main) and junction block combination |
| C-52 | No connection   |
| C-53 | Clutch pedal switch                                       |
| C-54 | ETACS control unit  |
| C-55 | No connection   |
| C-56 | Foot lamp (LH)  |
| C-57 | —   |
| C-58 | —   |
| C-59 | —   |
| C-60 | —   |
| C-61 | —   |
| C-62 | —   |
| C-63 | —   |
| C-64 | —   |
| C-65 | —   |
| C-66 | —   |
| C-67 | —   |
| C-68 | —   |
| C-69 | —   |
| C-70 | —   |
| C-71 | —   |
| C-72 | —   |
| C-73 | —   |
| C-74 | —   |
| C-75 | —   |
| C-76 | —   |
| C-77 | —   |
| C-78 | —   |
| C-79 | —   |
| C-80 | —   |

**4-2 R.H. drive vehicles**



C-01	Body wiring harness (main) and front wiring harness combination	C-19	Air-inlet sensor
C-02	—	C-20	Air selection damper control motor
C-03	Body wiring harness (main) and front wiring harness combination	C-21	Body wiring harness (main) and control
C-04X	Door lock relay	C-22	wiring harness combination
C-05X	Rear fog lamp relay	C-23	Body wiring harness (main) and front wiring harness
C-06X	Defogger relay	C-24	combination
C-07X	Power window relay	C-25	—
C-08	—	C-26	—
C-09	Column switch	C-27	—
C-10	—	C-28	Foot lamp (RH)
C-11	Diode (for theft-alarm circuit)	C-29	—
C-12	Control wiring harness and instrument panel wiring harness combination	C-30	Auto-cruise control unit
C-13	Body wiring harness (main) and instrument panel wiring harness combination	C-31	Blower motor
C-14	Blend air damper control motor	C-32	Blower motor relay (HI)
C-15	Mode selection damper control motor	C-33	Air conditioner compressor lock controller
C-16	Air conditioner control panel	C-34	Air-thermo sensor
C-17	—	C-35	Engine coolant temperature sensor
C-18	Power transistor (for air conditioner circuit)	C-36	Engine control relay
		C-37	Air conditioner control unit
		C-38	—
		C-39	—
		C-40	Lighting monitor buzzer

## Vehicles with theft-alarm system



C-41 Headlamp washer relay  
C-42 Engine oil level sensor relay

C-43  
C-44 } Engine control unit  
C-45 }

C-46 Auto-cruise relay  
C-47 Steering wheel angle speed sensor  
C-48 Clock spring

C-49 —

C-50 Stop lamp switch  
C-51 Key reminder switch

C-52 Ignition switch

C-53 Clutch pedal switch

C-54 } ETACS control unit  
C-55 }




C-56 Foot lamp (LH)

C-57 —

C-58 —

C-59 Body wiring harness (main) and front wiring harness combination



C-60 Body wiring harness (main) and control wiring harness combination





- |      |  |
|------|--|
| C-61 | Body wiring harness (main) and body wiring harness (sub) combination |
| C-62 | Body wiring harness (sub) and front wiring harness combination       |
| C-63 | Front wiring harness and junction block combination                  |
| C-64 | Adapter wiring harness and junction block combination                |
| C-65 | Theft-alarm horn relay   |
| C-66 | Diagnosis connector  |
| C-67 | Blower motor relay   |
| C-68 | Roof wiring harness and junction block combination                   |
| C-69 | Body wiring harness (main) and junction block combination            |
| C-70 | No connection  |
| C-71 | Diode (pop-up circuit)   |
| C-72 | Body wiring harness (main) and junction block combination            |
| C-73 | Body wiring harness (main) and junction block combination            |
| C-74 | Body wiring harness (main) and junction block combination            |
| C-75 | Body wiring harness (main) and junction block combination            |
| C-76 | Body wiring harness (main) and junction block combination            |
| C-77 | Body wiring harness (main) and junction block combination            |
| C-78 | Body wiring harness (main) and junction block combination            |
| C-79 | Body wiring harness (main) and junction block combination            |
| C-80 | Body wiring harness (main) and junction block combination            |
| C-81 | Body wiring harness (main) and junction block combination            |

## 5 INSTRUMENT PANEL AND FLOOR CONSOLE

### 5-1 L.H. drive vehicles



- |              |   |      |  |
|--------------|---|------|--|
| D-01         | Pop-up switch and fog lamp switch                   | D-13 | Front speaker (RH)   |
| D-02         | Front speaker (LH)                                  | D-14 | Glove box illumination lamp switch   |
| D-03         | Combination meter                                   | D-15 | Instrument panel wiring harness and control<br>wiring harness combination    |
| thru<br>D-05 |   | D-16 | Instrument panel wiring harness and body<br>wiring harness (sub) combination |
| D-06         | Defogger switch and ECS switch                      | D-17 | Ashtray illumination lamp  |
| D-07         | Hazard switch                                       | D-18 | Cigarette lighter  |
| D-08         | Clock   | D-19 |  |
| D-09         | Combination gauge                                   | D-20 | Cigarette lighter illumination lamp  |
| D-10         | Diode (for 4WS fluid level warning<br>lamp circuit) | D-21 | Power seat switch  |
| D-11         | Glove box illumination lamp                         | D-22 | Body wiring harness (main) and console<br>wiring harness combination         |
| D-12         | Photo sensor  |      |  |





36F0043

- D-23 }  
thru SRS diagnosis unit
- D-26 }  
ABS G sensor
- D-27 ABS G sensor
- D-28 Parking brake switch
- D-29 Active aero switch
- D-30 } Accessory socket
- D-31 }
- D-32 Auto-cruise main switch
- D-33 Jumper connector
- D-34 Pop-up relay
- D-35 } Radio
- D-36 }


- D-37 Rear wiper and washer switch
- D-38 Headlamp leveling switch
- D-39 No connection
- D-40 Remote-control mirror switch
- D-41 Rheostat
- D-42 } Instrument panel wiring harness and  
D-43 } body wiring harness (main) combination
- D-44 }
- D-45 Instrument panel wiring harness and adapter  
wiring harness combination
- D-46 Instrument panel wiring harness and front  
wiring harness combination

## 5-2 R.H. drive vehicles



- D-01 Pop-up switch and fog lamp switch
- D-02 Front speaker (LH)
- D-03
- D-04 Combination meter
- D-05
- D-06 Defogger switch and ECS switch
- D-07 Hazard switch
- D-08 Clock
- D-09 Combination gauge
- D-10 Diode (for 4WS fluid level warning lamp circuit)
- D-11 Glove box illumination lamp
- D-12 Photo sensor

- D-13 Front speaker (RH)
- D-14 Glove box illumination lamp switch
- D-15 Instrument panel wiring harness and control wiring harness combination
- D-16 Instrument panel wiring harness and body wiring harness (sub) combination
- D-17 Ashtray illumination lamp
- D-18
- D-19 Cigarette lighter
- D-20 Cigarette lighter illumination lamp
- D-21 Power seat switch
- D-22 Body wiring harness (main) and console wiring harness combination




36F0035

- D-23 }  
thru SRS diagnosis unit
- D-26 }
- D-27 ABS G sensor
- D-28 Parking brake switch
- D-29 Active aero switch
- D-30 }  
D-31 } —
- D-32 Auto-cruise main switch
- D-33 Jumper connector
- D-34 Pop-up relay
- D-35 }  
D-36 } Radio

- D-37 Rear wiper and washer switch
- D-38 Headlamp leveling switch
- D-39 No connection
- D-40 Remote-control mirror switch
- D-41 Rheostat
- D-42 }  
D-43 } Instrument panel wiring harness and  
body wiring harness (main) combination
- D-44 }
- D-45 Instrument panel wiring harness and adapter  
wiring harness combination
- D-46 Instrument panel wiring harness and front  
wiring harness combination


## 6 INTERIOR

### 6-1 L.H. drive vehicles



- E-01 Body wiring harness (main) and door wiring harness (RH) combination
- E-02 Door mirror (RH)
- E-03 Door speaker (RH)
- E-04 Room lamp
- E-05 Power window sub switch
- E-06 Power window motor (Passenger's side)
- E-07 Door lamp (Passenger's side)


- E-08 Door key cylinder unlock switch (Passenger's side)
- E-09 Door lock actuator (Passenger's side)
- E-10 ABS control unit
- E-11 ABS resistor
- E-12 Door switch (Passenger's side)
- E-13 ABS rear speed sensor (RH)
- E-14 Rear intermittent wiper relay
- E-15 ABS rear speed sensor (LH)



36F0039


- |      |   |      |  |  |
|------|---|------|--|--|
| E-16 | Door switch (Driver's side)                     | E-25 | Jumper connector   |  |
| E-17 | Door lock actuator (Driver's side)              | E-26 | Body wiring harness (main) and door<br>wiring harness (LH) combination |  |
| E-18 | Door key cylinder unlock switch (Driver's side) | E-27 | Door mirror (LH)   |  |
| E-19 | Door lamp (Driver's side)                       | E-28 | Power window main switch   |  |
| E-20 | Power seat assembly                             | E-29 | Power window motor (Driver's side)                                     |  |
| E-21 | ECS G sensor                                    | E-30 | —  |  |
| E-22 | Door speaker                                    | E-31 |  |  |
| E-23 | Turn signal and hazard flasher unit             | E-32 |  |  |
| E-24 | Diode (for MPI circuit)                         |      |  |  |

## 6-2 R.H. drive vehicles



- |      |  |
|------|--|
| E-01 | —  |
| E-02 | Door mirror (RH)                                   |
| E-03 | Door speaker (RH)                                  |
| E-04 | Room lamp  |
| E-05 | Power window sub switch                            |
| E-06 | Power window motor (Passenger's side)              |
| E-07 | Door lamp (Passenger's side)                       |
| E-08 | Door key cylinder unlock switch (Passenger's side) |



- |      |                                       |
|------|---------------------------------------|
| E-09 | Door lock actuator (Passenger's side) |
| E-10 | ABS control unit                      |
| E-11 | ABS resistor                          |
| E-12 | Door switch (Passenger's side)        |
| E-13 | ABS rear speed sensor (RH)            |
| E-14 | Rear intermittent wiper relay         |
| E-15 | ABS rear speed sensor (LH)            |
| E-16 | Door switch (Driver's side)           |



- E-17 Door lock actuator (Driver's side)
- E-18 Door key cylinder unlock switch (Driver's side)
- E-19 Door lamp (Driver's side)
- E-20 Power seat assembly
- E-21 ECS G sensor
- E-22 Door speaker
- E-23 Turn signal and hazard flasher unit
- E-24 Diode (for MPI circuit)
- E-25 Jumper connector

- E-26 Body wiring harness (main) and door wiring harness (LH) combination
- E-27 Door mirror (LH)
- E-28 Power window main switch
- E-29 Power window motor (Driver's side)
- E-30 Body wiring harness (main) and door wiring harness (RH) combination
- E-31 No connection
- E-32 Body wiring harness (main) and door wiring harness (LH) combination

## **7 LUGGAGE COMPARTMENT**



- |        |  |        |   |
|--------|--|--------|---|
| F-01   | Interior temperature sensor  | F-17   | Body wiring harness (sub) and rear bumper wiring harness combination <LHD>  |
| F-02   | Defogger (+)   |        | Body wiring harness (main) and rear bumper wiring harness combination <RHD> |
| F-03   | Rear wiper motor   | F-18 } | Body wiring harness (main) and body   |
| F-04   | Active aero rear spoiler   | F-19 } | wiring harness (sub) combination  |
| F-05   | Defogger (-)   | F-20   | License plate lamp (LH)   |
| F-06   | Rear speaker (RH)  | F-21   | Luggage compartment lamp switch   |
| F-07   | ECS rear shock absorber (RH)   | F-22   | Tailgate cylinder lock switch   |
| F-08   | Luggage compartment lamp   | F-23   | Tailgate switch   |
| F-09   | Rear combination lamp (RH)   | F-24   | Buck-up lamp (LH)   |
| F-10   | Back-up lamp (RH)  | F-25 } | Active aero control unit  |
| F-11 } | ECS control unit   | F-26 } |   |
| F-12 } |  | F-27   | Rear combination lamp (LH)  |
| F-13   | Body wiring harness (sub) and fuel tank<br>wiring harness combination <LHD>  | F-28   | Motor antenna control unit  |
|        | Body wiring harness (main) and fuel tank<br>wiring harness combination <RHD> | F-29   | ECS rear shock absorber (LH)  |
| F-14   | Rear washer motor  | F-30   | Rear speaker (LH)   |
| F-15   | Fuel tank  | F-31 } | Body wiring harness (main) and tailgate<br>wiring harness combination <LHD> |
| F-16   | Licence plate lamp (RH)  | F-32 } | Body wiring harness (sub) and tailgate<br>wiring harness combination <RHD>  |

## **2B WIRING HARNESS CONFIGURATION DIAGRAMS**

### **OVERALL WIRING DIAGRAM**

L.H. drive vehicles .....	2B-3
R.H. drive vehicles .....	2B-3

### **ENGINE COMPARTMENT [A]**

L.H. drive vehicles .....	2B-4
R.H. drive vehicles .....	2B-6

### **ENGINE AND TRANSMISSION [B] .....** **2B-8**

### **DASH PANEL [C]**

L.H. drive vehicles .....	2B-10
R.H. drive vehicles .....	2B-12

### **INSTRUMENT PANEL AND FLOOR CONSOLE [D]**



L.H. drive vehicles .....	2B-14
R.H. drive vehicles .....	2B-16

### **INTERIOR [E]**


L.H. drive vehicles .....	2B-18
R.H. drive vehicles .....	2B-20

### **LUGGAGE COMPARTMENT [F] .....** **2B-22**


**NOTES**

**OVERALL WIRING DIAGRAM****L.H. drive vehicles****R.H. drive vehicles****NOTE**


- (1) This illustration shows only the major wiring harness.
- (2) \*indicates also equipped at the right side.

**ENGINE COMPARTMENT****L.H. drive vehicles**

A-01X	Headlamp relay
A-02X	—
A-03X	—
A-04X	Radiator fan motor relay (LO)
A-05X	Tail lamp relay
A-06X	Horn relay
A-07X	Radiator fan motor relay (HI)
A-08X	—
A-09X	Starter relay
A-10X	Alternator relay
A-11X	Storage connector
A-12	ABS front speed sensor (RH)
A-13	Side turn signal lamp (RH)
A-14	Control wiring harness and ECS front shock absorber joint wiring harness (RH) combination
A-15	Washer fluid level sensor
A-16	Windshield wiper motor
A-17	Engine speed detection connector
A-18	Fuel pump check connector
A-19	Ignition timing adjustment connector
A-20	Windshield washer motor
A-21	Resistor
A-22	Control wiring harness and solenoid valve wiring harness combination
A-23	Waste gate solenoid valve
A-24	Fuel pressure solenoid valve
A-25	Purge control solenoid valve
A-26	EGR control solenoid valve
A-27	Brake fluid level sensor
A-28	Front wiring harness and ECS front shock absorber joint wiring harness (LH) combination
A-29	Side turn signal lamp (LH)
A-30	Auto-cruise vacuum pump
A-31	Theft-alarm horn
A-32	Theft-alarm horn




A-33	ABS front speed sensor (LH)
A-34	4WS fluid level sensor
A-35	—
A-36	Daytime running lamp relay
A-37	Daytime running lamp control unit
A-38	—
A-43	—
A-44X	Condenser fan motor relay (HI)
A-45X	—
A-46X	Magnetic clutch relay
A-47X	Condenser fan motor relay (LO)
A-48	Dual pressure switch
A-49	—
A-50	A/C relay box
A-51	SRS front impact sensor (LH)
A-52	Front turn signal lamp (LH)




- A-53 Inspection lamp switch
- A-54 Headlamp (LH: HI)
- A-55 Headlamp leveling unit (LH)
- A-56
- A-57 } —
- A-58 } —
- A-59 } Condenser fan motor
- A-60 } —
- A-61 } Horn
- A-62 } —
- A-63 } —
- A-64 } —
- A-65 Fuel pump resistor
- A-66 Radiator fan motor
- A-67 Headlamp washer motor
- A-68 Engine coolant level sensor
- A-69 Active aero front venturi skirt
- A-70 } —
- A-71 } —
- A-72 } —
- A-73 Headlamp leveling unit (RH)

### ENGINE HOOD





### Vehicles with daytime running lamp



- A-74 Headlamp (RH: HI)
- A-75 Front turn signal lamp (RH)
- A-76 SRS front impact sensor (RH)
- A-77 } ABS hydraulic unit
- A-78 }
- A-79 Hood switch <Vehicles with theft-alarm system>
- A-80 Front wiring harness and control wiring harness combination
- A-81 } —
- A-82 } —
- A-83 } —
- A-84 Diode (for ABS circuit)
- A-85 No connection
- A-86 Inspection lamp
- A-87 ECS front shock absorber (RH)
- A-88 ECS front shock absorber (LH)
- A-89 Position lamp (LH)
- A-90 Position lamp (RH)
- A-91 Headlamp (LH: LO)
- A-92 Headlamp (RH: LO)
- A-93 No connection

**ENGINE COMPARTMENT**

R.H. drive vehicles





A-01X	Headlamp relay
A-02X	—
A-03X	—
A-04X	Radiator fan motor relay (LO)
A-05X	Tail lamp relay
A-06X	Horn relay
A-07X	Radiator fan motor relay (HI)
A-08X	—
A-09X	Starter relay
A-10X	Alternator relay
A-11X	Storage connector
A-12	ABS front speed sensor (RH)
A-13	Side turn signal lamp (RH)
A-14	Control wiring harness and ECS front shock absorber joint wiring harness (RH) combination
A-15	Washer fluid level sensor
A-16	Windshield wiper motor
A-17	Engine speed detection connector
A-18	Fuel pump check connector
A-19	Ignition timing adjustment connector
A-20	Windshield washer motor
A-21	Resistor

Refer to  
CENTRALIZED  
JUNCTION

A-22	Control wiring harness and solenoid valve wiring harness combination
A-23	Waste gate solenoid valve
A-24	Fuel pressure solenoid valve
A-25	Purge control solenoid valve
A-26	EGR control solenoid valve
A-27	Brake fluid level sensor
A-28	Front wiring harness and ECS front shock absorber joint wiring harness (LH) combination
A-29	Side turn signal lamp (LH)
A-30	Auto-cruise vacuum pump
A-31	Theft-alarm horn
A-32	—
A-33	ABS front speed sensor (LH)
A-34	4WS fluid level sensor
A-35	—
A-36	—
A-37	—


## ENGINE HOOD



- |                                     |   |
|-------------------------------------|---|
| A-38 }<br>thru }                    | Diode (for dim-dip lamp)                                    |
| A-41 }                              |   |
| A-42                                | Resistor <Vehicles with dim-dip lamp>                       |
| A-43                                | Joint connector <Vehicles with dim-dip lamp>                |
| A-44X                               | Condenser fan motor relay (HI)                              |
| A-45X                               | —   |
| A-46X                               | Magnetic clutch relay                                       |
| A-47X                               | Condenser fan motor relay<br>(LO)                           |
| A-48                                | Dual pressure switch  |
| A-49 }<br>A-50 }                    | A/C relay box   |
| A-51                                | SRS front impact sensor (LH)                                |
| A-52                                | Front turn signal lamp (LH)                                 |
| A-53                                | Inspection lamp switch                                      |
| A-54                                | Headlamp (LH: HI)   |
| A-55                                | Headlamp leveling unit (LH)                                 |
| Refer to<br>CENTRALIZED<br>JUNCTION |   |
| A-56 }<br>A-57 }                    | —   |
| A-58                                |   |
| A-59 }<br>A-60 }                    | Condenser fan motor   |
| A-61 }<br>thru }                    | Horn  |
| A-64                                |   |
| A-65                                | Fuel pump resistor  |
| A-66                                | Radiator fan motor  |
| A-67                                | Headlamp washer motor                                       |
| A-68                                | Engine coolant level sensor                                 |
| A-69                                | Active aero front venturi skirt                             |
| A-70 }<br>A-71 }                    | —   |
| A-72                                |   |
| A-73                                | Headlamp leveling unit (RH)                                 |
| A-74                                | Headlamp (RH: HI)   |
| A-75                                | Front turn signal lamp (RH)                                 |
| A-76                                | SRS front impact sensor (RH)                                |
| A-77 }<br>A-78 }                    | ABS hydraulic unit  |
| A-79                                | Hood switch <Vehicles with theft-alarm system>              |
| A-80                                | Front wiring harness and control wiring harness combination |
| A-81                                | Dim-dip lamp relay 1 or no connection                       |
| A-82 }<br>A-83 }                    | Dim-dip lamp relay 2,3 or jumper connector                  |
| A-84                                | Diode (for ABS circuit)                                     |
| A-85                                | —   |
| A-86                                | Inspection lamp   |
| A-87                                | ECS front shock absorber (RH)                               |
| A-88                                | ECS front shock absorber (LH)                               |
| A-89                                | Position lamp (LH)  |
| A-90                                | Position lamp (RH)  |
| A-91                                | Headlamp (LH: LO)   |
| A-92                                | Headlamp (RH: LO)   |
| A-93                                | No connection   |


## ENGINE AND TRANSMISSION

Connector symbol



36F0138

- |          |  |             |                    |
|----------|--|-------------|--------------------|
| B-01     | Engine coolant temperature gauge unit                              | B-09        | Injector No. 5     |
| B-02     | Engine coolant temperature sensor                                  | B-10        | Injector No. 3     |
| B-03 } - |  | B-11        | Oxygen sensor (LH) |
| B-04 }   |  | B-12        | Injector No. 1     |
| B-05     | Throttle position sensor   | B-13        | Ignition coil      |
| B-06     | Control wiring harness and oil pressure wiring harness combination | B-14        | Noise capacitor    |
| B-07     | Control wiring harness and injector wiring harness combination     | B-15 } B-16 | Alternator         |
| B-08     | Detonation sensor  | B-17        | Oxygen sensor (RH) |
|          |  | B-18        | Magnetic clutch    |





36F0034



B-19	Power transistor	B-28	Injector No. 4
B-20	Starter motor	B-29	Injector No. 6
B-21		B-30	Speed sensor
B-22		B-31	Idle speed control servo (stepper motor)
B-23	Back-up lamp switch	B-32	Engine oil level sensor
B-24	Fuel pump relay	B-33	Oil pressure gauge unit
B-25	Air flow sensor (with intake air temperature sensor and atmospheric sensor)	B-34	Oil pressure switch
B-26	Control wiring harness and battery cable combination	B-35	Power steering oil pressure switch
B-27	Injector No. 2	B-36	Cam position sensor
		B-37	Crank angle sensor

## DASH PANEL


L.H. drive vehicles

**JUNCTION BLOCK**  
(Front side)



## (Rear side)




- |       |  |      |  |
|-------|--|------|--|
| C-01  | Body wiring harness (main) and front wiring harness combination            | C-18 | Power transistor (for A/C circuit)                                   |
| C-02  |  | C-19 | Air-inlet sensor   |
| C-03  |  | C-20 | Air selection damper control motor                                   |
| C-04X | Door lock power relay  | C-21 | Body wiring harness (main) and control wiring harness combination    |
| C-05X | Rear fog lamp relay  | C-22 | Body wiring harness (main) and front wiring harness combination      |
| C-06X | Defogger relay   | C-23 | Body wiring harness (sub) and front wiring harness combination       |
| C-07X | Power window relay   | C-24 | Body wiring harness (sub) and front wiring harness combination       |
| C-08  | —  | C-25 | Body wiring harness (main) and body wiring harness (sub) combination |
| C-09  | Column switch  | C-26 | Body wiring harness (main) and body wiring harness (sub) combination |
| C-10  | —  | C-27 | Body wiring harness (main) and body wiring harness (sub) combination |
| C-11  |  | C-28 | Foot lamp (RH)   |
| C-12  | Control wiring harness and instrument panel wiring harness combination     | C-29 | Body wiring harness (sub) and control wiring harness combination     |
| C-13  | Body wiring harness (main) and instrument panel wiring harness combination | C-30 | Auto-cruise control unit   |
| C-14  | Blend air damper control motor   | C-31 | Blower motor   |
| C-15  | Mode selection damper control motor  | C-32 | Blower motor relay (HI)  |
| C-16  | A/C control panel  | C-33 | A/C compressor lock controller                                       |
| C-17  |  | C-34 | Air-thermo sensor  |
- Refer to CENTRALIZED JUNCTION




- |      |                                   |      |  |
|------|-----------------------------------|------|--|
| C-35 | Engine coolant temperature sensor | C-58 | —  |
| C-36 | Engine control relay              | C-64 |  |
| C-37 |                                   | C-65 |  |
| C-38 | A/C control unit                  | C-66 | Front wiring harness and junction block combination                    |
| C-39 |                                   | C-67 |  |
| C-40 | Lighting monitor buzzer           | C-68 | Instrument panel adapter wiring harness and junction block combination |
| C-41 | Headlamp washer relay             | C-69 | Theft-alarm horn relay   |
| C-42 | Engine oil level relay            | C-70 | Diagnosis connector  |
| C-43 |                                   | C-71 | Blower motor relay   |
| C-44 | Engine control unit               | C-72 | Roof wiring harness and junction block combination                     |
| C-45 |                                   | C-73 | Body wiring harness (main) and junction block combination              |
| C-46 | Auto-cruise control relay         | C-74 |  |
| C-47 | Steering wheel angle speed sensor | C-75 |  |
| C-48 | Clock spring                      | C-76 |  |
| C-49 | No connection                     | C-77 |  |
| C-50 | Stop lamp switch                  | C-78 |  |
| C-51 | Key reminder switch               | C-79 |  |
| C-52 | Ignition switch                   | C-80 |  |
| C-53 | Clutch pedal switch               | C-81 |  |
| C-54 |                                   | C-82 |  |
| C-55 | ETACS control unit                | C-83 | No connection  |
| C-56 | Foot lamp (LH)                    | C-84 | —  |
| C-57 | Diode (for headlamp circuit)      | C-85 | Air bag module (Passenger's side)                                      |
|      |                                   | C-86 | Front wiring harness and control wiring harness combination            |
|      |                                   | C-87 | Body wiring harness (main) and body wiring harness (sub) combination   |
|      |                                   | C-88 | No connection  |

**DASH PANEL****R.H. drive vehicles**


- |       |  |      |   |
|-------|--|------|---|
| C-01  | Body wiring harness (main) and front wiring harness combination            | C-19 | Air-inlet sensor  |
| C-02  | —  | C-20 | Air selection damper control motor                                |
| C-03  | Body wiring harness (main) and front wiring harness combination            | C-21 | Body wiring harness (main) and control wiring harness combination |
| C-04X | Door lock power relay  | C-22 | —   |
| C-05X | Rear fog lamp relay  | C-23 | Body wiring harness (main) and front wiring harness combination   |
| C-06X | Defogger relay   | C-24 | —   |
| C-07X | Power window relay   | C-25 | —   |
| C-08  | —  | C-26 | —   |
| C-09  | Column switch  | C-27 | —   |
| C-10  | —  | C-28 | Foot lamp (RH)  |
| C-11  | —  | C-29 | —   |
| C-12  | Control wiring harness and instrument panel wiring harness combination     | C-30 | Auto-cruise control unit  |
| C-13  | Body wiring harness (main) and instrument panel wiring harness combination | C-31 | Blower motor  |
| C-14  | Blend air damper control motor   | C-32 | Blower motor relay (HI)   |
| C-15  | Mode selection damper control motor  | C-33 | A/C compressor lock controller                                    |
| C-16  | A/C control panel  | C-34 | Air-thermo sensor   |
| C-17  | —  | C-35 | Engine coolant temperature sensor                                 |
| C-18  | Power transistor (for A/C circuit)   | C-36 | Engine control relay  |
|       |  | C-37 | A/C control unit  |
|       |  | C-38 | —   |
|       |  | C-39 | —   |
- Refer to CENTRALIZED JUNCTION



**JUNCTION BLOCK  
(Front side)**





**(Rear side)**



- |      |  |      |  |
|------|--|------|--|
| C-40 | Lighting monitor buzzer  | C-64 | Body wiring harness (sub) and front wiring harness combination         |
| C-41 | Headlamp washer relay  | C-65 | Front wiring harness and junction block combination                    |
| C-42 | Engine oil level relay   | C-66 | Instrument panel adapter wiring harness and junction block combination |
| C-43 |  | C-67 | Theft-alarm horn relay   |
| C-44 | Engine control unit  | C-68 | Diagnosis connector  |
| C-45 |  | C-69 | Blower motor relay   |
| C-46 | Auto-cruise control relay  | C-70 | Roof wiring harness and junction block combination                     |
| C-47 | Steering wheel angle speed sensor                                    | C-71 | Body wiring harness (main) and junction block combination              |
| C-48 | Clock spring   | C-72 |  |
| C-49 | —  | C-73 | Air bag module (Passenger's side)                                      |
| C-50 | Stop lamp switch   | thru | Front wiring harness and control wiring harness combination            |
| C-51 | Key reminder switch  | C-79 | Body wiring harness (main) and body wiring harness (sub) combination   |
| C-52 | Ignition switch  | C-80 | No connection  |
| C-53 | Clutch pedal switch  | thru |  |
| C-54 | ETACS control unit   | C-84 |  |
| C-55 |  | C-85 |  |
| C-56 | Foot lamp (LH)   | C-86 |  |
| C-57 | —  | C-87 |  |
| C-58 |  | C-88 |  |
| C-59 | Body wiring harness (main) and front wiring harness combination      |      |  |
| C-60 | Body wiring harness (main) and control wiring harness combination    |      |  |
| C-61 | Body wiring harness (main) and body wiring harness (sub) combination |      |  |
| C-62 |  |      |  |
| C-63 |  |      |  |



## INSTRUMENT PANEL AND FLOOR CONSOLE

L.H. drive vehicles



- D-01 Rear fog lamp switch
- D-02 Front speaker (LH)
- D-03
- D-04 Combination meter
- D-05
- D-06 Defogger switch and ECS switch
- D-07 Hazard switch
- D-08 Clock
- D-09 Combination gauge
- D-10 Diode (for 4WS fluid level warning lamp circuit)
- D-11 Glove box lamp
- D-12 Photo sensor
- D-13 Front speaker (RH)
- D-14 Glove box lamp switch

- D-15 Instrument panel wiring harness and control wiring harness combination
- D-16 Instrument panel wiring harness and body wiring harness (sub) combination
- D-17 Ashtray illumination lamp
- D-18 Cigarette lighter
- D-19
- D-20 Cigarette lighter illumination lamp
- D-21 Power seat switch
- D-22 Body wiring harness (main) and console wiring harness combination
- D-23 SRS diagnosis unit
- D-24
- D-25 —
- D-26 SRS diagnosis unit





36F0141

D-27	ABS G sensor	D-40	Remote controlled mirror switch
D-28	Parking brake switch	D-41	Rheostat
D-29	Active aero switch	D-42	Instrument panel wiring harness and body wiring
D-30	Accessory socket	D-43	harness (main) combination
D-31		D-44	
D-32	Auto-cruise main switch	D-45	Instrument panel wiring harness and instrument panel
D-33	—	D-46	adapter wiring harness combination
D-34	—	D-47	Instrument panel wiring harness and front wiring
D-35	Radio and tape player	D-48	harness combination
D-36		D-49	
D-37	Rear wiper and washer switch	D-50	No connection
D-38	Headlamp leveling switch		
D-39	No connection		


## INSTRUMENT PANEL AND FLOOR CONSOLE

R.H. drive vehicles



- |      |  |
|------|--|
| D-01 | Rear fog lamp switch                             |
| D-02 | Front speaker (LH)                               |
| D-03 |  |
| D-04 | Combination meter                                |
| D-05 |  |
| D-06 | Defogger switch and ECS switch                   |
| D-07 | Hazard switch                                    |
| D-08 | Clock  |
| D-09 | Combination gauge                                |
| D-10 | Diode (for 4WS fluid level warning lamp circuit) |
| D-11 | Glove box lamp                                   |
| D-12 | Photo sensor                                     |
| D-13 | Front speaker (RH)                               |
| D-14 | Glove box lamp switch                            |


- |      |   |
|------|---|
| D-15 | Instrument panel wiring harness and control wiring harness combination    |
| D-16 | Instrument panel wiring harness and body wiring harness (sub) combination |
| D-17 | Ashtray illumination lamp   |
| D-18 |   |
| D-19 | Cigarette lighter   |
| D-20 | Cigarette lighter illumination lamp                                       |
| D-21 | Power seat switch   |
| D-22 | Body wiring harness (main) and console wiring harness combination         |
| D-23 |   |
| D-24 | SRS diagnosis unit  |
| D-25 | —   |
| D-26 | SRS diagnosis unit  |




36F0142

- D-27 ABS G sensor
- D-28 Parking brake switch
- D-29 Active aero switch
- D-30 } —
- D-31 } —
- D-32 Auto-cruise main switch
- D-33 —
- D-34 —
- D-35 } Radio and tape player
- D-36 } —
- D-37 Rear wiper and washer switch
- D-38 Headlamp leveling switch
- D-39 No connection

- D-40 Remote controlled mirror switch
- D-41 Rheostat
- D-42 } Instrument panel wiring harness and body wiring harness (main) combination
- D-43 }
- D-44 }
- D-45 Instrument panel wiring harness and instrument panel adapter wiring harness combination
- D-46 Instrument panel wiring harness and front wiring harness combination
- D-47 —
- D-48 }
- D-49 —
- D-50 No connection

**INTERIOR****L.H. drive vehicles**

E-01	Body wiring harness (main) and door wiring harness (RH) combination	E-09	Door lock actuator (Passenger's side)
E-02	Door mirror (Passenger's side)	E-10	ABS control unit
E-03	Door speaker (Passenger's side)	E-11	ABS resistor
E-04	Room lamp	E-12	Door switch (Passenger's side)
E-05	Power window sub switch	E-13	ABS rear speed sensor (RH)
E-06	Power window motor (Passenger's side)	E-14	Rear intermittent wiper relay
E-07	Door lamp (Passenger's side)	E-15	ABS rear speed sensor (LH)
E-08	Door key cylinder unlock switch (Passenger's side)	E-16	Door switch (Driver's side)
		E-17	Door lock actuator (Driver's side)




36F0147


E-18	Door key cylinder unlock switch (Driver's side) <Vehicles with theft-alarm system>	E-27	Door mirror (Driver's side)
E-19	Door lamp (Driver's side)	E-28	Power window main switch
E-20	Power seat assembly	E-29	Power window motor (Driver's side)
E-21	ECS G sensor	E-30	—
E-22	Door speaker (Driver's side)	E-31	No connection
E-23	Turn signal and hazard flasher unit	E-32	
E-24	Diode (for MPI circuit)	E-33	
E-25	Jumper connector	E-34	
E-26	Body wiring harness (main) and door wiring harness (LH) combination	E-35	
		E-36	—
		E-37	No connection
		E-38	

## **INTERIOR**

## **R.H. drive vehicles**





- |      |  |      |                                       |
|------|--|------|---------------------------------------|
| E-01 | Body wiring harness (main) and door wiring harness<br>(LH) combination | E-09 | Door lock actuator (Passenger's side) |
| E-02 | Door mirror (Passenger's side)   | E-10 | ABS control unit                      |
| E-03 | Door speaker (Passenger's side)  | E-11 | ABS resistor                          |
| E-04 | Room lamp  | E-12 | Door switch (Passenger's side)        |
| E-05 | Power window sub switch  | E-13 | ABS rear speed sensor (RH)            |
| E-06 | Power window motor (Passenger's side)                                  | E-14 | Rear intermittent wiper relay         |
| E-07 | Door lamp (Passenger's side)   | E-15 | ABS rear speed sensor (LH)            |
| E-08 | Door key cylinder unlock switch (Passenger's side)                     | E-16 | Door switch (Driver's side)           |



- E-17 Door lock actuator (Driver's side)
- E-18 Door key cylinder unlock switch (Driver's side)  
〈Vehicles with theft-alarm system〉
- E-19 Door lamp (Driver's side)
- E-20 Power seat assembly
- E-21 ECS G sensor
- E-22 Door speaker (Driver's side)
- E-23 Turn signal and hazard flasher unit
- E-24 Diode (for MPI circuit)
- E-25 —

- E-26 Body wiring harness (main) and door wiring harness (RH) combination
- E-27 Door mirror (Driver's side)
- E-28 Power window main switch
- E-29 Power window motor (Driver's side)
- E-30 No connection
- E-31 } thru E-36 } —
- E-37 } E-38 } No connection

## LUGGAGE COMPARTMENT



36F0093

- |                    |   |  |
|--------------------|---|--|
| F-01               | Interior temperature sensor   | F-18 } Body wiring harness (main) and body wiring harness (sub) combination  |
| F-02               | Defogger (+)  | F-19 } Licence plate lamp (LH)   |
| F-03               | Rear wiper motor  | F-20 Luggage compartment lamp switch   |
| F-04               | Active aero rear spoiler  | F-21 Tailgate cylinder lock switch <Vehicles with theft-alarm system>  |
| F-05               | Defogger (-)  | F-22 Tailgate switch <Vehicles with theft-alarm system>  |
| F-06               | Rear speaker (RH)   | F-23 Buck-up lamp (LH)   |
| F-07               | Body wiring harness (sub) <LHD> or (main) <RHD> and ECS rear shock absorber joint wiring harness (RH) combination | F-24 Active aero control unit  |
| F-08               | Luggage compartment lamp  | F-25 } Rear combination lamp (LH)  |
| F-09               | Rear combination lamp (RH)  | F-26 Motor antenna control unit  |
| F-10               | Back-up lamp (RH)   | F-27 Body wiring harness (main) <LHD> or (sub) <RHD> and ECS rear shock absorber joint wiring harness (LH) combination |
| F-11 } F-12 } F-13 | ECS control unit  | F-28 Rear speaker (LH)   |
| F-14               | Body wiring harness (sub) <LHD> or (main) <RHD> and fuel tank wiring harness combination                          | F-29 Body wiring harness (main) <LHD> or (sub) <RHD> and tailgate wiring harness combination                           |
| F-15               | Rear washer motor   | F-30 Fuel tank   |
| F-16               | Fuel tank   | F-31 } ECS rear shock absorber (RH)  |
| F-17               | Licence plate lamp (RH)   | F-32 } ECS rear shock absorber (LH)  |
|                    | Body wiring harness (sub) <LHD> or (main) <RHD> and rear bumper wiring harness combination                        | F-33   |
|                    |   | F-34   |

### **3 SINGLE PART INSTALLATION POSITION**

<b>RELAY .....</b>	<b>3-2</b>
<b>CONTROL UNIT .....</b>	<b>3-5</b>
<b>SENSOR .....</b>	<b>3-7</b>
<b>SOLENOID VALVE .....</b>	<b>3-11</b>
<b>DIODE .....</b>	<b>3-12</b>
<b>INSPECTION TERMINAL .....</b>	<b>3-14</b>
<b>FUSIBLE LINK AND FUSE .....</b>	<b>3-15</b>
<b>EARTH CABLE .....</b>	<b>3-16</b>
<b>EARTH .....</b>	<b>3-17</b>

**RELAY**

Name	Symbol	Name	Symbol
ABS power relay	A	Headlamp relay	A
Alternator relay	A	Headlamp washer relay	H
Auto-cruise control relay	K	Horn relay	A
Blower motor relay	L	Magnetic clutch relay	E
Blower motor relay (HI)	I	Motor relay (ABS hydraulic unit)	B
Condenser fan motor relay (HI)	E	Pop-up motor relay	A
Condenser fan motor relay (LO)	E	Pop-up relay *1 *2	H
Daytime running lamp relay 1 *1	F	Power window relay	G
Daytime running lamp relay 2 *1	F	Radiator fan motor control relay	E
Defogger relay	G	Radiator fan motor relay (HI)	A
Dim-dip lamp relay 1 *2	C	Radiator fan motor relay (LO)	A
Dim-dip lamp relay 2 *2	C	Rear fog lamp relay	G
Dim-dip lamp relay 3 *2	C	Rear intermittent wiper relay	N
Door lock relay	G	Starter relay *3	A
Driving lamp relay	A	Tail lamp relay	A
Engine control relay	J	Theft-alarm horn relay *3	L
Engine oil level relay	H	Turn-signal and hazard flasher unit	M
Fuel pump relay	D	Valve relay (ABS hydraulic unit)	B


## NOTE

(1) \*1: L.H. drive vehicles with daytime running lamp.



(2) \*2: R.H. drive vehicles with dim-dip lamp.

(3) \*3: Vehicles with theft-alarm system.





(4) Names are listed in alphabetical order.

**Engine compartment**


16F0257



16F0008






## Instrument panel








19F0134



### NOTE

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.





### Quarter panel





## CONTROL UNIT

Name	Symbol	Name	Symbol
ABS control unit	I	Electronic control suspension control unit	H
Active aero control unit	G	Engine control unit	C
Air conditioner compressor lock controller	D	ETACS control unit	B
Air conditioner control unit	C	Motor antenna control unit	F
Auto-cruise control unit	D	SRS diagnosis unit	E
Daytime running lamp control unit *	A		



### NOTE

- (1) \*: L.H. drive vehicles with daytime running lamp.  
(2) Names are listed in alphabetical order.


### Engine compartment





### Instrument panel









**NOTE**  
For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.





### Quarter panel, luggage compartment







## SENSOR









Name	Symbol	Name	Symbol
ABS speed sensor (front)	U	Front impact sensor	T
ABS speed sensor (rear)	V	G sensor (for ABS)	Q
Air-flow sensor (with built-in barometric pressure sensor, intake air temperature sensor)	B	G sensor (for electronic control suspension)	R
		Interior temperature sensor	S
		Oxygen sensor	G
Air inlet sensor (for A/C)	O	Photo sensor	P
Air thermo sensor (for A/C)	N	Power steering oil pressure switch	F
Cam position sensor	H	Revolution pick-up sensor	I
Crank angle sensor	H	Steering wheel angle speed sensor	L
Detonation sensor	E	Thermo sensor	K
Engine coolant temperature sensor (for engine control)	A	Thermostat	H
Engine coolant temperature sensor (for A/C)	M	Throttle position sensor	D
Engine coolant temperature switch (for A/C)	A	Vehicle speed sensor	C
Engine oil level sensor	J		

**NOTE**


Names are listed in alphabetical order.

### Engine compartment






## Instrument panel




19F0134

## NOTE


For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.




12F0072




20F0065




16F0056






16F0047





16F0283





16F0051

**Roof****Front under floor**

16F0040



## Rear under floor




## SOLENOID VALVE

Name	Symbol	Name	Symbol
EGR control solenoid valve	C	Purge control solenoid valve	B
Fuel pressure solenoid valve	A	Waste gate solenoid valve	D





## NOTE

The "Name" column is arranged in alphabetical order.

## &lt;Engine compartment&gt;



16F0257






**DIODE**


Name	Symbol	Name	Symbol
Diode (ABS circuit)	A	Diode (Pop-up circuit) <R.H. drive vehicles>	D
Diode (Daytime running lamp circuit)	D	Diode (Theft-alarm circuit)	D
Diode (Dim-dip lamp circuit)	B	Diode (4WS fluid level warning lamp circuit)	E
Diode (MPI circuit)	C		

**NOTE**

Names are listed in alphabetical order.

**Engine compartment**





## Instrument panel



19F0134

## NOTE

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.




## INSPECTION TERMINAL

Name	Symbol	Name	Symbol
Diagnosis connector	B	Fuel pump check connector	A
Engine speed detection connector	A	Ignition timing adjustment connector	A


**NOTE**

Names are listed in alphabetical order.

### Engine compartment




16F0257




16F0060

### Instrument panel



19F0134



16F0246

**NOTE**







For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.

**FUSIBLE LINK AND FUSE**


Name	Symbol	Name	Symbol
Dedicated fuse ① to ⑦	B	Fusible link	A
Dedicated fuse ⑧ ⑨	C	Multi-purpose fuse	D
Dedicated fuse ⑩	E	—	—

**NOTE**

Names are listed in alphabetical order.



**Engine compartment****Instrument panel****NOTE**

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.





## EARTH CABLE

### Engine compartment




### Front under floor





**EARTH**

&lt;L.H. drive vehicles&gt;




&lt;R.H. drive vehicles&gt;

















## &lt;Vehicles without dim-dip lamp&gt;



## &lt;Vehicles with dim-dip lamp&gt;





---

**NOTES**

## **3B SINGLE PART INSTALLATION POSITION**

<b>RELAY .....</b>	<b>3B-2</b>
<b>CONTROL UNIT .....</b>	<b>3B-5</b>
<b>SENSOR .....</b>	<b>3B-7</b>
<b>SOLENOID VALVE .....</b>	<b>3B-11</b>
<b>DIODE .....</b>	<b>3B-12</b>
<b>INSPECTION CONNECTOR .....</b>	<b>3B-13</b>
<b>FUSIBLE LINK AND FUSE .....</b>	<b>3B-14</b>
<b>EARTH CABLE .....</b>	<b>3B-15</b>
<b>EARTH .....</b>	<b>3B-16</b>

**RELAY**




Name	Symbol	Name	Symbol
ABS motor relay	B	Engine oil level relay	H
ABS valve relay	B	Fuel pump relay	D
Alternator relay	A	Headlamp relay	A
Auto-cruise control relay	K	Headlamp washer relay	H
Blower motor relay	L	Horn relay	A
Blower motor relay (HI)	I	Magnetic clutch relay	E
Condenser fan motor relay (HI)	E	Power window relay	G
Condenser fan motor relay (LO)	E	Radiator fan motor relay (HI)	A
Daytime running lamp relay *1	F	Radiator fan motor relay (LO)	A
Defogger relay	G	Rear fog lamp relay	G
Dim-dip lamp relay 1 *2	C	Rear intermittent wiper relay	N
Dim-dip lamp relay 2 *2	C	Starter relay *3	A
Dim-dip lamp relay 3 *2	C	Tail lamp relay	A
Door lock power relay	G	Theft-alarm horn relay *3	L
Engine control relay	J	Turn-signal and hazard flasher unit	M





## NOTE

(1) \*1: L.H. drive vehicles with daytime running lamp.



(2) \*2: R.H. drive vehicles with dim-dip lamp.

(3) \*3: Vehicles with theft-alarm system.

**Engine compartment**










## Instrument panel





### NOTE

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.





## Quarter panel





## CONTROL UNIT

Name	Symbol	Name	Symbol
ABS control unit	I	ECS control unit	H
Active aero control unit	G	Engine control unit	C
A/C compressor lock controller	D	ETACS control unit	B
A/C control unit	C	Motor antenna control unit	F
Auto-cruise control unit	D	SRS diagnosis unit	E
Daytime running lamp control unit *	A		



## NOTE

\*: L.H. drive vehicles with daytime running lamp.

### Engine compartment






### Instrument panel









## NOTE

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.
















### Quarter panel, luggage compartment




**SENSOR**

Name	Symbol	Name	Symbol
ABS front speed sensor	T	Engine coolant temperature sensor (for A/C)	L
ABS G sensor	P	Engine oil level sensor	J
ABS rear speed sensor	U	Interior temperature sensor	R
Air-flow sensor (with built-in barometric pressure sensor, intake air temperature sensor)	B	Oxygen sensor	G
		Photo sensor	O
Air inlet sensor (for A/C)	N	Power steering oil pressure switch	F
Air thermo sensor (for A/C)	M	Revolution pick-up sensor	I
Cam position sensor	H	Speed sensor	C
Crank angle sensor	H	SRS front impact sensor	S
Detonation sensor	E	Steering wheel angle speed sensor	K
ECS G sensor	Q	Thermostat	I
Engine coolant temperature sensor (for engine control)	A	Throttle position sensor	D


**Engine compartment**




**Instrument panel****NOTE**

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.


19F0134




12F0072




20F0065




16F0056




16F0047




16F0283




16F0051




16F0050

**Roof**


16F0524




16F0045

**Front under floor**


16F0536




16F0064



14N0177

**Rear under floor**

16F0535




14N0100





## SOLENOID VALVE

Name	Symbol	Name	Symbol
EGR control solenoid valve	B	Purge control solenoid valve	C
Fuel pressure solenoid valve	A	Waste gate solenoid valve	D

### Engine compartment







16F0502






**DIODE**

Name	Symbol	Name	Symbol
Diode (for ABS circuit)	A	Diode (for MPI circuit)	E
Diode (for headlamp circuit)	B, C	Diode (for 4WS fluid level warning lamp circuit)	D

**Engine compartment****Instrument panel****NOTE**

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.









## INSPECTION CONNECTOR

Name	Symbol	Name	Symbol
Diagnosis connector	B	Fuel pump check connector	A
Engine speed detection connector	A	Ignition timing adjustment connector	A

### Engine compartment



### Instrument panel



#### NOTE





For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.

## 3B-14 SINGLE PART INSTALLATION POSITION — Fusible Link and Fuse



### FUSIBLE LINK AND FUSE

Name	Symbol	Name	Symbol
Dedicated fuse ① thru ⑦	B	Fusible link	A
Dedicated fuse ⑧, ⑨	C	Multi-purpose fuse	
Dedicated fuse ⑩	E		D

#### Engine compartment




#### Instrument panel





#### NOTE

For R.H. drive vehicles, only the positions indicated by the \* are symmetrical.





## EARTH CABLE

### Engine compartment




### Front under floor












**EARTH**







&lt;L.H. drive vehicles&gt;



&lt;R.H. drive vehicles&gt;







## 4 CIRCUIT DIAGRAM

<b>JUNCTION BLOCK .....</b>	<b>4-4</b>
<b>CENTRALIZED JUNCTION .....</b>	<b>4-6</b>
<b>POWER DISTRIBUTION SYSTEM</b>	
L.H.drive vehicles .....	4-12
R.H.drive vehicles .....	4-17
<b>STARTING SYSTEM</b>	
Vehicles without theft-alarm system ....	4-22
L.H.drive vehicles with theft-alarm system .....	4-23
R.H.drive vehicles with theft-alarm system .....	4-24
<b>IGNITION SYSTEM .....</b>	<b>4-26</b>
<b>CHARGING SYSTEM .....</b>	
<b>MPI SYSTEM</b>	
L.H.drive vehicles .....	4-30
R.H.drive vehicles .....	4-36
<b>COOLING SYSTEM .....</b>	<b>4-42</b>
<b>HEADLAMP</b>	
L.H.drive vehicles without daytime running lamp .....	4-45
R.H.drive vehicles without dim-dip lamp .....	4-50
L.H.drive vehicles with daytime running lamp .....	4-58
R.H.drive vehicles with dim-dip lamp ....	4-66
Headlamp leveling system .....	4-74
<b>TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP</b>	
L.H.drive vehicles .....	4-76
R.H.drive vehicles .....	4-78
<b>REAR FOG LAMP</b>	
L.H. drive vehicles without daytime running lamp .....	4-82
L.H. drive vehicles with daytime running lamp .....	4-84
R.H.drive vehicles .....	4-86
<b>GLOVE BOX LAMP AND INSPECTION LAMP .....</b>	
<b>4-89</b>	
<b>ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP .....</b>	
<b>4-90</b>	
<b>DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR WARNING LAMP</b>	
L.H.drive vehicles .....	4-94
R.H.drive vehicles .....	4-96
<b>TURN-SIGNAL LAMP AND HAZARD LAMP</b>	
L.H.drive vehicles .....	4-98
R.H.drive vehicles .....	4-100
<b>STOP LAMP</b>	
L.H.drive vehicles .....	4-103
R.H.drive vehicles .....	4-104
<b>BACK-UP LAMP</b>	
L.H.drive vehicles .....	4-105
R.H.drive vehicles .....	4-105
<b>HORN</b>	
Vehicles without theft-alarm system ....	4-107
Vehicles with theft-alarm system ....	4-108
<b>METER AND GAUGE .....</b>	
<b>4-110</b>	
<b>4WS FLUID LEVEL WARNING LAMP ...</b>	
<b>4-112</b>	
<b>BRAKE WARNING LAMP .....</b>	
<b>4-113</b>	
<b>OIL PRESSURE WARNING LAMP .....</b>	
<b>4-113</b>	
<b>LOW FUEL WARNING LAMP .....</b>	
<b>4-114</b>	
<b>LOW ENGINE OIL LEVEL WARNING LAMP .....</b>	
<b>4-114</b>	
<b>POWER WINDOW .....</b>	
<b>4-116</b>	
<b>CENTRAL DOOR LOCKING SYSTEM ...</b>	
<b>4-118</b>	
<b>AIR CONDITIONER</b>	
L.H.drive vehicles .....	4-122
R.H.drive vehicles .....	4-130
<b>WINDSHIELD WIPER AND WASHER ....</b>	
<b>4-138</b>	
<b>REAR WIPER AND WASHER</b>	
L.H.drive vehicles .....	4-141
R.H.drive vehicles .....	4-142
<b>HEADLAMP WASHER .....</b>	
<b>4-144</b>	
<b>REMOTE CONTROLLED MIRROR</b>	
L.H.drive vehicles .....	4-146
R.H.drive vehicles .....	4-147
<b>DEFOGGER .....</b>	
<b>4-148</b>	
<b>RADIO AND TAPE PLAYER</b>	
L.H.drive vehicles .....	4-152
R.H.drive vehicles .....	4-154
<b>CLOCK .....</b>	
<b>4-156</b>	
<b>CIGARETTE LIGHTER .....</b>	
<b>4-157</b>	
<b>ANTI-LOCK BRAKE SYSTEM</b>	
L.H.drive vehicles .....	4-158
R.H.drive vehicles .....	4-161
<b>ELECTRONIC CONTROL SUSPENTION SYSTEM</b>	
L.H.drive vehicles .....	4-164
R.H.drive vehicles .....	4-169
<b>ACTIVE AERO SYSTEM</b>	
L.H.drive vehicles without theft-alarm system .....	4-174
L.H.drive vehicles with theft-alarm system .....	4-177
R.H.drive vehicles without theft-alarm system .....	4-180
R.H.drive vehicles with theft-alarm system .....	4-183

**SUPPLEMENTAL RESTRAINT SYSTEM**

- |                          |       |
|--------------------------|-------|
| L.H.drive vehicles ..... | 4-186 |
| R.H.drive vehicles ..... | 4-188 |

**AUTO-CRUISE CONTROL SYSTEM**

- |                          |       |
|--------------------------|-------|
| L.H.drive vehicles ..... | 4-191 |
| R.H.drive vehicles ..... | 4-195 |

**POWER SEAT**

- |                          |       |
|--------------------------|-------|
| L.H.drive vehicles ..... | 4-200 |
| R.H.drive vehicles ..... | 4-202 |


**THEFT-ALARM SYSTEM**

- |                          |       |
|--------------------------|-------|
| L.H.drive vehicles ..... | 4-204 |
| R.H.drive vehicles ..... | 4-208 |

---



**NOTES**

## JUNCTION BLOCK



## Remark

- Connector numbers are keyed to the configuration diagram (dash panel) and each circuit diagram.


**Front****Back**

16F0432

16F0058

**CENTRALIZED JUNCTION****FUSIBLE LINK (Relay box in engine compartment)**


No.	Circuit	Housing colour	Rated capacity (A)
1	Alternator circuit, Fusible link No.⑥, ⑦, ⑨, ⑩, ⑪, Dedicated fuse ⑦	Wine red	120
2	Pop-up motor circuit	Pink	30
3	Lighting circuit	Green	40
4	Ignition switch circuit	Pink	30
5	Radiator fan motor and condenser fan motor circuit	Green	40
6	Junction block (Multipurpose fuse ⑥, ⑬, ⑭, ⑯, ⑰, ⑲), Dedicated fuse ④	Green	40
7	ABS circuit	Yellow	60
8	—	—	—
9	Power window circuit, Power seat circuit	Pink	30
10	Defogger circuit	Green	40
11	Active aero circuit	Pink	30



16F0434


## DEDICATED FUSE

Power supply circuit	No.	Rated capacity (A)	Housing colour	Circuit
Battery	1	20	Yellow	MPI circuit
Tail lamp relay	2	10	Red	Tail lamp circuit, Lighting monitor buzzer circuit <LHD>
	3	10	Red	Tail lamp circuit, Lighting monitor buzzer circuit <RHD>
Fusible link ⑥	4	10	Red	Horn circuit
Headlamp relay	5	10	Red	Upper beam circuit, Headlamp leveling circuit, Headlamp washer circuit, Rear fog lamp circuit
Battery	6	10	Red	Hazard lamp circuit
	7	10	Red	ABS circuit
Fusible link ⑤	8	20	Yellow	Condenser fan motor circuit
	9	10	Red	Air conditioner circuit
Defogger relay	10	10	Red	Remote controlled mirror heater circuit




NOTE  
 (1) \*1: L.H.drive vehicles.  
 (2) \*2: R.H.drive vehicles.

16F0434

**<Air conditioner relay box in engine compartment>**

16F0002

**<Interior relay box>**


16F0431

**MULTI-PURPOSE FUSE (In junction block)**

Power supply circuit		No.	Rated capacity (A)	Load circuit	
—	—	1	—	—	
—	—	2	—	—	
Ignition switch	IG <sub>2</sub>	3	10	ABS power relay, Air conditioner compressor lock controller, Air conditioner control unit, Blower motor relay, Condenser fan motor relay (HI), Daytime running lamp control unit, Daytime running lamp relay 2, Defogger relay, Dim-dip lamp relay 1, Electronic control suspension control unit, Headlamp washer relay, Power windows relay, Radiator fan motor relay	
	ACC	4	10	Audio, Auto-cruise control unit, Motor antenna control unit, Clock	
		5	15	Cigarette lighter, Remote controlled mirror	
Battery		6	10	Door lock power relay, Motor antenna control unit, Headlamp pop-up switch	
—	—	7	—	—	
—	—	8	—	—	
Ignition switch	ACC	9	15	Rear intermittent wiper relay, Washer motor, Wiper motor, Wiper relay	
		10	15	Accessory socket*, ETACS control unit	
	IG <sub>1</sub>	11	15	Active aero control unit, Auto-cruise control main switch, Auto-cruise control relay, Combination gauge, Combination meter, Engine oil level relay, ETACS control unit, Lighting monitor buzzer, Motor antenna control unit, Pop-up relay, Speed sensor, SRS diagnosis unit, Turn signal and hazard flasher unit, 4WS fluid level sensor	
		12	15	Capacitor, Engine control relay, Engine control unit, Ignition coil, Power transistor	
Battery		13	10	Rear fog lamp	
		14	10	Theft-alarm horn, Theft-alarm horn relay	
—	—	15	—	—	
Battery		16	30	Blower motor	
		17	15	Stop lamp	
Ignition switch	IG <sub>1</sub>	18	10	Back-up lamp, SRS diagnosis unit	
Battery		19	10	Active aero control unit, Air conditioner control unit, Auto-cruise control unit, Clock, Combination meter, Door lamp, Electronic control suspension control unit, Engine control unit, ETACS control unit, Foot lamp, Ignition key cylinder illumination lamp, Key reminder switch, Luggage compartment lamp, Radio and Tape player, Room lamp	

NOTE

\*: L.H.drive vehicles.




**CENTRALIZED RELAY**


Classification	Name	Classification	Name
Relay box in engine compartment	A-01X	Air condi- tioner relay box in engine compartment	A-44X Condenser fan motor relay (HI)
	A-02X		A-45X Radiator fan motor control relay
	A-03X		A-46X Magnetic clutch relay
	A-04X		A-47X Condenser fan motor relay (LO)
	A-05X		C-04X Door lock power relay
	A-06X		C-05X Rear fog lamp relay
	A-07X		C-06X Defogger relay
	A-08X		C-07X Power windows relay
	A-09X		—
	A-10X		—
	A-11X		—

NOTE


\*: Vehicles with theft-alarm system.

**<Relay box in engine compartment>**

16F0434

**<Air conditioner relay box  
in engine compartment>**

16F0002


**<Interior relay box>**

16F0431

---

**NOTES**

**POWER DISTRIBUTION SYSTEM**  
**(L.H. drive vehicles)**




Wire colour code


B:Black    LG:Light green    G:Green  
BR:Brown    O:Orange    GR:Gray


L:Blue    W:White    Y:Yellow


R:Red    P:Pink    V:Violet

SB:Sky blue









Wire colour code

B:Black

LG:Light green

G:Green

I:Blue

R:Red

W:White

P:Pink


V:Yellow

V:Violet

SB:Sky blue


# POWER DISTRIBUTION SYSTEM


< R.H. drive vehicles >





Wire colour code  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

## FUSIBLE LINK










## STARTING SYSTEM

<Vehicles without theft-alarm system>



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink


Y:Yellow

V:Violet

BB:Sky blue


# STARTING SYSTEM

(L.H. drive vehicles with theft-alarm system)



# STARTING SYSTEM

(R. H. drive vehicles with theft-alarm system)



## STARTING SYSTEM (See P. 4-23, 24.)

### OPERATION

- When the ignition switch is switched to the "ST" position, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.

## IGNITION SYSTEM (See P. 4-26.)

### OPERATION

- Turn ignition switch to "ON" position, and battery voltage will be applied to primary winding of ignition coil.
- When crank angle sensor signal is input to engine control unit, engine control unit makes ON-OFF control of power transistors one by one.
- When power transistor A is turned from ON to OFF, the spark plugs of No.1 and No.4 cylinders spark. Turning of power transistor B from ON to OFF will produce sparking in spark plugs of No.2 and No.5 cylinders. Furthermore, when power transistor C is turned from ON to OFF, sparking is produced in spark plugs of No.3 and No.6 cylinders.

### TROUBLESHOOTING HINTS

The starter motor does not operate at all.

- Check the starter (coil).
- Check for poor contact at the battery terminals and starter.
- Check starter relay.
- Check key reminder switch.

### TROUBLESHOOTING HINTS

1. Engine cranks, but does not start.

- (1) Spark is insufficient or does not occur at all (on spark plug).
  - Check ignition coil.
  - Check crank angle sensor.
  - Check power transistor.
  - Check spark plugs.
  - Check spark plug cable.

(2) Spark is good.

- Check ignition timing.


2. Engine idles roughly or stalls.

- Check spark plugs.
- Check ignition timing.
- Check ignition coil.
- Check spark plug cable.


3. Poor acceleration

- Check ignition timing.
- Check spark plug cable.
- Check ignition coil.

## IGNITION SYSTEM



## CHARGING SYSTEM



Wire colour code

B:Black BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink

Y:Yellow

V:Violet

SB:Sky blue

**CHARGING SYSTEM (See P. 4-27.)****OPERATION****When engine is stopped**

When the ignition switch is switched to the "ON" position, electricity flows from the "L" terminal of the alternator to the field coil, and at the same time the charging warning lamp illuminates.

**When engine is being started/has started**

When the engine is started, charging voltage is applied to the "L" terminal of the alternator, with the result that the charging warning lamp is extinguished. In addition, because battery voltage is applied to the "S" terminal of the alternator, this battery voltage is monitored at the IC voltage regulator, thus switching ON and OFF the current to the field coil and thereby controlling the output voltage of the alternator.

Power is supplied to each load from the "B" terminal of the alternator.

**NOTE**


The alternator relay functions as a back-up for the flow of electricity to the field coil if there is a disconnection or damaged wiring of the charging warning lamp.


**TROUBLESHOOTING HINTS**

1. Charging warning lamp does not go on when the ignition switch is turned to "ON", before the engine starts.
  - Check the bulb.
2. Charging warning lamp fails to go off once the engine starts.
  - Check the IC voltage regulator (located within the alternator).
3. Discharged or overcharged battery.
  - Check the IC voltage regulator (located within the alternator).
4. The charging warning lamp illuminates dimly.
  - Check the diode (within the combination meter) for a short-circuit.


---


**NOTES**


**MPI SYSTEM**  
 <L. H. drive vehicles>





Wire colour code  
 B:Black LG:Light green G:Green  
 BR:Brown O:Orange GR:Gray L:Blue  
 W:White P:Pink Y:Yellow V:Violet  
 BB:Sky blue












## MPI SYSTEM



**<R. H. drive vehicles>**







Wire colour code  
BR:Black LG:Light green G:Green L:Blue W:White Y:Yellow BB:Sky blue  
BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet











## COOLING SYSTEM





Wire colour code  
 B:Black      LG:Light green      G:Green  
 BR:Brown      O:Orange      GR:Gray      L:Blue  
 R:Red      W:White      Y:Yellow  
 P:Pink      V:Violet      BB:Sky blue

## COOLING SYSTEM (See P. 4-42.)

### OPERATION

#### 1. When air conditioner compressor lock controller outputs LO signal (0 V)

- When the engine coolant temperature increases to 85°C (185°F), the engine coolant temperature sensor (for low speed) in the radiator turns "ON".
- This causes the radiator fan motor relay (LO) to turn "ON", to make the radiator fan operate at low speed.
- Also, when the engine coolant temperature increases to 95°C (203°F), the engine coolant temperature (for high speed) in the radiator turns "ON".
- Because of this, the radiator fan motor relay (HI) and the condenser fan motor relay (HI) turn "ON", and the radiator fan and condenser fan operate at high speed.

#### 2. When air conditioner compressor lock controller outputs HI signal (approx. 12 V)

- The power from the air conditioner compressor lock controller turns the radiator fan motor relay and the condenser fan motor relay (LO) to "ON", and the radiator fan and condenser fan operate at low speed.
- When the engine coolant temperature reaches 95°C (203°F), the engine coolant temperature (for high speed) turns "ON" and the radiator fan motor and condenser fan operate at high speed, in the same way as in item 1.

### Fan Operating Mode

Switch conditions			Fan revolving operation condition	
Air conditioner compressor lock controller output	Thermo sensor		Radiator fan motor	Condenser fan motor Condenser fan motor operates in HIGH only when it receives input from condenser fan motor relay (HI) and (LO).
	For radiator fan ON at 85 ± 4°C (185 ± 7°F) or more OFF at 77°C (171°F) or less	For condenser fan ON at 95 ± 4°C (203 ± 7°F) or more OFF at 87°C (189°F) or less		
LO (0V)	OFF	OFF	OFF	OFF
LO (0V)	ON	OFF	LOW	OFF
LO (0V)	ON	ON	HIGH	HIGH
HI (12V)	OFF	OFF	LOW	LOW
HI (12V)	ON	OFF	LOW	LOW
HI (12V)	ON	ON	HIGH	HIGH

### TROUBLESHOOTING HINTS


- Neither radiator fan nor condenser fan operates.
  - Check the fusible link No. ⑤.
- Condenser fan does not operate at all.
  - Check the dedicated fuse No. ⑧.
- Radiator fan and condenser fan do not operate at low speed only.
  - The air conditioner compressor magnetic clutch also does not turn "ON".
    - Check if there is output from the air conditioner compressor lock controller.
  - The air conditioner compressor magnetic clutch turns "ON".
    - Check each of the low speed relays and resistors.

#### Remark

- For troubleshooting the air conditioner compressor lock controller, see the Troubleshooting in Group 55 Heater, Air conditioner and Ventilation of the separate WORKSHOP MANUAL (Pub. No. PWUE9119).

**HEADLAMP**

&lt; L. H. drive vehicles without daytime running lamp &gt;



Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange


G:Green GR:Gray


L:Blue R:Red

W:White P:Pink

Y:Yellow V:Violet

BB:Sky blue





### Wire colour code

B:Black LG:1  
BR:Brown Q:Q

BR:Brown 0:0

version May 1993

ght green

ange

— 1 —

G:Green  
CB:Green

GR:Gray

---

DL

L:BLU  
D:BLU

R:Rec

IE9201

W:Whit  
D:Din

P:Print

• 100 •


Y:Yell  
V:Viol


## V:Viol

— 1 —

SB:Sky blue

—  
—





- \*1: Vehicles with theft-alarm system
- \*2: Vehicles without theft-alarm system

\*2: Vehicles without  
theft-alarm system

### Wire colour code

B:Black LG:Light

BR:Brown

BR:Brown      O:Orange

B:Black LG:Light Green G:Green  
BR:Brown O:Orange GR:Gray

L:Blue  
R:Red


W:White  
P:Pink

SIDE  
Y:Yellow  
V:Violet

SB:Sky blue

**HEADLAMP**

&lt; R. H. drive vehicles without dim-dip lamp &gt;



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red


W:White


P:Pink

Y:Yellow

V:Violet

BB:Sky blue






Wire colour code  
B:Black LG:Light green  
BR:Brown O:Orange GR:Gray


G:Green  
P:Pink


L:Blue  
R:Red

W:White  
V:Violet

BB:Sky blue







## HEADLAMP <VEHICLES WITHOUT DAYTIME RUNNING LAMP AND DIM-DIP LAMP> (See P. 4-45, 50.)

### OPERATION

#### <Headlamps ON operation>

- Turn the lighting switch to "HEAD", and the contact point of the headlamp relay will be closed to turn "ON" the headlamp relay.
- When the dimmer switch is placed in the LO position, the headlamp low-beams go on. When the switch is placed in the HI position, the headlamp high-beams go on.

#### <High-beam indicator lamp>

- When the high-beam is lit or when the passing switch is activated, the high-beam indicator lamp will be lit.

#### <Pop-up operation-Operation by lighting switch>

- When the lighting switch is placed in the HEAD position, current flows through multi-purpose fuse ⑥ to the lighting switch, and the ETACS control unit. Then the UP timer circuit in the ETACS control unit is operated, and current flows from the ETACS control unit to the U contact of the pop-up motor U/D (UP/DOWN) switch, the coil of the pop-up motor relay and earth, causing the contacts of the pop-up motor relay to close.

When the contacts of the pop-up motor relay close, current flows through the contacts of the pop-up motor relay to the pop-up motor and earth, causing the pop-up motor to rotate, which brings the headlamps to the UP position.

The pop-up motor rotates until the automatic UP stop position is reached, then the contacts of the interlocked U/D (UP/DOWN) switch change from the U to D contacts. As a result, the contacts of the pop-up motor relay open to cut off the current supplied to the pop-up motor. Then the pop-up motor ceases to rotate, holding the headlamps in the UP position.

- When the lighting switch is placed in the TAIL or OFF position, current flows through the multipurpose fuse ⑥ to the lighting switch, and the ETACS control unit. Then the DOWN timer circuit in the ETACS control unit is operated and current flows from the ETACS control unit to the DOWN contacts of the pop-up motor U/D (UP/DOWN) switch, the coil of the pop-up motor relay and earth causing the contacts of the pop-up motor relay to close.

When the contacts of the pop-up motor relay close, current flows through the contacts of the pop-up motor relay to the pop-up motor and earth, causing the pop-up motor to rotate, which brings the headlamps to the DOWN position.

The pop-up motor rotates until the automatic DOWN stop position is reached, then the contacts of the interlocked U/D (UP/DOWN) switch change from the D to U contacts. As a result, the contacts of the pop-up motor relay open to cut off current supply to the pop-up motor. Then the pop-up motor ceases to rotate, holding the headlamps in the DOWN position.

#### <Pop-up operation-Operation by pop-up switch>


- When the pop-up switch is placed in the UP position, current flows through multi-purpose fuse ⑥ to the lighting switch, the pop-up switch and the ETACS control unit, which brings the headlamps to the UP position and holds them in the UP position just like when they are operated by the lighting switch.
- When the pop-up switch is placed in the DOWN position, current flows through the multipurpose fuse ⑥ to the lighting switch, the pop-up switch and the ETACS control unit, which brings the headlamps to the DOWN position and holds them in the DOWN position just like when they are operated by the lighting switch.

## TROUBLESHOOTING HINTS

Phenomenon		Checking method
Headlamp don't come on.	But the tail lamps do illuminate.	<ul style="list-style-type: none"> <li>Check the headlamp relay.</li> <li>Check the lighting switch.</li> </ul>
	The tail lamps also don't illuminate.	<ul style="list-style-type: none"> <li>Check the fusible link ③.</li> </ul>
The low beam at both sides doesn't illuminate.		<ul style="list-style-type: none"> <li>Check the "LO" contacts of the dimmer switch.</li> </ul>
The upper beam at both sides doesn't illuminate.	The passing signal functions OK.	<ul style="list-style-type: none"> <li>Check the "HI" contacts of the dimmer switch.</li> </ul>
	The passing signal doesn't function.	<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> </ul>
One headlamp doesn't illuminate.		<ul style="list-style-type: none"> <li>Check the bulb.</li> </ul>
Can't switch from low to high beam or vice versa		<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> </ul>
The high beam indicator lamp doesn't illuminate.	The high beam of the headlamps is normal.	<ul style="list-style-type: none"> <li>Check dedicated fuse No. ⑤.</li> <li>Check the bulb.</li> </ul>
Headlamps do not rise.	They rise only when the lighting switch is operated.	<ul style="list-style-type: none"> <li>Check the pop-up switch input signal.</li> <li>Check the pop-up switch.</li> </ul>
	They rise only when the pop-up switch is operated.	<ul style="list-style-type: none"> <li>Check the lighting switch.</li> </ul>
Headlamps do not retract.		<ul style="list-style-type: none"> <li>Check the pop-up switch input signal.</li> <li>Check the pop-up switch.</li> </ul>
One headlamp does not move.		<ul style="list-style-type: none"> <li>Check the pop-up motor relay.</li> <li>Check the pop-up motor.</li> </ul>

**HEADLAMP**

&lt;L. H. drive vehicles with daytime running lamp&gt;



Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange


G:Green GR:Gray


L:Blue R:Red


W:White P:Pink


Y:Yellow V:Violet


SB:Sky blue











- \*1: Vehicles with theft alarm system
- \*2: Vehicles without theft-alarm system

**HEADLAMP <VEHICLES WITH DAYTIME RUNNING LAMP> (See P. 4-58.)****OPERATION****<Headlamps ON operation>**


- Even if the lighting switch is "OFF", when the ignition switch is turned to "ON", transistor Tr1 inside the daytime running lamp control unit turns "ON", causing the contact point of daytime running lamp relay 2 to close, turning the relay "ON" and illuminating the low-beam headlamps.
- If the lighting switch is set to the "TAIL" position, the tail lamp relay turns "ON", and because transistor Tr2 and transistor Tr1 inside the daytime running lamp control unit turn "ON" and "OFF" respectively, the tail lamps illuminate without the headlamps illuminating.
- If the lighting switch is set to the "HEAD" position, the headlamp relay turns "ON" and the headlamps illuminate.

**<Pop-up operation-Operation by lighting switch>**

- For vehicles with daytime running lamps, when the ignition switch is turned to "ON", the pop-up relay normally turns "ON" independent of the lighting switch, and the ETACS up timer circuit operates, setting the headlamps to the UP position.

## TROUBLESHOOTING HINTS


Phenomenon		Checking method
Headlamp don't come on.	But the tail lamps do illuminate.	<ul style="list-style-type: none"> <li>Check the headlamp relay.</li> <li>Check the lighting switch.</li> <li>Check the daytime running lamp relay 2</li> </ul>
	The tail lamps also don't illuminate.	<ul style="list-style-type: none"> <li>Check the fusible link ③.</li> </ul>
The low beam at both sides doesn't illuminate		<ul style="list-style-type: none"> <li>Check the "LO" contacts of the dimmer switch.</li> </ul>
The upper beam at both sides doesn't illuminate.	The passing signal functions OK.	<ul style="list-style-type: none"> <li>Check the "HI" contacts of the dimmer switch.</li> </ul>
	The passing signal doesn't function.	<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> <li>Check the daytime running lamp relay 1.</li> </ul>
One headlamp doesn't illuminate.		<ul style="list-style-type: none"> <li>Check the bulb.</li> </ul>
Can't switch from low to high beam or vice versa.		<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> </ul>
The high beam indicator lamp doesn't illuminate.	The high beam of the headlamps is normal.	<ul style="list-style-type: none"> <li>Check dedicated fuse No. ⑤.</li> <li>Check the bulb.</li> </ul>
Headlamps do not rise.	They rise only when the ignition switch is "OFF" and lighting switch is set to the HEAD position.	<ul style="list-style-type: none"> <li>Check the pop-up switch</li> <li>Check the pop-up switch input signal.</li> <li>Check the pop-up relay.</li> </ul>
	They rise only when the ignition switch is "ON".	<ul style="list-style-type: none"> <li>Check the pop-up switch</li> <li>Check the pop-up switch input signal.</li> </ul>
	They rise only when the pop-up switch is operated.	<ul style="list-style-type: none"> <li>Check the lighting switch</li> <li>Check the pop-up relay.</li> </ul>
Headlamps do not retract.		<ul style="list-style-type: none"> <li>Check the pop-up switch input signal.</li> <li>Check the pop-up switch.</li> </ul>
One headlamp does not move.		<ul style="list-style-type: none"> <li>Check the pop-up motor relay.</li> <li>Check the pop-up motor.</li> </ul>


**HEADLAMP****(R. H. drive vehicles with dim-dip lamp)**

Wire colour code

B:Black    LG:Light green    G:Green  
BR:Brown    O:Orange    GR:GrayL:Blue  
R:RedW:White  
P:PinkY:Yellow  
V:Violet

BB:Sky blue





Wire colour code

B:Black

BR:Brown

O:Orange

LG:Light green

G:Green

GR:Gray

L:Blue

R:Red


P:Pink


W:White


V:Violet

Y:Yellow

BB:Sky blue







**HEADLAMP <VEHICLES WITH DIM-DIP LAMP> (See P. 4-66.)****OPERATION****<Headlamps ON operation>**

- When the ignition switch is "ON" and the lighting switch is set to the "TAIL" position, the contact point of dim-dip lamp relay 1 closes, and the headlamps illuminate. The contact point of dim-dip lamp relay 1 is connected to the earth via a resistor, so when the headlamps illuminate dimmer than normally.

**<Pop-up operation-Operation by lighting switch>**


- For vehicles with dim-dip lamps, when the ignition switch is turned to "ON", the pop-up relay normally turns "ON" independent of the lighting switch, and the ETACS up timer circuit operates, setting the headlamps to the UP position.

## TROUBLESHOOTING HINTS

Phenomenon		Checking method
Headlamps don't illuminate even when the lighting switch is in the "HEAD" position.	But the tail lamps do illuminate.	<ul style="list-style-type: none"> <li>Check the headlamp relay.</li> <li>Check the lighting switch.</li> <li>Check the dim-dip lamp relay 2 and 3</li> </ul>
	The tail lamps also don't illuminate.	<ul style="list-style-type: none"> <li>Check the fusible link ③.</li> </ul>
Headlamps do not illuminate dimmer than normally even when the lighting switch is in the "TAIL" position.	But the tail lamps do illuminate.	<ul style="list-style-type: none"> <li>Check the headlamp relay.</li> <li>Check the lighting switch.</li> <li>Check the dim-dip lamp relay 1.</li> </ul>
	The tail lamps also don't illuminate.	<ul style="list-style-type: none"> <li>Check the fusible link ③.</li> </ul>
The low beam at both sides doesn't illuminate.		<ul style="list-style-type: none"> <li>Check the "LO" contacts of the dimmer switch.</li> </ul>
The upper beam at both sides doesn't illuminate.	The passing signal functions OK.	<ul style="list-style-type: none"> <li>Check the "HI" contacts of the dimmer switch.</li> </ul>
	The passing signal doesn't function.	<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> </ul>
One headlamp doesn't illuminate.		<ul style="list-style-type: none"> <li>Check the bulb.</li> </ul>
Can't switch from low to high beam or vice versa.		<ul style="list-style-type: none"> <li>Check the dimmer switch.</li> </ul>
The high beam indicator lamp doesn't illuminate.	The high beam of the headlamps is normal.	<ul style="list-style-type: none"> <li>Check dedicated fuse No. ⑤.</li> <li>Check the bulb.</li> </ul>
Headlamps do not rise.	They rise only when the ignition switch is "OFF" and lighting switch is set to the HEAD position.	<ul style="list-style-type: none"> <li>Check the pop-up switch</li> <li>Check the pop-up switch input signal</li> <li>Chbck the pop-up relay</li> </ul>
	They rise only when the ignition switch is "ON".	<ul style="list-style-type: none"> <li>Check the pop-up switch</li> <li>Check the pop-up switch input signal</li> </ul>
	They rise only when the pop-up switch is operated.	<ul style="list-style-type: none"> <li>Check the lighting switch.</li> <li>Check the pop-up relay.</li> </ul>
Headlamps do not retract.		<ul style="list-style-type: none"> <li>Check the pop-up switch input signal.</li> <li>Check the pop-up switch.</li> </ul>
One headlamp does not move.		<ul style="list-style-type: none"> <li>Check the pop-up motor relay.</li> <li>Check the pop-up motor.</li> </ul>

## HEADLAMP

&lt;Headlamp leveling system&gt;



Wire colour code

B:Black LG:Light green G:Green

BR:Brown O:Orange GR:Gray

I:Blue

R:Red

W:White

P:Pink

Y:Yellow

V:Violet

BB:Sky blue

**HEADLAMP-LEVELING SYSTEM (See P. 4-74.)****OPERATION****1. Headlamps angle-downward operation**

- When the lighting switch is set to the "HEAD" position, the headlamp relay is switched ON, and battery voltage is applied, through the headlamp-leveling unit, to dedicated fuse No. ⑤.
- When the headlamp-leveling switch setting is changed from "0" to "1", the positive (+) input terminal voltage of the comparator OP AMP 1 (located within the headlamp-leveling unit) becomes greater than the negative (-) input terminal standard reference voltage value, and OP AMP 1 outputs HIGH signals to OP AMP 2 and OP AMP 3.
- As a result of these HIGH signals, OP AMP 2 outputs LOW signals and OP AMP 3 outputs HIGH signals to the motor-control IC.
- When this happens, the motor-control IC is switched ON, current flows to the motor, and the motor rotates in the forward direction.
- The rotation of the motor, after passing through the gears and the output shaft, causes the headlamp reflectors to move to a downward angle, thus changing the angle of headlamp illumination.
- At this time, the position-detection sliding resistance is activated in the direction of the low resistance value, after which the OP AMP 1 negative (-) input terminal voltage value and positive (+) input terminal voltage value become equivalent, and OP AMP 2 and OP AMP 3 both output HIGH signals.
- When this happens, the motor-control IC is switched OFF and the motor stops.

**NOTE**

- (1) The same operation occurs if the headlamp-leveling switch is set to another position.
- (2) The input open protection circuit functions to stop the operation of the motor if there is an abnormal condition, such as damaged or disconnected wiring within the headlamp-leveling unit or of the wiring harness.


**2. Headlamps angle-upward operation**

- The headlamp angle-upward operation is the opposite logic of the downward operation; the motor operates in the reverse direction and then stops.

**TROUBLESHOOTING HINTS**

1. Absolutely no change of the headlamp angle
  - (1) The upper-beam indicator lamp illuminates.
    - Check the headlamp-leveling switch.
    - Check the headlamp-leveling unit.
  - (2) The upper-beam indicator lamp does not illuminate.
    - Check dedicated fuse No. ⑤.
2. There is one setting of the headlamp-leveling switch at which the headlamp angle does not change.
  - Check the headlamp-leveling switch.

**TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP  
(L.H. drive vehicles)**



Wire colour code

B:Black    LG:Light green    G:Green


BR:Brown    O:Orange    GR:Gray

L:Blue    P:Pink


R:Red    V:Yellow


V:Yellow

S:Sky blue



**TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP  
<R. H. drive vehicles>**





### TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP (See P. 4-76, 78.)

#### OPERATION

- When the lighting switch is placed in the TAIL or HEAD position, current flows through the coil of the tail lamp relay to the lighting switch and earth, causing the contacts of the tail lamp relay to close. Then current flows through the contacts of the tail lamp relay to the dedicated fuse ② and ③, the individual lamps and earth, causing the tail lamps, position lamps and licence plate lamps to go ON.

#### <Lighting monitor buzzer system>

- Placing the lighting switch in the TAIL or HEAD position causes the tail lamp relay to be energized.
- When the ignition switch is in the "OFF" position in this condition, if the driver's side door is opened and the front door switch turns "ON", the buzzer sounds to indicate that the lamps are not switched off.

#### TROUBLESHOOTING HINTS


- All lamps don't illuminate.
  - The headlamps don't illuminate, either.
    - Check the fusible link ③.
  - The headlamps illuminate.
    - Check the tail lamp relay.
    - Check the dedicated fuse ② and ③.
    - Check the lighting switch.
- Any lamp does not come on.
  - Check the bulb.
  - Check the earthing circuit.
- Lighting monitor buzzer doesn't sound.
  - But the tail lamps do illuminate.
    - Check the lighting monitor buzzer.
    - Check the front door switch (driver's side).
  - The tail lamps also don't illuminate.
    - Check the sub fusible link No. ③.
    - Check the dedicated fuse No. ②.


---

**NOTES**

## REAR FOG LAMP


&lt;L.H. drive vehicles without daytime running lamp&gt;






## REAR FOG LAMP


&lt;L.H. drive vehicles with daytime running lamp&gt;





## **REAR FOG LAMP**

**<R. H. drive vehicles>**



### Wire colour code

B:B

BR:Brown

W:White

V:Violet

LG:Light green

0:0

SB:Sky

— 1 —

G:Green


G  
D

P:Pink

L:Blue  
R:Blue

R

Y:Yellow



**REAR FOG LAMP (See P. 4-82, 84, 86.)****OPERATION**

Rear Fog lamp Relay ON Conditions

Ignition switch	Lighting switch	Rear fog lamp relay
—	"HEAD"	"ON"

- If the lighting switch is in the "HEAD" position and the rear fog lamp switch is set to "ON", the rear fog lamp relay turns "ON" and the rear fog lamps illuminate.


**TROUBLESHOOTING HINTS**

1. The rear fog lamp doesn't illuminate.
  - 1) Headlamps go on.
    - Check the rear fog lamp relay.
    - Check the rear fog lamp switch.
    - Check the dedicated fuse No. ⑯.
  - 2) Headlamps do not go on, either.
    - Check the lighting switch.
    - Check the fusible link No. ⑬.
2. The rear fog lamp at the one side doesn't illuminate.
  - Check the lamp bulb.

**GLOVE BOX LAMP AND INSPECTION LAMP (See P. 4-89.)****OPERATION**

- When the lighting switch is placed in the TAIL or HEAD position, and the contacts of the tail lamp relay close, battery voltage is applied via the dedicated fuse ② to the glove box illumination lamp and the inspection lamp.
- When the glove box is opened, the glove box illumination lamp switch is switched ON and the glove box illumination lamp illuminates.
- When the engine hood is opened, the inspection lamp switch is switched ON and the inspection lamp illuminates.

## GLOVE BOX LAMP AND INSPECTION LAMP





Wire colour code

B:Black LG:Light green G:Green  
BR:Brown O:Orange GR:GrayL:Blue  
R:RedW:White  
P:Pink  
Y:Yellow  
V:Violet

BB:Sky blue

# ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP





\*1:Vehicles  
without  
theft-alarm  
system

\*2: Vehicles  
with  
theft-alarm  
system

\*3:LH drive vehicles  
\*4:RH drive vehicles

## ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP (See P. 4-90.)

### OPERATION

#### <Room lamp>

- Battery voltage is always applied to the room lamp. When the room lamp switch is turned to "ON", the room lamp will remain lit. After either door is opened if the room lamp switch is at "DOOR" position, the room lamp will come on.
- With the room lamp turned on (with the ignition switch in the OFF position and with the room lamp switch in the DOOR position), close all doors, and the timer circuit in the ETACS control unit will be activated to gradually vary the voltage for approx. 6 seconds owing to the duty control, and the voltage will be output to transistor Tr. Since the voltage applied to the room lamp gradually decreases, the room lamp will be dimmed.
- If the ignition switch is turned to "ON" while the room lamp is lit (while the timer is activated), the timer circuit will be opened to turn "off" transistor Tr. This will immediately turn off the room lamp without dimming.

#### <Foot lamps and ignition key illumination lamp>

- Battery voltage is always applied to the foot lamps and ignition key illumination lamp. With the ignition switch in the OFF position, open any door, and all lamps will come on.
- With all lamps turned on (with the ignition switch in the OFF position), close all doors, and the timer circuit inside the ETACS control unit will operate in the same manner as the room lamp to dim all lamps. When the ignition switch is placed in the ON position with all lamps turned on (with the timer in operation), the same operation as the room lamp will take place.

### TROUBLESHOOTING HINTS

Phenomenon	Checking method
Room lamp does not come on when a door is opened with the room lamp switch in the DOOR position.	The foot lamps and ignition key cylinder illumination lamp don't illuminate, either. <ul style="list-style-type: none"> <li>Check the door switch input signal.</li> <li>Check the door switch.</li> </ul>
	The foot lamps and ignition key cylinder illumination lamp illuminate. <ul style="list-style-type: none"> <li>Check the room lamp switch.</li> <li>Check the room lamp bulb.</li> </ul>
Room lamp, foot lamps and ignition key illumination lamp go out at once when doors are closed.	<ul style="list-style-type: none"> <li>Check the door switch input signal.</li> </ul>
Even if ignition switch is turned on while lamps are being dimmed, lamps do not go out at the same time.	<ul style="list-style-type: none"> <li>Check the ignition switch input signal.</li> </ul>


## **DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR WARNING LAMP (See P. 4-94, 96.)**


### **OPERATION**

- Battery voltage is always applied (via sub-fusible link No. ⑥ and multipurpose fuse No. ⑩) to the luggage compartment lamp and door lamp.
- When the door is opened, the door switch is switched ON and the door lamp illuminates.
- When the tailgate is opened, the luggage compartment lamp switch is switched ON and the luggage compartment lamp illuminates.

# DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR WARNING LAMP


**L. H. drive vehicles**

**FUSIBLE LINK ⑥**




# DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR WARNING LAMP

< R. H. drive vehicles >

FUSIBLE LINK ⑥


Wire colour code


KX35-AC-R0814-EC	B:Black	LG:Light green	G:Green	L:Blue	W:White	Y:Yellow	BB:Sky blue
	BR:Brown	O:Orange	GR:Gray	R:Red	P:Pink	V:Violet	



# TURN-SIGNAL LAMP AND HAZARD LAMP

<L. H. drive vehicles>





### Wire colour code

Wire colour code  
B:Black LG:Light green G:Green  
BR:Brown O:Orange GR:Gray


L:Blue  
R:Red


W:White Y:Yellow  
P:Pink V:Violet

SB:Sky blue

# TURN-SIGNAL LAMP AND HAZARD LAMP

**(R. H. drive vehicles)**





## TURN-SIGNAL LAMP AND HAZARD LAMP (See P. 4-98, 100.)

### OPERATION

#### ⟨Turn-signal lamp⟩

##### 1. In normal operating condition

- When the ignition switch is placed in the ON position, battery voltage is applied through the hazard switch to the turn-signal and hazard flasher unit.
- When the turn-signal switch is placed in the LH (or RH) position, Tr1 in the flasher unit turns ON, causing the relay contacts in the flasher unit to close. This results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp lighting up.
- At the same time, the capacitor is charged through R2 up to the lower limit as set by COM3.
- As soon as the capacitor is fully charged, the output from COM3 is inverted, turning OFF Tr1. This opens the relay contacts and, as a result, the LH (or RH) turn-signal lamp and turn-signal indicator lamp go out.
- At the same time when Tr1 turns OFF, the capacitor starts discharging. As soon as the capacitor completes discharging, the COM3 output is inverted again causing Tr1 to turn ON. This results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp coming on.
- These sequences of operation repeat, which results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp flashing off and on.

##### 2. When one bulb is burnt

- When either one of the turn-signal lamp bulbs goes out, it causes the resistance of the entire lamp circuit to increase, hence a smaller voltage drop at R1 in the flasher unit.
- This smaller voltage drop is sensed and the lower voltage limit set by COM3 is raised, thus shortening the time required by the capacitor before it is fully charged.
- As a result, the on-off cycle of Tr1 becomes shorter with the resultant greater number of times the lamp flashes on and off.

#### ⟨Hazard lamp⟩

- When the hazard switch is placed in the ON position, the flasher unit relay contacts repeatedly close and open, which results in the RH and LH turn-signal lamps, turn-signal indicator lamps, and hazard warning indicator lamps flashing on and off at the same time.

#### Remark

- The number of times the hazard lamps flash on and off does not change even when one bulb is out.


### TROUBLESHOOTING HINTS

1. Neither the turn-signal lamps nor hazard lamps operate.
  - Check hazard switch contacts (on power source end).
  - Check flasher unit.
2. All LH or RH turn-signal lamps do not operate.
  - 1) Hazard lamp is fully operational.
    - Check turn-signal switch.
3. Flashing cycle of turn signal lamps is shorter.
  - Check the lamp bulb.
4. Hazard lamp does not operate.
  - 1) Turn-signal lamps are operational.
    - Check hazard switch contacts (on hazard lamp end).



**STOP LAMP**

&lt;R. H. drive vehicles&gt;



## Wire colour code

B:Black	LG:Light green
BR:Brown	O:Orange

G:Green	GR:Gray
---------	---------

L:Blue	R:Red
--------	-------


W:White	Y:Yellow
P:Pink	V:Violet

BB:Sky blue

## BACK UP LAMP


&lt;L. H. drive vehicles&gt;

IGNITION SWITCH (IG1)



&lt;R. H. drive vehicles&gt;

IGNITION SWITCH (IG1)



**BACK UP LAMP (See P. 4-105.)****OPERATION**

- When, with the ignition switch at the "ON" position, the shift lever is moved to the "R" position, the back up lamp switch is switched ON and the back up lamp illuminates.

**HORN (See P. 4-107, 108.)****OPERATION**

- The horn switch always receives battery voltage via the dedicated fuse ④ and the coil of the horn relay.
- When the horn switch is set to ON, the contacts of the horn relay close.

Then current flows through the dedicated fuse ④ to the contacts of the horn relay, the horn and earth, causing the horn to sound.

**TROUBLESHOOTING HINTS**


1. One of the horn does not sound.
  - Check the horn.
2. Horns do not sound.
  - Check the horn switch.
  - Check the dedicated fuse ④.

**NOTE**

For vehicles equipped with the theft-alarm system, refer to GROUP 54 Chassis Electrical of the separate WORKSHOP MANUAL (Pub. No. PWUE9119).

**HORN**

&lt;Vehicles without theft-alarm system&gt;



\*1:LHD

\*2:RHD

## Wire colour code

B:Black LG:Light green G:Green

BR:Brown O:Orange GR:Gray

L:Blue

R:Red

W:White

P:Pink


Y:Yellow

V:Violet

SB:Sky blue

**HORN**

&lt;Vehicles with theft-alarm system&gt;



\*1:LHD  
\*2:RHD

Wire colour code

KX35-AC-R0907-EC

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink

Y:Yellow

V:Violet

SB:Sky blue

## METER AND GAUGE (See P. 4-110.)

### OPERATION

#### <Fuel gauge>

- When the ignition key is at the "ON" position, the fuel gauge is activated.
- When there is much fuel, the unit's resistance is small and the current flowing in the circuit is great, so the gauge's indicator indicates in the "F" area.
- When there is little fuel, the unit's resistance is high and the current flowing in the circuit is small, so the gauge's indicator indicates in the "E" area.

#### <Engine coolant temperature gauge>

- When the ignition key is at the "ON" position, the engine coolant temperature gauge is activated.
- When the engine coolant temperature is high, the unit's resistance is low and there is a great flow of current in the circuit, so the gauge's indicator indicates in the "H" area.
- When the engine coolant temperature is low, the unit's resistance is high and there is a small flow of current in the circuit, so the gauge's indicator indicates in the "C" area.

#### <Speed sensor>

- Pulses are produced in accordance with the vehicle speed, and vehicle-speed signals are input to systems (the MPI system, etc.) that regulate according to the vehicle speed.

#### <Oil pressure gauge>

- When the ignition key is at the "ON" position, the oil pressure gauge is activated.
- When oil pressure is high, the internal contacts of the gauge unit are kept closed for a longer period of time. This causes more current to flow in the circuit, and the gauge pointer swings to the high pressure side.
- When oil pressure is low, the internal contacts of the gauge unit open in a shorter period of time. Therefore, there is less current flowing in the circuit and the gauge pointer swings to the low pressure side.


#### <Pressure gauge>


- When the ignition key is set to the "ON" position, the gauge indicator will be at "0".
- When the engine is started, the indicator will move from "0" to the minus (-) side, and then, as the boost level increases, it will move to the plus (+) side.

### TROUBLESHOOTING HINTS


1. The fuel gauge doesn't function, or shows the incorrect indication.
  - (1) Disconnect the connector of the fuel pump and gauge unit assembly; the "F" side is indicated when terminal ⑤ is then earthed.
    - Check the fuel gauge.
2. The engine coolant temperature gauge doesn't function, or shows the incorrect indication.
  - (1) The "H" side is indicated when the connector of the engine coolant temperature gauge unit is disconnected and then earthed.
    - Check the engine coolant temperature gauge unit.
3. Systems dependent upon control according to the vehicle speed do not function correctly.
  - Check the speed sensor.
4. The oil pressure gauge doesn't function, or shows the incorrect indication.
  - (1) The "H" side is indicated when the connector of the oil pressure gauge unit is disconnected and then earthed.
    - Check the oil pressure gauge unit.
5. The meter illumination lamp does not illuminate.
  - (1) The tail lamps illuminate.
    - Check the rheostat.

## METER AND GAUGE







## 4WS FLUID LEVEL WARNING LAMP



BRAKE WARNING LAMP      OIL PRESSURE WARNING LAMP



LOW FUEL  
WARNING LAMPLOW ENGINE OIL  
LEVEL WARNING LAMP

## 4WS FLUID LEVEL WARNING LAMP, BRAKE WARNING LAMP, OIL PRESSURE WARNING LAMP, LOW FUEL WARNING LAMP, LOW ENGINE OIL LEVEL WARNING LAMP (See P. 4-112, 113, 114.)

### OPERATION

#### 〈4WS fluid level warning lamp〉

- When, with the ignition switch at the ON position, the amount of 4WS fluid becomes less than the specified amount, the 4WS fluid level sensor is switched ON and the warning lamp illuminates.

#### Remark

The delay circuit is provided to prevent the low engine oil warning lamp from going on even if the engine oil level sensor is temporarily turned off due to cornering or other running conditions of the vehicle.

#### 〈Brake warning lamp〉

- When the brake fluid level goes down below a predetermined level or parking brake lever is pulled, with the ignition switch in the ON position, the brake fluid level sensor is activated or the parking brake switch is turned ON, causing the brake warning lamp to light up.

#### 〈Oil pressure warning lamp〉

- When the lubrication system fails after engine starting, resulting in the oil pressure failing to build up, the oil pressure switch turns ON causing the oil pressure warning lamp to light up.


#### 〈Low fuel warning lamp〉

- When the fuel level goes down causing the level sensor to be exposed, with the ignition switch in the ON position, the resistance of level sensor becomes small. When this resistance goes down below the predetermined level, the low fuel warning lamp lights up to warn the driver that the amount of fuel still available for use is small.

#### 〈Low engine oil warning lamp〉

- When the ignition switch is turned to the "ON" position (in the state where the engine is stopped), electric current will flow to terminal "L" of the alternator through the multi-purpose fuse No. ⑪, low engine oil warning lamp and engine oil level relay and the low engine oil warning lamp will also light up.
- When the engine starts, the charging voltage will be applied to the terminal "L" of the alternator. Therefore, the low engine oil warning lamp will go out.
- When the engine oil temperature rises to approx. 55°C (131°F), the engine oil level sensor (TEMP) provided in the oil pan will be turned off.
- When the engine oil amount in the oil pan drops below the set level in this state, the engine oil level sensor (LEVEL) will be turned off to apply the voltage to the delay circuit.
- If the "OFF" state continues for approx. 20 seconds or more, the power transistor will be turned on to light the low engine oil warning lamp to indicate a shortage of engine oil.

## POWER WINDOW



\*1: LHD  
\*2: RHD

Wire colour code  
 B:Black BR:Brown LG:Light green O:Orange G:Green GR:Gray I:Blue R:Red W:White P:Pink Y:Yellow V:Violet BB:Sky blue

**POWER WINDOW (See P. 4-116.)****OPERATION**

- When the power window (main or sub) switch is depressed (UP or DOWN) with the ignition switch in the ON position, current flows through sub-fusible link No. ⑨ to the power window motor. This energizes the power window motor causing the door window glass to open or close.
- When the DOWN side the power window main switch (driver's seat side switch) is depressed all the way, it is locked in the depressed position and the power window motor is operated until the door glass is fully opened.
- When the power window lock switch is placed in the LOCK (OFF) position, operating a switch other than the ones for the driver's and front passenger's side window (both main and sub) does not cause the power window motor to be operated.
- The power window motor is provide with a circuit breaker that protects the motor from damage caused by overcurrent.

Reference: Circuit breaker characteristics Restricts the motor at room temperature [20 to 25°C (68 to 77°F)];


Opens following 4-to-40sec. initial energization time;

Resets within 60 seconds if left open thereafter.

**TROUBLESHOOTING HINTS**

1. All door glasses cannot be opened or closed.
  - Check the fusible link No. ⑨.
  - Check the multi-purpose fuse No. ③.
  - Check the power window relay.
  - Check the power window main switch.
2. Any door glass cannot be opened or closed.
  - (1) Neither power window main nor sub switch is activated.
    - Check the power window main switch.
    - Check the defective power window motor.
  - (2) Either power window main or sub switch is inoperative.
    - Check the inoperative power window switch.
3. One-touch switch function is not operational.
  - Replace the power window main switch.

# CENTRAL DOOR LOCKING SYSTEM



### Wire colour code

Wire colour code  
B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray


L:Blue  
R:Red

W:White  
P:Pink

Y:Yellow  
V:Violet

SB:8ky blue





\*1:Vehicles without theft-alarm system  
\*2:Vehicles with theft-alarm system  
\*3:LHD  
\*4:RHD

**CENTRAL DOOR LOCKING SYSTEM (See P. 4-118.)****OPERATION**


- When the driver's side inside lock knob is set to the "LOCK" (or "UNLOCK") position, the switch inside the driver's side door lock actuator turns OFF (or ON), and the timer function of the ETACS control unit causes transistor Tr1 (or Tr2) to turn ON for 0.5 seconds. This causes the "LOCK" (or "UNLOCK") side of the door lock relay to turn ON, thereby operating the passenger's side door lock actuator.
- When the passenger's side door is locked (or unlocked) by key operation, the door key cylinder unlock switch turns ON and the switch inside the passenger's side door lock actuator turns OFF (or ON), and the timer function of the ETACS control unit causes transistor Tr1 (or Tr2) to turn ON for 0.5 seconds. This causes the "LOCK" (or "UNLOCK") side of the door lock relay to turn ON, thereby operating the driver's side door lock actuator. The driver's side door lock actuator cannot be operated by operating the passenger's side inside lock knob.
- If the driver's side door is opened and the inside lock knob is set to the "LOCK" position while the key is left inserted in the ignition switch, the timer function of the ETACS unit causes transistor Tr2 to turn ON. This causes the "UNLOCK" side of the door lock relay to turn ON, thereby unlocking all doors.


**TROUBLESHOOTING HINTS**

Phenomenon	Inspection method
One of the door lock actuators fails to operate	<ul style="list-style-type: none"> <li>Check the door actuator which fails to operate.</li> </ul>
The passenger's side door doesn't lock or unlock even if the driver's side door lock knob is operated.	<ul style="list-style-type: none"> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>
The driver's side door doesn't lock or unlock even if the passenger's side door lock knob is operated.	<ul style="list-style-type: none"> <li>Check the door key cylinder unlock switch input signal.</li> <li>Check the door key cylinder unlock switch.</li> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>
No unlock operation can be made by pressing door lock knob after fulfilment of following conditions. <ul style="list-style-type: none"> <li>Insertion of key in ignition switch (key reminder switch OFF)</li> <li>Opening of driver's side door (door switch ON)</li> </ul>	<ul style="list-style-type: none"> <li>Check the key reminder switch input signal.</li> <li>Check the key reminder switch.</li> <li>Check the driver's side door switch input signal.</li> <li>Check the driver's side door switch.</li> </ul>
Neither the central door locking function nor the key reminder function operates.	<ul style="list-style-type: none"> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>

# AIR CONDITIONER

<L. H. drive vehicles>





### Wire colour code

B:Black

BR:Brown

**BR-Brown**

**Light green**

**Light Green  
Orange**

### **Orange**

G:Green

G.Green  
GR:Gray

GRAY

LiBlue

L:Blue  
R:Red

R.R&B

White

W:White  
P:Pink

P-PINK

V-Vet Low


Y:Yellow  
V:Virginia


V.VIOLE


SB-Sky Blue


BB:Sky blue

—  
—









#### Wire colour code

B:Black LG:

BR:Brown 0:0

---

light green

range

— 1 —

G:Green

GR:Gray

卷之三

L:Blue

R:Red

www.IBM.com

W:White

www.cs


— 1 —


Y: Yellow

V:Violet

• 100 •


SB:Sky blue







# AIR CONDITIONER


*(R. H. drive vehicles)*







Wire colour code  
 B:Black L:Light green G:Green L:Blue  
 BR:Brown O:Orange GR:Gray R:Red W:White Y:Yellow P:Pink V:Violet SB:Sky blue







Wire colour code  
 B:Black    LG:Light green    G:Green    L:Blue    W:White    Y:Yellow    BB:Sky blue  
 BR:Brown    O:Orange    GR:Gray    R:Red    P:Pink    V:Violet











## **WINDSHIELD WIPER AND WASHER**



KX35-AC-R1301-EC



## WINDSHIELD WIPER AND WASHER (See P. 4-138.)

### OPERATION

#### 〈Low-speed (and high-speed) wiper〉

- When the wiper switch is placed in the LO position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.
- Placing the wiper switch in the HI position causes the wipers to operate at high speed.

#### 〈Intermittent wiper〉

- If the wiper switch is turned to the INT position when the ignition switch is in the ON or ACC position, the voltage value from the intermittent variable volume switch is input to the intermittent time detection circuit.
- The intermittent time detection circuit outputs an H signal at the intermittent time according to the set value of the intermittent variable volume switch and, via OR, turns the Tr on and off to operate the wiper.

#### 〈Auto wiper stop〉

- When the wiper switch is placed in the OFF position, the cam contacts of wiper motor causes current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

#### 〈Mist wiper〉

- If the washer switch is on for 0.6 second or less when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will not be poured but the transistor will be turned on to operate the wipers one time.

#### 〈Wiper linked with washer〉

- If the washer switch is on for 0.6 second or more when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will be poured and the transistor will be turned on 0.6 second later to operate the wipers two or three times.

#### 〈Low washer fluid warning lamp〉

- If the windshield washer fluid is below the specified level when the ignition switch is in the "ON" position, the washer fluid level sensor will be turned on to light the low washer fluid warning lamp.


### TROUBLESHOOTING HINTS

Phenomenon		Inspecting method
Wipers do not operate continuously.	Washer does not operate.	<ul style="list-style-type: none"> <li>Check the multi-purpose fuse No. ⑨</li> </ul>
	Washer operates.	<ul style="list-style-type: none"> <li>Check the wiper motor.</li> <li>Check the column switch.</li> </ul>
Low-speed (or high-speed) wiper operation only is inoperative.		<ul style="list-style-type: none"> <li>Check the column switch.</li> </ul>
Wipers do not operate intermittently. (They operate continuously.)		<ul style="list-style-type: none"> <li>Check the wiper switch "INT" input signal.</li> <li>Check the column switch.</li> </ul>
Wipers do not stop.		<ul style="list-style-type: none"> <li>Check the wiper switch "INT" input signal.</li> <li>Check the column switch.</li> <li>Check the wiper motor.</li> </ul>
The intermittent time will not vary even if the variable intermittent wiper control switch is operated.		<ul style="list-style-type: none"> <li>Check the variable intermittent wiper control switch input signal.</li> <li>Check the column switch.</li> </ul>
Even if the washer switch is on for 0.6 second or more, the washer will not operate.	The wipers linked with the washer operate.	<ul style="list-style-type: none"> <li>Check the washer motor.</li> <li>Check the washer nozzle and washer tube.</li> </ul>
	The wipers linked with the washer do not operate.	<ul style="list-style-type: none"> <li>Check the washer switch input signal.</li> <li>Check the washer switch.</li> </ul>

## REAR WIPER AND WASHER


&lt;L. H. drive vehicles&gt;

## IGNITION SWITCH(ACC)



## REAR WIPER AND WASHER

&lt;R. H. drive vehicles&gt;



## REAR WIPER AND WASHER (See P. 4-141, 142.)

### OPERATION

#### Low-speed wiper

- When the rear wiper switch is placed in the ON position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.

#### Auto wiper stop

- When the rear wiper switch is placed in the OFF position, the cam contacts of wiper motor causes current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

#### Intermittent wiper

- When the rear wiper switch is placed in the INT position with the ignition switch in ACC or ON position, the rear intermittent wiper relay is energized causing the rear intermittent wiper relay contacts to close and open repeatedly.
- When the contacts are closed, the wiper motor is energized.
- When the rear wiper motor is energized, the rear intermittent wiper relay contacts open; however, the cam contacts keep the rear wiper motor energized until the wiper blades return to their stop position.


### TROUBLESHOOTING HINTS

- Wipers do not operate.
  - (1) Washer is not operative, either.
    - Check multi-purpose fuse No. ⑨.
    - Check earth.
- Low-speed wiper operation only is inoperative.
  - Check wiper switch.
- Wipers do not stop.
  - Check wiper motor.
  - Check rear intermittent wiper relay.
  - Check rear wiper switch.
- Intermittent wiper operation is inoperative.
  - Check terminal voltage of the rear intermittent wiper relay energized.

Terminal No.	Voltage	Check
2	0V	Rear intermittent wiper relay or rear wiper switch
	12V	Rear intermittent wiper relay
	0 ↔ 12V (alternating)	— (Normal)

- Washer is inoperative.
  - Check washer motor.
  - Check washer switch.

## **HEADLAMP WASHER**



Wire colour code  
B:Black LG:Li

**ght green**

G:Green  
G:Germany

L:Blue  
Ed

1

W:White  
P:Pink

Y:Y  
Y:Y

below  
last

BB:Sky blue

**HEADLAMP WASHER (See P. 4-144.)****OPERATION**

- When the headlamp washer switch is turned ON with ignition switch in ON and lighting switch in HEAD position, the headlamp washer relay is energized causing the headlamp washer motor to start.

**⟨Low washer fluid warning lamp⟩**

- If the headlamp washer fluid is below the specified level when the ignition switch is in the "ON" position, the washer fluid level sensor will be turned on to light the low washer fluid warning lamp.

**REMOTE CONTROLLED MIRROR (See P. 4-146, 147.)****OPERATION**


- When the remote controlled mirror switch is operated while the ignition key is in "ACC" or "ON" position, current flows through fuse No. ⑤ remote controlled mirror switch, remote controlled mirror, remote controlled mirror switch, and earth, causing the mirror to move.

**TROUBLESHOOTING HINTS**

Neither right nor left mirror operates

- 1) Also cigarette lighter does not operate
  - Check multi-purpose fuse No. ⑤.
- 2) Cigarette lighter operates
  - Check remote controlled mirror switch.

## REMOTE CONTROLLED MIRROR (*Highly variable*)



### Wire colour code

B:Black  
B&W:Black & White

BR:Brown

L.G:Light green

**0:Orange**

G:Green

GR:Gray

L:Blue

R:Red

**W:White**

P:Pink


Y:Yellow

V:Violet


SB:Sky blue


# REMOTE CONTROLLED MIRROR

< R. H. drive vehicles >



## DEFOGGER





\*1:LHD  
\*2:RHD

• E • RD

**DEFOGGER (See P. 4-148.)****OPERATION**

- If the defogger switch is turned to "ON" with the ignition switch at the "ON" position, the timer circuit in the ETACS control unit will be operated to keep the transistor "on" for 11 minutes to close the contact point of the defogger relay. When the defogger relay is "on", the defogger and mirror heater will be activated. Moreover, the indicator lamp of the defogger switch is lit to inform that the defogger and mirror heater are activated.
- When 11 minutes have passed, the defogger and mirror heater will stop activating even if the defogger switch is at "ON". When the defogger and mirror heater are activated (the timer is activated), they will also stop activating even if the defogger switch is set at "ON" again.


**TROUBLESHOOTING HINTS**


Phenomenon	Checking method
Mirror heater operates but defogger does not operate.	<ul style="list-style-type: none"> <li>• Check the defogger</li> </ul>
Defogger operates but mirror heater does not operate.	<ul style="list-style-type: none"> <li>• Check the dedicated fuse No. ⑩.</li> <li>• Check the mirror heater.</li> </ul>
Neither defogger nor mirror heater operates.	<ul style="list-style-type: none"> <li>• Check the multi-purpose fuse No. ③.</li> <li>• Check the defogger relay.</li> <li>• Check the defogger switch.</li> <li>• Check the defogger switch input signal.</li> <li>• Check the ignition switch input signal.</li> </ul>
Illumination lamp of defogger switch does not come on or is dim.	<ul style="list-style-type: none"> <li>• Check the illumination lamp bulb.</li> <li>• Check the rheostat.</li> </ul>

**NOTES**

## RADIO AND TAPE PLAYER


&lt;L. H. drive vehicles&gt;





# RADIO AND TAPE PLAYER

(R. H. drive vehicles)



C-74

1234 X 567  
8910111213141516

C-75

123 X 456  
7891011121314

C-77


123 X 456  
7891011121314

C-79

123 X 456  
7891011121314

C-61

1234 X 567  
8910111213141516




Wire colour code


B:Black LG:Light green G:Green  
BR:Brown O:Orange GR:GrayL:Blue  
R:RedW:White  
P:Pink  
Y:Yellow  
V:Violet

SB:Sky blue

## CLOCK



## CIGARETTE LIGHTER



### Remarks

Remarks  
(1)\*1:L.H. drive vehicles.  
(2)\*2:R.H. drive vehicles.

10

KX35-AC-R1404-EC

Wire colour code  
B:Black LG:Light green  
BR:Brown O:Orange

G:Green  
GR:Gray


L:Blue  
R:Red


W:White Y:Yellow  
P:Pink V:Violet

SB:Sky blue


# ANTI-LOCK BRAKE SYSTEM (ABS)

<L. H. drive vehicles>







Wire colour code  
 B:Black    LG:Light green    G:Green  
 BR:Brown    O:Orange    GR:Gray    L:Blue  
 R:Red    W:White    V:Yellow  
 BB:Sky blue



# ANTI-LOCK BRAKE SYSTEM (ABS)

<R. H. drive vehicles>







Wire colour code

B:Black  
BR:BrownLG:Light green  
O:OrangeG:Green  
GR:GrayL:Blue  
R:RedW:White  
P:PinkY:Yellow  
V:Violet

BB:Sky blue



**ELECTRONIC CONTROL SUSPENSION (ECS) SYSTEM**  
 <L. H. drive vehicles>



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

I:Blue

R:Red


W:White

P:Pink


Y:Yellow


V:Violet

SB:Sky blue




# 4-166 CIRCUIT DIAGRAM — Electronic Control Suspension (ECS) System









FRONT SHOCK ABSORBER (LH)



FRONT SHOCK ABSORBER (RH)



ELECTRONIC  
CONTROL  
SUSPENSION  
CONTROL UNIT



REAR SHOCK  
ABSORBER (LH)



REAR SHOCK  
ABSORBER (RH)



Wire colour code  
B:Black BR:Brown LG:Light Green O:Orange G:Green GR:Gray


L:Blue R:Red

W:White P:Pink Y:Yellow V:Violet


SB:Sky blue


# ELECTRONIC CONTROL SUSPENSION (ECS) SYSTEM


< R. H. drive vehicles >




# 4-170 CIRCUIT DIAGRAM — Electronic Control Suspension (ECS) System









Wire colour code  
B:Black LG:Light green G:G  
BR:Brown O:Orange GR:

green  
Gray

L:Blue  
R:Red


W:White  
P:Pink


Y:Yellow  
V:Violet

SB:Sky blue

## ACTIVE AERO SYSTEM

&lt;L. H. drive vehicles without theft-alarm system&gt;





### Wire colour code


Wire colour code  
B:Black LG:Light green  
BR:Brown O:Orange

G:Green  
GR:Gray

L:Blue  
R:Red


W:White Y:Yellow  
P:Pink V:Violet

SB:Sky blue



## ACTIVE AERO SYSTEM

**L.H. drive vehicles with theft-alarm system**



### Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray

L:Blue  
R:Red

W:White  
P:Pink

Y:Yellow  
V:Violet

BB:Sky blue



### Wire colour code

8:6

Black LG:

**Light green**

G:Green


L:Blue

www.viphi.com

te Y:Ye!


BB · 8


88-844 9110




## ACTIVE AERO SYSTEM

&lt;R.H. drive vehicles without theft-alarm system&gt;









## ACTIVE AERO SYSTEM

&lt; R.H. drive vehicles with theft-alarm system &gt;





### Wire colour code

B:Black LG:1

BR:Brown

BRITISH

G:Light green

**:Orange**

• 87 • 130

G:Green

GR:Gray

www.english-test.net

L:Blue

R:Red

R-KOD

W:White Y:Ye


W:White  
P:Pink

P-PIK

SB:Sky blue


88:89

et



# SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

<L. H. drive vehicles>




Wire colour code  
B:Black    LG:Light green    G:Green  
BR:Brown    O:Orange    GR:Gray

L:Blue  
R:Red

W:White  
P:Pink

Y:Yellow  
V:Violet


SB:Sky blue

**CAUTION**

Carefully read and observe the SRS SERVICE PRECAUTIONS (Refer to WORKSHOP MANUAL (Pub. No. PWUE9119) SRS Service Precautions) prior to any service.

# SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

(R. H. drive vehicles)



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

I:Blue

R:Red


W:White

P:Pink

Y:Yellow

V:Violet

SB:Sky blue


**CAUTION**


• Carefully read and observe the SRS SERVICE PRECAUTIONS (Refer to WORKSHOP MANUAL (Pub. No. PWUE9119) SRS Service Precautions) prior to any service.

**NOTES**

# AUTO-CRUISE CONTROL SYSTEM

< L. H. drive vehicles >





### Wire colour code

white colour code  
B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray


L:Blue  
R:Red

W:White  
P:Pink

Y:Yellow  
V:Violet

BB:Sky blue






## **AUTO-CRUISE CONTROL UNIT**


C-30


D-43 12345 M 678910  
111213141516171819202122


# AUTO-CRUISE CONTROL SYSTEM

< R. H. drive vehicles >









## **AUTO-CRUISE CONTROL UNIT**

C-30

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

D-43

D-43 12945 Motor 910  
112 131 145 158 171 192 202 212

### Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange

G:Green  
G:Gray

L:Blue  
D:Bad

W:White  
D:Black

Y:Yellow  
V:Violet


SB:Sky blue


---

**NOTES**

**POWER SEAT**

&lt;L. H. drive vehicles&gt;






## Wire colour code


B:Black  
BR:BrownLG:Light green  
O:OrangeG:Green  
GR:GrayL:Blue  
R:RedW:White  
P:PinkY:Yellow  
V:Violet

SB:Sky blue

## **POWER SEAT**

### **<R. H. drive vehicles>**





## Wire colour code


B:Black    LG:Light green    G:Green  
 BR:Brown    O:Orange    GR:Gray


I:Blue    W:White    V:Yellow  
 P:Pink


BB:Sky blue  
 V:Violet


## THEFT-ALARM SYSTEM

&lt; L. H. drive vehicles &gt;













## THEFT-ALARM SYSTEM

&lt;R. H. drive vehicles&gt;









---

**NOTES**

## 4B CIRCUIT DIAGRAM

<b>JUNCTION BLOCK .....</b>	<b>4B-4</b>
<b>CENTRALIZED JUNCTION .....</b>	<b>4B-6</b>
<b>POWER DISTRIBUTION SYSTEM</b>	
L.H. drive vehicles .....	4B-12
R.H. drive vehicles .....	4B-17
<b>STARTING SYSTEM</b>	
L.H. drive vehicles with theft-alarm system .....	4B-22
R.H. drive vehicles with theft-alarm system .....	4B-23
Vehicles without theft-alarm system .....	4B-24
<b>IGNITION SYSTEM .....</b>	<b>4B-26</b>
<b>CHARGING SYSTEM .....</b>	<b>4B-27</b>
<b>MPI SYSTEM</b>	
L.H. drive vehicles .....	4B-30
R.H. drive vehicles .....	4B-36
<b>COOLING SYSTEM</b>	
L.H. drive vehicles .....	4B-42
R.H. drive vehicles .....	4B-44
<b>HEADLAMP</b>	
L.H. drive vehicles with daytime running lamp .....	4B-46
L.H. drive vehicles without daytime running lamp .....	4B-50
R.H. drive vehicles with dim-dip lamp .....	4B-54
R.H. drive vehicles without dim-dip lamp .....	4B-56
<b>HEADLAMP LEVELING SYSTEM .....</b>	<b>4B-58</b>
<b>TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP</b>	
L.H. drive vehicles .....	4B-60
R.H. drive vehicles .....	4B-62
<b>REAR FOG LAMP</b>	
L.H. drive vehicles with daytime running lamp .....	4B-66
L.H. drive vehicles without daytime running lamp .....	4B-68
R.H. drive vehicles .....	4B-70
<b>GLOVE BOX LAMP AND INSPECTION LAMP .....</b>	
<b>4B-72</b>	
<b>ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP</b>	
L.H. drive vehicles .....	4B-74
R.H. drive vehicles .....	4B-76
<b>DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR WARNING LAMP</b>	
L.H. drive vehicles .....	4B-78
R.H. drive vehicles .....	4B-80
<b>TURN-SIGNAL LAMP AND HAZARD LAMP</b>	
L.H. drive vehicles .....	4B-82
R.H. drive vehicles .....	4B-84
<b>STOP LAMP</b>	
L.H. drive vehicles .....	4B-87
R.H. drive vehicles .....	4B-88
<b>BACK-UP LAMP</b>	
L.H. drive vehicles .....	4B-89
R.H. drive vehicles .....	4B-89
<b>HORN</b>	
Vehicles with theft-alarm system .....	4B-91
Vehicles without theft-alarm system .....	4B-92
<b>METER AND GAUGE .....</b>	
<b>4B-94</b>	
<b>4WS FLUID LEVEL WARNING LAMP .....</b>	
<b>4B-96</b>	
<b>BRAKE WARNING LAMP .....</b>	
<b>4B-97</b>	
<b>LOW FUEL WARNING LAMP .....</b>	
<b>4B-97</b>	
<b>OIL PRESSURE WARNING LAMP .....</b>	
<b>4B-98</b>	
<b>LOW ENGINE OIL LEVEL WARNING LAMP .....</b>	
<b>4B-98</b>	
<b>POWER WINDOW .....</b>	
<b>4B-100</b>	
<b>CENTRAL DOOR LOCKING SYSTEM .....</b>	
<b>4B-102</b>	
<b>AIR CONDITIONER</b>	
L.H. drive vehicles .....	4B-106
R.H. drive vehicles .....	4B-114
<b>WINDSHIELD WIPER AND WASHER .....</b>	
<b>4B-122</b>	
<b>REAR WIPER AND WASHER</b>	
L.H. drive vehicles .....	4B-126
R.H. drive vehicles .....	4B-127
<b>HEADLAMP WASHER .....</b>	
<b>4B-128</b>	
<b>REMOTE CONTROLLED MIRROR</b>	
L.H. drive vehicles .....	4B-130
R.H. drive vehicles .....	4B-131
<b>DEFOGGER .....</b>	
<b>4B-132</b>	
<b>RADIO AND TAPE PLAYER</b>	
L.H. drive vehicles .....	4B-136
R.H. drive vehicles .....	4B-138
<b>CLOCK .....</b>	
<b>4B-140</b>	
<b>CIGARETTE LIGHTER .....</b>	
<b>4B-141</b>	
<b>ANTI-LOCK BRAKE SYSTEM</b>	
L.H. drive vehicles .....	4B-142
R.H. drive vehicles .....	4B-145
<b>ELECTRONIC CONTROL SUSPENSION SYSTEM</b>	
L.H. drive vehicles .....	4B-148
R.H. drive vehicles .....	4B-153

**ACTIVE AERO SYSTEM**

L.H. drive vehicles with theft-alarm system .....	4B-158
L.H. drive vehicles without theft-alarm system .....	4B-161
R.H. drive vehicles with theft-alarm system .....	4B-164
R.H. drive vehicles without theft-alarm system .....	4B-167

**SUPPLEMENTAL RESTRAINT SYSTEM**

L.H. drive vehicles .....	4B-170
R.H. drive vehicles .....	4B-172

**AUTO-CRUISE CONTROL SYSTEM**

L.H. drive vehicles .....	4B-174
R.H. drive vehicles .....	4B-178

**POWER SEAT**


L.H. drive vehicles .....	4B-182
R.H. drive vehicles .....	4B-184

**THEFT-ALARM SYSTEM**

L.H. drive vehicles .....	4B-186
R.H. drive vehicles .....	4B-190

**NOTES**


## JUNCTION BLOCK



## Remark


- Connector numbers are keyed to the configuration diagram (dash panel) and each circuit diagram.

K035-AC-R1601-SC



**CENTRALIZED JUNCTION****FUSIBLE LINK (Relay box in engine compartment)**


No.	Circuit	Housing colour	Rated capacity (A)
1	Alternator circuit, Fusible link No. ⑥, ⑦, ⑨, ⑩, ⑪, Dedicated fuse ⑦	Wine red	120
2	—	—	—
3	Lighting circuit, Charging circuit	Green	40
4	Ignition switch circuit	Pink	30
5	Radiator fan motor and condenser fan motor circuit	Green	40
6	Junction block (Multipurpose fuse ⑥, ⑬, ⑭, ⑯, ⑰, ⑲), Dedicated fuse ④	Green	40
7	ABS circuit	Yellow	60
8	—	—	—
9	Power window circuit, Power seat circuit	Pink	30
10	Defogger circuit, Remote controlled mirror circuit	Green	40
11	Active aero circuit	Pink	30




16F0434

## DEDICATED FUSE


Power supply circuit	No.	Rated capacity (A)	Housing colour	Circuit
Battery	1	20	Yellow	MPI circuit
Tail lamp relay	2	10	Red	Tail lamp circuit, Lighting monitor buzzer circuit <LHD>
	3	10	Red	Tail lamp circuit, Lighting monitor buzzer circuit <RHD>
Fusible link ⑥	4	10	Red	Horn circuit
Headlamp relay	5	10	Red	Upper beam circuit, Headlamp leveling circuit, Headlamp washer circuit
Battery	6	10	Red	Hazard lamp circuit
	7	—	—	—
Fusible link ⑤	8	20	Yellow	Condenser fan motor circuit
	9	10	Red	A/C circuit
Defogger relay	10	10	Red	Remote controlled mirror heater circuit



16F0434



16F0002




16F0544

**MULTI-PURPOSE FUSE (In junction block)**

Power supply circuit		No.	Rated capacity (A)	Load circuit	
—		1	—	—	
—		2	—	—	
Ignition switch	IG <sub>2</sub>	3	10	ABS control unit, A/C compressor lock controller, A/C control unit, Blower motor relay, Condenser fan motor relay (HI), Daytime running lamp control unit, Defogger relay, Dim-dip lamp relay 1, Electronic control suspension control unit, Headlamp washer relay, Power window relay, Radiator fan motor relay	
	ACC	4	10	Radio and tape player, Auto-cruise control unit, Motor antenna control unit, Clock	
		5	15	Cigarette lighter, Remote controlled mirror	
Battery		6	10	Door lock power relay, ETACS control unit, Motor antenna control unit	
—		7	—	—	
—		8	—	—	
Ignition switch	ACC	9	15	Rear intermittent wiper relay, Washer motor, Wiper motor, Wiper relay	
		10	15	Accessory socket*, ETACS control unit	
	IG <sub>1</sub>	11	15	Active aero control unit, Auto-cruise control main switch, Auto-cruise control relay, Combination gauge, Combination meter, Engine oil level relay, ETACS control unit, Lighting monitor buzzer, Motor antenna control unit, Speed sensor, SRS diagnosis unit, Turn signal and hazard flasher unit, 4WS fluid level sensor	
		12	15	Capacitor, Engine control relay, Engine control unit, Ignition coil, Power transistor	
Battery		13	10	Rear fog lamp relay, Rear fog lamp	
		14	10	Theft-alarm horn, Theft-alarm horn relay	
—		15	—	—	
Battery		16	30	Blower motor	
		17	15	Stop lamp	
Ignition switch	IG <sub>1</sub>	18	10	Back-up lamp, SRS diagnosis unit	
Battery		19	10	Active aero control unit, A/C control unit, Auto-cruise control unit, Clock, Combination meter, Door lamp, Electronic control suspension control unit, Engine control unit, ETACS control unit, Foot lamp, Ignition key cylinder illumination lamp, Luggage compartment lamp, Radio and Tape player, Room lamp, Starter relay, MUT-II power supply circuit	

## NOTE

\*: L.H. drive vehicles.




16N1129

**CENTRALIZED RELAY**


Classification		Name	Classification		Name
Relay box in engine compartment	A-01X	Headlamp relay	A/C relay box in engine compartment	A-44X	Condenser fan motor relay (HI)
	A-02X	—		A-45X	—
	A-03X	—		A-46X	Magnetic clutch relay
	A-04X	Radiator fan motor relay (LO)		A-47X	Condenser fan motor relay (LO)
	A-05X	Tail lamp relay		C-04X	Door lock power relay
	A-06X	Horn relay		C-05X	Rear fog lamp relay
	A-07X	Radiator fan motor relay (HI)		C-06X	Defogger relay
	A-08X	—		C-07X	Power window relay
	A-09X	Starter relay*		—	—
	A-10X	Alternator relay		—	—
	A-11X	Storage connector		—	—

## NOTE


\*: Vehicles with theft-alarm system.

**<Relay box in engine compartment>**

16F0434

**<A/C relay box in  
engine compartment>**

16F0002


**<Interior relay box>**

16F0544

**NOTES**

# POWER DISTRIBUTION SYSTEM

L. H. drive vehicles



Wire colour code  
B:Black  
BR:Brown

LG:Light green  
O:Orange


G:Green  
GR:Gray


I:Blue  
R:Red


W:White  
P:Pink


Y:Yellow  
V:Violet

SB:Sky blue











Wire colour code  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow BB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet


# POWER DISTRIBUTION SYSTEM


R. H. drive vehicles




Wire colour code  
 B:Black    LG:Light green    G:Green    L:Blue    W:White    Y:Yellow  
 BR:Brown    O:Orange    GR:Gray    R:Red    P:Pink    V:Violet    SB:Sky blue









Wire colour code


KX35-AC-R0106B-EC

B:Black LG:Light green G:Green  
BR:Brown O:Orange GR:GrayL:Blue  
R:RedW:White  
P:PinkY:Yellow  
V:Violet

BB:Sky blue


## STARTING SYSTEM

L.H. drive vehicles with theft-alarm system




## STARTING SYSTEM

R.H. drive vehicles with theft-alarm system



# STARTING SYSTEM

Vehicles without theft-alarm system



## STARTING SYSTEM (See P. 4B-22, 23, 24.)

### OPERATION

- When the ignition switch is switched to the "ST" position, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.

#### 〈Vehicles with theft-alarm system〉

- The transistor inside the ETACS control unit is switched ON if a vehicle door is opened without using the key. This turns the starter relay OFF, and power ceases to be supplied to the starter magnet switch.

## IGNITION SYSTEM (See P. 4B-26.)

### OPERATION

- Turn ignition switch to "ON" position, and battery voltage will be applied to primary winding of ignition coil.
- When crank angle sensor signal is input to engine control unit, engine control unit makes ON-OFF control of power transistors one by one.
- When power transistor A is turned from ON to OFF, the spark plugs of No. 1 and No. 4 cylinders spark. Turning of power transistor B from ON to OFF will produce sparking in spark plugs of No. 2 and No. 5 cylinders. Furthermore, when power transistor C is turned from ON to OFF, sparking is produced in spark plugs of No. 3 and No. 6 cylinders.


### TROUBLESHOOTING HINTS

- The starter motor does not operate at all.
- Check the starter (coil).
  - Check for poor contact at the battery terminals and starter.
  - Check starter relay. 〈with theft-alarm system〉
  - Check key reminder switch. 〈with theft-alarm system〉


### TROUBLESHOOTING HINTS

1. Engine cranks, but does not start.
  - (1) Spark is insufficient or does not occur at all (on spark plug).
    - Check ignition coil.
    - Check crank angle sensor.
    - Check power transistor.
    - Check spark plugs.
    - Check spark plug cable.
  - (2) Spark is good.
    - Check ignition timing.
2. Engine idles roughly or stalls.
  - Check spark plugs.
  - Check ignition timing.
  - Check ignition coil.
  - Check spark plug cable.
3. Poor acceleration
  - Check ignition timing.
  - Check spark plug cable.
  - Check ignition coil.

## IGNITION SYSTEM



## CHARGING SYSTEM



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink

Y:Yellow

V:Violet

SB:Sky blue

**CHARGING SYSTEM (See P. 4B-27.)****OPERATION****When engine is stopped**

When the ignition switch is switched to the "ON" position, electricity flows from the "L" terminal of the alternator to the field coil, and at the same time the charging warning lamp illuminates.

**When engine is being started/has started**

When the engine is started, charging voltage is applied to the "L" terminal of the alternator, with the result that the charging warning lamp is extinguished. In addition, because battery voltage is applied to the "S" terminal of the alternator, this battery voltage is monitored at the IC voltage regulator, thus switching ON and OFF the current to the field coil and thereby controlling the output voltage of the alternator.

Power is supplied to each load from the "B" terminal of the alternator.

**NOTE**

The alternator relay functions as a back-up for the flow of electricity to the field coil if there is a disconnection or damaged wiring of the charging warning lamp.


**TROUBLESHOOTING HINTS**


1. Charging warning lamp does not go on when the ignition switch is turned to "ON", before the engine starts.
  - Check the bulb.
2. Charging warning lamp fails to go off once the engine starts.
  - Check the IC voltage regulator (located within the alternator.)
3. Discharged or overcharged battery.
  - Check the IC voltage regulator (located within the alternator).
4. The charging warning lamp illuminates dimly.
  - Check the diode (within the combination meter) for a short-circuit.

**NOTES**


# MPI SYSTEM


## L. H. drive vehicles






Wire colour code  
 B:Black    LG:Light green    G:Green    B:Blue  
 BR:Brown    O:Orange    GR:Gray    R:Red    W:White    P:Pink    Y:Yellow    V:Violet  
 SB:Sky blue








**Remarks**


- (1) \*1: ACTIVE AERO SYSTEM
- AUTO-CRUISE CONTROL SYSTEM
- CIGARETTE LIGHTER
- RADIO AND TAPE PLAYER
- TAIL LAMP POSITION LAMP AND LICENCE PLATE LAMP
- (2) \*2: Vehicles with DRL
- (3) \*3: Vehicles without DRL


C-43 [12345678910111213]  
[14151617181920212223242526]C-44 [12345678910111213]  
[3031323334353637383930313233343536373839]



# MPI SYSTEM

## R. H. drive vehicles





### Wire colour code

B:Black

BR:Brown O:Orange

BR:Brown U:Orange

green G:Green  
GPII

GR:Gray

GR:Gray

L:Blue

R:Red

R:Red

W:White  
B:Black

P:Pink


P:PINK


W:White Y:Yellow  
R:Red V:Violet


P:Pink V:Violet


P:Pink V:Violet

SB:Sky blue











# COOLING SYSTEM

L. H. drive vehicles







Wire colour code  
 B:Black LG:Light green G:Green  
 BR:Brown O:Orange GR:Gray L:Blue W:White Y:Yellow  
 R:Red P:Pink V:Violet BB:Sky blue

# COOLING SYSTEM

R. H. drive vehicles





Wire colour code  
B:Black LG:Lig  
BR:Brown O:Oran

Wire colour code  
B:Black LG:Light green  
BR:Brown O:Orange

G:Green  
GR:Gray

L:Blue  
R:Red


W:White Y:  
P:Pink V:


## Yellow Violet


SB:Sky blue

## HEADLAMP

L. H. drive vehicles with daytime running lamp







Wire colour code  
B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

**HEADLAMP < L.H. drive vehicles with daytime running lamp > (See P. 4B-46.)****OPERATION**

Headlamps Relay ON Conditions

Ignition switch	Lighting switch	Dimmer/ passing switch	Headlamps relay
"ON"	"OFF"	—	ON
—	"HEAD"	—	ON
—	—	"PASS"	ON

**<Daytime running lamp operation>**

- Turning the ignition switch to the ON position causes the headlamps relay, and tail lamp relay to be energized, which causes the headlamps, tail lamps, etc. to go on.

**<Low-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamps relay and daytime running lamp relay to be energized.
- If the dimmer/passing switch is placed in the LO position at this time, the headlamps light up in low beam.

**<Upper-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamps relay and daytime running lamp relay to be energized.
- If the dimmer/passing switch is placed in the HI position at this time, the headlamps light up in upper beam.

**<Upper-beam indicator lamp>**

- This lamp lights up when the upper/passing beams are on, indicating that the headlamps are on in upper beam.

**<Passing operation>**


- When the dimmer/passing switch is set to the "ON" position, the headlamps relay and daytime running lamp relay are switched ON and the upper beam of the headlamps illuminates.


**TROUBLESHOOTING HINTS**

- 1) Headlamps don't go on.
  - 1) But the tail lamps do illuminate.
    - Check the headlamps relay.
    - Check the lighting switch.
  - 2) The tail lamps also don't illuminate.
    - Check the fusible link No. ③.
- 2) The upper beam at both sides doesn't illuminate.
  - 1) The passing signal functions OK.
    - Check the dimmer switch HI contacts.
  - 2) The passing signal doesn't function.
    - Check the dimmer switch.
    - Check the daytime running lamp relay.
    - Check the daytime running lamp control unit.
- 3) One headlamp doesn't illuminate.
  - Check the lamp bulb.
- 4) Can't switch from low to upper beam or vice-versa.
  - Check the dimmer switch.
- 5) With the ignition switch at the "ON" position, the headlamps' low beam does not illuminate.
  - Check the daytime running lamp control unit.
- 6) Upper-beam indicator lamp does not go on.
  - 1) Headlamps' upper beams are operational.
    - Check dedicated fuse No. ⑤.
    - Check the indicator lamp bulb.

## **HEADLAMP**

L.H. drive vehicles without daytime running lamp





Wire colour code  
B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

## HEADLAMP <Vehicles without daytime running lamp and dim-dip lamp> (See P. 4B-50, 56)

### OPERATION

Headlamp Relay ON Conditions

Lighting switch	Dimmer/ passing switch	Headlamp relay
"HEAD"	—	ON
—	ON	ON

#### <Low-beam operation>

- Placing the lighting switch in the HEAD position causes the headlamp relay to be energized.
- If the dimmer/passing switch is placed in the LO position at this time, the headlamps light up in low beam.

#### <Upper-beam operation>

- Placing the lighting switch in the HEAD position causes the headlamp relay to be energized.
- If the dimmer/passing switch is placed in the HI position at this time, the headlamps light up in upper beam.

#### <Upper-beam indicator lamp>

- This lamp lights up when the upper/passing beams are on, indicating that the headlamps are on in upper beam.

#### <Passing operation>

- When the dimmer/passing switch is set to the "ON" position, the headlamp relay is switched ON and the upper beam of the headlamps illuminates.

### TROUBLESHOOTING HINTS

1. Headlamps don't go on.
  - 1) But the tail lamps illuminate.
    - Check the headlamp relay.
    - Check the lighting switch.
  - 2) The tail lamps also don't illuminate.
    - Check the fusible link No. ③.
2. The low beam at both sides doesn't illuminate.
  - Check the dimmer switch LO contacts.
3. The upper beam at both sides doesn't illuminate.
  - 1) The passing signal functions OK.
    - Check the dimmer switch HI contacts.
4. One headlamp doesn't illuminate.
  - Check the lamp bulb.
5. Can't switch from low to upper beam or vice-versa.
  - Check the dimmer switch.
6. Upper-beam indicator lamp does not go on.
  - 1) Headlamp upper beams are operational.
    - Check dedicated fuse No. ⑤.
    - Check the indicator lamp bulb.

**HEADLAMP <R.H. drive vehicles with dim-dip lamp> (See P. 4B-54.)****OPERATION**

Headlamp Relay ON Conditions

Ignition switch	Lighting switch	Dimmer/ passing switch	Headlamp relay
"ON"	"TAIL"	—	ON
—	"HEAD"	—	ON
—	—	"PASS"	ON

**<Dim-dip lamp operation>**

- Placing the lighting switch in the TAIL position causes dim-dip lamp relay (1) to be energized.
- This causes the headlamp relay to be also energized resulting in the headlamps being lit up dimly through the circuit by way of resistor.

**<Low-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamp relay, dim-dip lamp relay (2) and dim-dip lamp relay (3) to be energized.
- If the dimmer/passing switch is placed in the LO position at this time, the headlamps light up in low beam.

**<Upper-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamp relay, dim-dip lamp relay (2) and dim-dip lamp relay (3) to be energized.
- If the dimmer/passing switch is placed in the HI position at this time, the headlamps light up in upper beam.

**<Upper-beam indicator lamp>**

- This lamp lights up when the upper/passing beams are on, indicating that the headlamps are on in upper beam.

**<Passing operation>**


- When the dimmer/passing switch is set to the "ON" position, the headlamp relay is switched ON and the upper beam of the headlamps illuminates.


**TRUOUBLESHOOTING HINTS**

1. Headlamps don't go on.
  - 1) But the tail lamps illuminate.
    - Check the headlamp relay.
    - Check the lighting switch.
    - Check the dim-dip lamp relays (2) and (3).
  - 2) The tail lamps also don't illuminate.
    - Check the fusible link No. ③.
2. The low beam at both sides doesn't illuminate.
  - Check the dimmer switch LO contacts.
3. The upper beam at both sides doesn't illuminate.
  - 1) The passing signal functions OK.
    - Check the dimmer switch HI contacts.
4. One headlamp doesn't illuminate.
  - Check the lamp bulb.
5. Can't switch from low to upper beam or vice-versa.
  - Check the dimmer switch.
6. The headlamp's low beam does not illuminate at the "TAIL" position of the lighting switch.
  - 1) The low beam does illuminate, however, when, with lighting switch at the "HEAD" position, the dimmer switch is set to "LO".
    - Check the dim-dip lamp relay (1).
    - Check the resistor.
    - Check the diode.
7. Upper-beam indicator lamp does not go on.
  - 1) Headlamp upper beams are operational.
    - Check dedicated fuse No. ⑤.
    - Check the indicator lamp bulb.

## HEADLAMP

R. H. drive vehicles with dim-dip lamp







Wire colour code  
B:Black  
BR:Brown  
G:Green  
GR:Gray  
L:Blue  
V:Violet  
SB:Sky blue  
LG:Light green  
O:Orange  
P:Pink  
R:Red  
Y:Yellow  
W:White

**HEADLAMP**


R. H. drive vehicles without dim-dip lamp

FUSIBLE LINK (3)





## HEADLAMP LEVELING SYSTEM



## HEADLAMP LEVELING SYSTEM (See P. 4B-58.)

### OPERATION

#### 1. Headlamps angle-downward operation

- When the lighting switch is set to the "HEAD" position, the headlamp relay is switched ON, and battery voltage is applied, through the headlamp leveling unit, to dedicated fuse No. ⑤.
- When the headlamp leveling switch setting is changed from "0" to "1", the positive (+) input terminal voltage of the comparator OP AMP 1 (located within the headlamp leveling unit) becomes greater than the negative (-) input terminal standard reference voltage value, and OP AMP 1 outputs HIGH signals to OP AMP 2 and OP AMP 3.
- As a result of these HIGH signals, OP AMP 2 outputs LOW signals and OP AMP 3 outputs HIGH signals to the motor-control IC.
- When this happens, the motor-control IC is switched ON, current flows to the motor, and the motor rotates in the forward direction.
- The rotation of the motor, after passing through the gears and the output shaft, causes the headlamp reflectors to move to a downward angle, thus changing the angle of headlamp illumination.
- At this time, the position-detection sliding resistance is activated in the direction of the low resistance value, after which the OP AMP 1 negative (-) input terminal voltage value and positive (+) input terminal voltage value become equivalent, and OP AMP 2 and OP AMP 3 both output HIGH signals.
- When this happens, the motor-control IC is switched OFF and the motor stops.

#### NOTE

- (1) The same operation occurs if the headlamp leveling switch is set to another position.
- (2) The input open protection circuit functions to stop the operation of the motor if there is an abnormal condition, such as damaged or disconnected wiring within the headlamp leveling unit or of the wiring harness.


#### 2. Headlamps angle-upward operation

- The headlamp angle-upward operation is the opposite logic of the downward operation; the motor operates in the reverse direction and then stops.

### TROUBLESHOOTING HINTS

1. Absolutely no change of the headlamp angle
  - (1) The upper-beam indicator lamp illuminates.
    - Check the headlamp leveling switch.
    - Check the headlamp leveling unit.
  - (2) The upper-beam indicator lamp does not illuminate.
    - Check dedicated fuse No. ⑤.
2. There is one setting of the headlamp leveling switch at which the headlamp angle does not change.
  - Check the headlamp leveling switch.

TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP  
L. H. drive vehicles



Wire colour code  
B:Black LG:Li

B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray

L:Blue  
R:Red


W:White  
P:Pink

Y:Yellow  
V:Violet

SB:Sky blue



**TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP**  
**R. H. drive vehicles**



Wire colour code  
B:Black LG:Light

B:Black

BR:Brown

LG:Light green

0:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White


Pink

Y:Yellow

V:Violin

SB:Sky Blue

BB-SKY 010e



### **TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP (See P. 4B-60, 62.)**

#### **OPERATION**

- In vehicles with daytime running lamps, when the lighting switch is placed in the TAIL or HEAD position and the ignition switch is turned to ON, current always flows through the coil of the tail lamp relay to the lighting switch and earth, causing the contacts of the tail lamp relay to close. Current then flows through the contacts of the tail lamp relay to dedicated fuses ② and ③, the individual lamps and the earth, causing the tail lamps, position lamps and licence plate lamps to turn ON.

#### **Lighting monitor buzzer system**

- Placing the lighting switch in the TAIL or HEAD position causes the tail lamp relay to be energized.
- When the ignition switch is in the "OFF" position in this condition, if the driver's side door is opened and the front door switch turns "ON", the buzzer sounds to indicate that the lamps are not switched off.

#### **TROUBLESHOOTING HINTS**

1. All lamps don't illuminate.
  - (1) The headlamps don't illuminate, either.
    - Check the fusible link ③.
  - (2) The headlamps illuminate.
    - Check the tail lamp relay.
    - Check the dedicated fuse ② and ③.
    - Check the lighting switch.
2. Any lamp does not come on.
  - Check the bulb.
  - Check the earthing circuit.
3. Lighting monitor buzzer doesn't sound.
  - (1) But the tail lamps do illuminate.
    - Check the lighting monitor buzzer.
    - Check the front door switch (driver's side).
  - (2) The tail lamps also don't illuminate.
    - Check the sub fusible link No. ③.
    - Check the dedicated fuse No. ②.

**REAR FOG LAMP (See P. 4B-66, 68, 70.)****OPERATION**

Rear Fog lamp Relay ON Conditions

⟨Vehicles without daytime running lamp⟩

Ignition switch	Lighting switch	Rear fog lamp relay
—	"HEAD"	ON

⟨Vehicles with daytime running lamp⟩

Ignition switch	Lighting switch	Rear fog lamp relay
—	"HEAD"	ON
"ON"	"OFF" or "HEAD"	ON

- Placing the lighting switch in the HEAD position causes the rear fog lamp relay to be energized. For vehicles with daytime running lamps, if the ignition switch is in the "ON" position and the lighting switch is in the "OFF" position, the rear fog lamp relay will be energized.
- When the rear fog lamp switch is turned ON in this condition, the rear fog lamps go on.

**TROUBLESHOOTING HINTS**


1. The rear fog lamp doesn't illuminate.
  - 1) Headlamps go on.
    - Check the rear fog lamp relay.
    - Check the rear fog lamp switch.
    - Check the dedicated fuse No. ⑩.
  - 2) Headlamps do not go on, either.
    - Check the lighting switch.
    - Check the fusible link No. ③.
2. The rear fog lamp at the one side doesn't illuminate.
  - Check the lamp bulb.

**GLOVE BOX LAMP AND INSPECTION LAMP (See P. 4B-72.)****OPERATION**

- When the lighting switch is placed in the TAIL or HEAD position, and the contacts of the tail lamp relay close, battery voltage is applied via the dedicated fuse ② to the glove box illumination lamp and the inspection lamp.
- When the glove box is opened, the glove box illumination lamp switch is switched ON and the glove box illumination lamp illuminates.
- When the engine hood is opened, the inspection lamp switch is switched ON and the inspection lamp illuminates.

## REAR FOG LAMP

L. H. drive vehicles with daytime running lamp



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red


W:White

P:Pink

Y:Yellow


V:Violet

BB:Sky blue



## REAR FOG LAMP

L. H. drive vehicles without daytime running lamp



### Wire colour code

B:Black

BR:Black O:Bright Green G:Green  
BR:Brown O:Orange GR:Gray

204 2000

[View Details](#) | [Edit](#) | [Delete](#)


R:Blue  
L:Red

— 1 —


W:White Y:Yellow  
P:Pink V:Violet

[View all posts by admin](#) | [View all posts in category](#)

SB:Sky blue



**REAR FOG LAMP**  
R. H. drive vehicles



#### **Wire colour code**

Wife color code  
B:Black L:Light green

10

BR:Brown O:Orange

G:Green

8

GR:Gran

LiBlue

1

R:Red

W:White

2


www.winter-pink.com

#### **White-Yellow**


11

1

SB-Skyline



## GLOVE BOX LAMP AND INSPECTION LAMP



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

I:Blue

R:Red

W:White

P:Pink

Y:Yellow

V:Violet

BB:Sky blue

## ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP (See P. 4B-74, 76.)

### OPERATION

#### Room lamp

- Battery voltage is always applied to the room lamp. When the room lamp switch is turned to "ON", the room lamp will remain lit. After either door is opened if the room lamp switch is at "DOOR" position, the room lamp will come on.
- With the room lamp turned on (with the ignition switch in the OFF position and with the room lamp switch in the DOOR position), close all doors, and the timer circuit in the ETACS control unit will be activated to gradually vary the voltage for approx. 6 seconds owing to the duty control, and the voltage will be output to transistor Tr. Since the voltage applied to the room lamp gradually decreases, the room lamp will be dimmed.
- If the ignition switch is turned to "ON" while the room lamp is lit (while the timer is activated), the timer circuit will be opened to turn "off" transistor Tr. This will immediately turn off the room lamp without dimming.


#### Foot lamps and ignition key illumination lamp

- Battery voltage is always applied to the foot lamps and ignition key illumination lamp. With the ignition switch in the OFF position, open any door, and all lamps will come on.
- With all lamps turned on (with the ignition switch in the OFF position), close all doors, and the timer circuit inside the ETACS control unit will operate in the same manner as the room lamp to dim all lamps. When the ignition switch is placed in the ON position with all lamps turned on (with the timer in operation), the same operation as the room lamp will take place.

### TROUBLESHOOTING HINTS

Phenomenon	Checking method
Room lamp does not come on when a door is opened with the room lamp switch in the DOOR position.	<p>The foot lamps and ignition key cylinder illumination lamp don't illuminate, either.</p> <ul style="list-style-type: none"> <li>Check the door switch input signal.</li> <li>Check the door switch.</li> <li>Check the multi-purpose fuse No. ⑯.</li> </ul>
	<p>The foot lamps and ignition key cylinder illumination lamp illuminate.</p> <ul style="list-style-type: none"> <li>Check the room lamp switch.</li> <li>Check the room lamp bulb.</li> </ul>
Room lamp, foot lamps and ignition key illumination lamp go out at once when doors are closed.	<ul style="list-style-type: none"> <li>Check the door switch input signal.</li> </ul>
Even if ignition switch is turned on while lamps are being dimmed, lamps do not go out at the same time.	<ul style="list-style-type: none"> <li>Check the ignition switch input signal.</li> </ul>

**ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER  
ILLUMINATION LAMP**  
L. H. drive vehicles



IGNITION KEY  
CYLINDER  
ILLUMINATION  
LAMP  
J/B


J/B

B

C

J/B

A



IGNITION  
SWITCH (IG1)

36

2B-W

7

C-78

J/B

11

15A

13

C-76

1234560

5

B-W

2

B-W

1

B-W

3

B-W

2

B-W

1

B-W

0

B-W

1

B-W

2

B-W

3

B-W

4

B-W

5

B-W

6

B-W

7

B-W

8

B-W

9

B-L

4

B-L

5

B-L

16

DIAGNOSIS

CONNECTOR

C-70

FRONT SIDE

1234567890

01011010101010

10

2B

11

B

12

B

13

B

14

B

15

B

16

B

17

B

18

B

19

B

20

B

21

B

22

B

23

B

24

B

25

B

26

B

27

B

28

B

29

B

30

B

31

B

32

B

33

B

34

B

35

B

36

B

37

B

38

B

39

B

40

B

41

B

42

B

43

B

44

B

45

B

46

B

47

B

48

B

49

B

50

B

51

B

52

B

53

B

54

B

55

B

56

B

57

B

58

B

59

B

60

B

61

B

62

B

63

B

64

B

65

B

66

B

67

B

68

B

69

B

70

B

71

B

72

B

73

B

74

B

75

B

76

B

77

B

78

B

79

B

80

B

81

B

82

B

83

B

84

B

85

B

86

B

87

B

88

B

89

B

90

B

91

B

92

B

93

B

94

B

95

B

96

B

97

B

98

B

99

B

100

B

101

B

102

B

103

B

104

B

105

B

106

B

107

B

108

B

109

B

110

B

111

B

112

B

113

B

114

B

115

B

116

B

117

B

118

B

119

B

120

B

121

B

122

B

123

B

124

B

125

B

126

B

127

B

128

B

129

B

130


B


131

B


132

**ROOM LAMP, FOOT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP**  
**R. H. drive vehicles**





**DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR  
WARNING LAMP**  
L. H. drive vehicles



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red


W:White

P:Pink

Y:Yellow


V:Violet

BB:Sky blue



**DOOR LAMP, LUGGAGE COMPARTMENT LAMP AND DOOR  
WARNING LAMP**  
**R. H. drive vehicles**

## FUSIBLE LINK ⑥



### Wire colour code

Wire colour code  
B:Black LG:Light  
BR:Brown O:Orange


green G:Green  
GR:Gray

L:Blue  
R:Red

W:White  
P:Pink


Y:Yellow  
V:Violet

SB:Sky blue



## TURN-SIGNAL LAMP AND HAZARD LAMP


L. H. drive vehicles






## TURN-SIGNAL LAMP AND HAZARD LAMP

## R. H. drive vehicles





Wire colour code  
B:Black LG:Li  
BR:Brown O:Dra

B:Black  
BR:Brown  
LG:Lilac  
O:Orange

ight green  
orange

G:Green  
GR:Gray

L:Blue  
R:Red

W:White  
P:Pink

Y:Yellow  
V:Violet

BB:SKY BLUE

## TURN-SIGNAL LAMP AND HAZARD LAMP (See P. 4B-78, 80.)

### OPERATION

#### <Turn-signal lamp>

##### 1. In normal operating condition

- When the ignition switch is placed in the ON position, battery voltage is applied through the hazard switch to the turn-signal and hazard flasher unit.
- When the turn-signal switch is placed in the LH (or RH) position, Tr1 in the flasher unit turns ON, causing the relay contacts in the flasher unit to close. This results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp lighting up.
- At the same time, the capacitor is charged through R2 up to the lower limit as set by COM3.
- As soon as the capacitor is fully charged, the output from COM3 is inverted, turning OFF Tr1. This opens the relay contacts and, as a result, the LH (or RH) turn-signal lamp and turn-signal indicator lamp go out.
- At the same time when Tr1 turns OFF, the capacitor starts discharging. As soon as the capacitor completes discharging, the COM3 output is inverted again causing Tr1 to turn ON. This results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp coming on.
- These sequences of operation repeat, which results in the LH (or RH) turn-signal lamp and turn-signal indicator lamp flashing off and on.

##### 2. When one bulb is burnt

- When either one of the turn-signal lamp bulbs goes out, it causes the resistance of the entire lamp circuit to increase, hence a smaller voltage drop at R1 in the flasher unit.
- This smaller voltage drop is sensed and the lower voltage limit set by COM3 is raised, thus shortening the time required by the capacitor before it is fully charged.
- As a result, the on-off cycle of Tr1 becomes shorter with the resultant greater number of times the lamp flashes on and off.

#### <Hazard lamp>

- When the hazard switch is placed in the ON position, the flasher unit relay contacts repeatedly close and open, which results in the RH and LH turn-signal lamps, turn-signal indicator lamps, and hazard warning indicator lamps flashing on and off at the same time.

#### Remark


- The number of times the hazard lamps flash on and off does not change even when one bulb is out.

### TROUBLESHOOTING HINTS

1. Neither the turn-signal lamps nor hazard lamps operate.
  - Check hazard switch contacts (on power source end).
  - Check flasher unit.
2. All LH or RH turn-signal lamps do not operate.
  - 1) Hazard lamp is fully operational.
    - Check turn-signal switch.
3. Flashing cycle of turn signal lamps is shorter.
  - Check the lamp bulb.
4. Hazard lamp does not operate.
  - 1) Turn-signal lamps are operational.
    - Check hazard switch contacts (on hazard lamp end).

## STOP LAMP

## L. H. drive vehicles



### Wire colour code

B:Black LG:L

BR:Brown O:Oral

卷之三

ght green

ng

8

G:Green

**GR:Gray**

— 1 —

L:Blue

R:Red

— 10 —

W:White  
B:Black

P:Pink

— 1 —

Y: Yellow  
V: Viz-1-4

V:Violet


— 1 —

SB:Sky blue

---

## STOP LAMP

R. H. drive vehicles




## Wire colour code


B:Black	LG:Light green	G:Green	L:Blue	W:White	Y:Yellow	BB:Sky blue
BR:Brown	O:Orange	GR:Gray	R:Red	P:Pink	V:Violet	

## BACK-UP LAMP

&lt;L. H. drive vehicles&gt;



&lt;R. H. drive vehicles&gt;



Wire colour code  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

**BACK-UP LAMP (See P. 4B-89.)****OPERATION**

- When, with the ignition switch at the "ON" position, the shift lever is moved to the "R" position, the back up lamp switch is switched ON and the back-up lamp illuminates.

**HORN (See P. 4B-91, 92.)****OPERATION**

- The horn switch always receives battery voltage via the dedicated fuse ④ and the coil of the horn relay.
- When the horn switch is set to ON, the contacts of the horn relay close.

Then current flows through the dedicated fuse ④ to the contacts of the horn relay, the horn and earth, causing the horn to sound.

**TROUBLESHOOTING HINTS**


- One of the horn does not sound.
  - Check the horn.
- Horns do not sound.
  - Check the horn switch.
  - Check the dedicated fuse ④.

**NOTE**

For vehicles equipped with the theft-alarm system, refer to GROUP 54 Chassis Electrical of the separate WORKSHOP MANUAL (Pub. No. PWUE9119).

**HORN**

Vehicles with theft-alarm system



Wire colour code

B:Black BR:Brown

LG:Light green O:Orange

G:Green GR:Gray

L:Blue R:Red


W:White P:Pink

Y:Yellow V:Violet

BB:Sky blue

## HORN

Vehicles without theft-alarm system



## METER AND GAUGE (See P. 4B-94.)

### OPERATION

#### <Fuel gauge>

- When the ignition switch is at the "ON" position, the fuel gauge is activated.
- When there is much fuel, the unit's resistance is small and the current flowing in the circuit is great, so the gauge's indicator indicates in the "F" area.
- When there is little fuel, the unit's resistance is high and the current flowing in the circuit is small, so the gauge's indicator indicates in the "E" area.

#### <Engine coolant temperature gauge>

- When the ignition switch is at the "ON" position, the engine coolant temperature gauge is activated.
- When the engine coolant temperature is high, the unit's resistance is low and there is a great flow of current in the circuit, so the gauge's indicator indicates in the "H" area.
- When the engine coolant temperature is low, the unit's resistance is high and there is a small flow of current in the circuit, so the gauge's indicator indicates in the "C" area.

#### <Speed sensor>

- Pulses are produced in accordance with the vehicle speed, and vehicle-speed signals are input to systems (the MPI system, etc.) that regulate according to the vehicle speed.

#### <Oil pressure gauge>

- When the ignition switch is at the "ON" position, the oil pressure gauge is activated.
- When oil pressure is high, the internal contacts of the gauge unit are kept closed for a longer period of time. This causes more current to flow in the circuit, and the gauge pointer swings to the high pressure side.
- When oil pressure is low, the internal contacts of the gauge unit open in a shorter period of time. Therefore, there is less current flowing in the circuit and the gauge pointer swings to the low pressure side.


#### <Pressure gauge>

- When the ignition switch is set to the "ON" position, the gauge indicator will be at "0".
- When the engine is started, the indicator will move from "0" to the minus (-) side, and then, as the boost level increases, it will move to the plus (+) side.

### TROUBLESHOOTING HINTS


1. The fuel gauge doesn't function, or shows the incorrect indication.
  - (1) Disconnect the connector of the fuel pump and gauge unit assembly; the "F" side is indicated when terminal ⑤ is then earthed.
    - Check the fuel gauge.
2. The engine coolant temperature gauge doesn't function, or shows the incorrect indication.
  - (1) The "H" side is indicated when the connector of the engine coolant temperature gauge unit is disconnected and then earthed.
    - Check the engine coolant temperature gauge unit.
3. Systems dependent upon control according to the vehicle speed do not function correctly.
  - Check the speed sensor.
4. The oil pressure gauge doesn't function, or shows the incorrect indication.
  - (1) The "H" side is indicated when the connector of the oil pressure gauge unit is disconnected and then earthed.
    - Check the oil pressure gauge unit.
5. The meter illumination lamp does not illuminate.
  - (1) The tail lamps illuminate.
    - Check the rheostat.

## METER AND GAUGE




### Remarks

(1) \*1:LHD  
(2) \*2:BHD



## 4WS FLUID LEVEL WARNING LAMP



### Wire colour code

B:Black  
BB:Brown

BR:Brown

O:Orange GR:Gray

L:Blue  
R:Pink

R: Rec

W:White  
D:Dink

P:Pink


Y: Yellow  
V: Viscous


V:Violet

BB:Sky blue

## BRAKE WARNING LAMP

## LOW FUEL WARNING LAMP



OIL PRESSURE  
WARNING LAMPLOW ENGINE OIL LEVEL  
WARNING LAMP

**4WS FLUID LEVEL WARNING LAMP (See P. 4B-96.)****BRAKE WARNING LAMP (See P. 4B-97.)****LOW FUEL WARNING LAMP (See P. 4B-97.)****OIL PRESSURE WARNING LAMP (See P. 4B-98.)****LOW ENGINE OIL LEVEL WARNING LAMP (See P. 4B-98.)****OPERATION****<4WS fluid level warning lamp>**

- When, with the ignition switch at the ON position, the amount of 4WS fluid becomes less than the specified amount, the 4WS fluid level sensor is switched ON and the warning lamp illuminates.

**<Brake warning lamp>**

- When the brake fluid level goes down below a predetermined level or parking brake lever is pulled, with the ignition switch in the ON position, the brake fluid level sensor is activated or the parking brake switch is turned ON, causing the brake warning lamp to light up.

**<Low fuel warning lamp>**

- When the fuel level goes down causing the level sensor to be exposed, with the ignition switch in the ON position, the resistance of level sensor becomes small. When this resistance goes down below the predetermined level, the low fuel warning lamp lights up to warn the driver that the amount of fuel still available for use is small.

**<Oil pressure warning lamp>**

- When the lubrication system fails after engine starting, resulting in the oil pressure failing to build up, the oil pressure switch turns ON causing the oil pressure warning lamp to light up.


**<Low engine oil warning lamp>**

- When the ignition switch is turned to the "ON" position (in the state where the engine is stopped), electric current will flow to terminal "L" of the alternator through the multi-purpose fuse No. ⑪, low engine oil warning lamp and engine oil level relay and the low engine oil warning lamp will also light up.
- When the engine starts, the charging voltage will be applied to the terminal "L" of the alternator. Therefore, the low engine oil warning lamp will go out.
- When the engine oil temperature rises to approx. 55°C, the engine oil level sensor (TEMP) provided in the oil pan will be turned off.
- When the engine oil amount in the oil pan drops below the set level in this state, the engine oil level sensor (LEVEL) will be turned off to apply the voltage to the delay circuit.
- If the "OFF" state continues for approx. 20 seconds or more, the power transistor will be turned on to light the low engine oil warning lamp to indicated a shortage of engine oil.

**Remark**

The delay circuit is provided to prevent the low engine oil warning lamp from going on even if the engine oil level sensor is temporarily turned off due to cornering or other running conditions of the vehicle.

## POWER WINDOW



**POWER WINDOW (See P. 4B-100.)****OPERATION**

- When the power window (main or sub) switch is depressed (UP or DOWN) with the ignition switch in the ON position, current flows through sub-fusible link No. ⑨ to the power window motor. This energizes the power window motor causing the door window glass to open or close.
- When the DOWN side the power window main switch (driver's seat side switch) is depressed all the way, it is locked in the depressed position and the power window motor is operated until the door glass is fully opened.
- When the power window lock switch is placed in the LOCK (OFF) position, operating a switch other than the ones for the driver's and front passenger's side window (main) does not cause the power window motor to be operated.
- The power window motor is provide with a circuit breaker that protects the motor from damage caused by overcurrent.


Reference: Circuit breaker characteristics Restricts the motor at room temperature [20 to 25°C]; Opens following 4-to-40sec. initial energization time;

Resets within 60 seconds if left open thereafter.

**TROUBLESHOOTING HINTS**

1. All door glasses cannot be opened or closed.
  - Check the fusible link No. ⑨.
  - Check the multi-purpose fuse No. ③.
  - Check the power window relay.
  - Check the power window main switch.
2. Any door glass cannot be opened or closed.
  - (1) Neither power window main nor sub switch is activated.
    - Check the power window main switch.
    - Check the defective power window motor.
  - (2) Either power window main or sub switch is inoperative.
    - Check the inoperative power window switch.
3. One-touch switch function is not operational.
  - Replace the power window main switch.

## CENTRAL DOOR LOCKING SYSTEM



#### Wire colour code

Wire colour  
B:Black L:  
BR:Brown O:

:Light green G:Green  
Orange GR:Gray


L:Blue  
R:Red


W:White  
P:Pink

Y:Yellow

V:Violet

SB:Sky blue



**Remarks**

- (1) \*1: Vehicles without theft-alarm system
- (2) \*2: Vehicles with theft-alarm system
- (3) \*3: LHD
- (4) \*4: RHD

**CENTRAL DOOR LOCKING SYSTEM (See P. 4B-102.)****OPERATION**


- When the driver's side inside lock knob is set to the "LOCK" (or "UNLOCK") position, the switch inside the driver's side door lock actuator turns OFF (or ON), and the timer function of the ETACS control unit causes transistor Tr1 (or Tr2) to turn ON for 0.5 seconds. This causes the "LOCK" (or "UNLOCK") side of the door lock relay to turn ON, thereby operating the passenger's side door lock actuator.
- When the passenger's side door is locked (or unlocked) by key operation, the door key cylinder unlock switch turns ON and the switch inside the passenger's side door lock actuator turns OFF (or ON), and the timer function of the ETACS control unit causes transistor Tr1 (or Tr2) to turn ON for 0.5 seconds. This causes the "LOCK" (or "UNLOCK") side of the door lock relay to turn ON, thereby operating the driver's side door lock actuator. The driver's side door lock actuator cannot be operated by operating the passenger's side inside lock knob.
- If the driver's side door is opened and the inside lock knob is set to the "LOCK" position while the key is left inserted in the ignition switch, the timer function of the ETACS unit causes transistor Tr2 to turn ON. This causes the "UNLOCK" side of the door lock relay to turn ON, thereby unlocking all doors.


**TROUBLESHOOTING HINTS**

Phenomenon	Inspection method
One of the door lock actuators fails to operate	<ul style="list-style-type: none"> <li>Check the door actuator which fails to operate.</li> </ul>
The passenger's side door doesn't lock or unlock even if the driver's side door lock knob is operated.	<ul style="list-style-type: none"> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>
The driver's side door doesn't lock or unlock even if the passenger's side door lock knob is operated.	<ul style="list-style-type: none"> <li>Check the door key cylinder unlock switch input signal.</li> <li>Check the door key cylinder unlock switch.</li> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>
No unlock operation can be made by pressing door lock knob after fulfilment of following conditions. <ul style="list-style-type: none"> <li>Insertion of key in ignition switch (key reminder switch OFF)</li> <li>Opening of driver's side door (door switch ON)</li> </ul>	<ul style="list-style-type: none"> <li>Check the key reminder switch input signal.</li> <li>Check the key reminder switch.</li> <li>Check the driver's side door switch input signal.</li> <li>Check the driver's side door switch.</li> </ul>
Neither the central door locking function nor the key reminder function operates.	<ul style="list-style-type: none"> <li>Check the door lock actuator switch input signal.</li> <li>Check the door lock actuator switch.</li> <li>Check the door lock power relay.</li> </ul>


# AIR CONDITIONER


L. H. drive vehicles







Wire colour code  
 B:Black LG:Light green G:Green L:Blue  
 BR:Brown O:Orange GR:Gray R:Red W:White Y:Yellow  
 BB:Sky blue P:Pink V:Violet







Wire colour code  
 B:Black L:Light green G:Green  
 BR:Brown O:Orange GR:Gray R:Blue  
 R:Red P:Pink V:Yellow V:Violet SB:Sky blue












# AIR CONDITIONER


R. H. drive vehicles





Wire colour code  
 B:Black      LG:Light green      G:Green      L:Blue  
 BR:Brown      O:Orange      GR:Gray      R:Red      W:White      Y:Yellow  
 BB:Sky blue      P:Pink      V:Violet





Wire colour code


W:White C:Colour G:Green  
B:Black L:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray


L:Blue  
R:Red

W:White Y:Yellow  
P:Pink V:Violet

BB:Sky blue







### Wire colour code

B:Black

BR:Brown

G:Green  
C:Grey

GR:Gray  
L:Blue

Violet

V:Violet  
O:Orange

SB:Sky blue

LG:Light grey

P:Pink  
P:Purple

R:Red  
Y:Yellow

Y:Yellow  
W:White


W. WHITE

METER AND  
CALENDAR


**GAUGE**

10

10




## WINDSHIELD WIPER AND WASHER



## Remarks

(1) \*1: Vehicles without theft-alarm system.  
 (2) \*2: Vehicles with theft-alarm system.



## WINDSHIELD WIPER AND WASHER (See P. 4B-122.)

### OPERATION

#### Low-speed (and high-speed) wiper

- When the wiper switch is placed in the LO position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.
- Placing the wiper switch in the HI position causes the wipers to operate at high speed.

#### Intermittent wiper

- If the wiper switch is turned to the INT position when the ignition switch is in the ON or ACC position, the voltage value from the intermittent variable volume switch is input to the intermittent time detection circuit.
- The intermittent time detection circuit outputs an H signal at the intermittent time according to the set value of the intermittent variable volume switch and, via OR, turns the Tr on and off to operate the wiper.

#### Auto wiper stop

- When the wiper switch is placed in the OFF position, the cam contacts of wiper motor causes current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

#### Mist wiper

- If the washer switch is on for 0.6 second or less when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will not be poured but the transistor will be turned on to operate the wipers one time.

#### Wiper linked with washer

- If the washer switch is on for 0.6 second or more when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will be poured and the transistor will be turned on 0.6 second later to operate the wipers two or three times.

#### Low washer fluid warning lamp

- If the windshield washer fluid is below the specified level when the ignition switch is in the "ON" position, the washer fluid level sensor will be turned on to light the low washer fluid warning lamp.

### TROUBLESHOOTING HINTS

Phenomenon		Inspecting method
Wipers do not operate continuously.	Washer does not operate.	<ul style="list-style-type: none"> <li>Check the multi-purpose fuse No. ⑨</li> </ul>
	Washer operates.	<ul style="list-style-type: none"> <li>Check the wiper motor.</li> <li>Check the column switch.</li> </ul>
Low-speed (or high-speed) wiper operation only is inoperative.		<ul style="list-style-type: none"> <li>Check the column switch.</li> </ul>
Wipers do not operate intermittently. (They operate continuously.)		<ul style="list-style-type: none"> <li>Check the wiper switch "INT" input signal.</li> <li>Check the column switch.</li> </ul>
Wipers do not stop.		<ul style="list-style-type: none"> <li>Check the wiper switch "INT" input signal.</li> <li>Check the column switch.</li> <li>Check the wiper motor.</li> </ul>
The intermittent time will not vary even if the variable intermittent wiper control switch is operated.		<ul style="list-style-type: none"> <li>Check the variable intermittent wiper control switch input signal.</li> <li>Check the column switch.</li> </ul>
Even if the washer switch is on for 0.6 second or more, the washer will not operate.	The wipers linked with the washer operate.	<ul style="list-style-type: none"> <li>Check the washer motor.</li> <li>Check the washer nozzle and washer tube.</li> </ul>
	The wipers linked with the washer do not operate.	<ul style="list-style-type: none"> <li>Check the washer switch input signal.</li> <li>Check the washer switch.</li> </ul>

## REAR WIPER AND WASHER (See P. 4B-126, 127.)

### OPERATION

#### Low-speed wiper

- When the rear wiper switch is placed in the ON position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.

#### Auto wiper stop

- When the rear wiper switch is placed in the OFF position, the cam contacts of wiper motor causes current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

#### Intermittent wiper

- When the rear wiper switch is placed in the INT position with the ignition switch in ACC or ON position, the rear intermittent wiper relay is energized causing the rear intermittent wiper relay contacts to close and open repeatedly.
- When the contacts are closed, the wiper motor is energized.
- When the rear wiper motor is energized, the rear intermittent wiper relay contacts open; however, the cam contacts keep the rear wiper motor energized until the wiper blades return to their stop position.

### TROUBLESHOOTING HINTS


- Wipers do not operate.
  - Washer is not operative, either.
    - Check multi-purpose fuse No. ⑨.
    - Check earth.
- Low-speed wiper operation only is inoperative.
  - Check wiper switch.
- Wipers do not stop.
  - Check wiper motor.
  - Check rear intermittent wiper relay.
  - Check rear wiper switch.
- Intermittent wiper operation is inoperative.
  - Check terminal voltage of the rear intermittent wiper relay energized.

Terminal No.	Voltage	Check
2	0V	Rear intermittent wiper relay or rear wiper switch
	System voltage	Rear intermittent wiper relay
	0 ↔ System voltage (alternating)	— (Normal)

- Washer is inoperative.
  - Check washer motor.
  - Check washer switch.


## REAR WIPER AND WASHER

L. H. drive vehicles




# REAR WIPER AND WASHER

R. H. drive vehicles



## HEADLAMP WASHER



## HEADLAMP WASHER (See P. 4B-128.)

### OPERATION

- When the headlamp washer switch is turned ON with ignition switch in ON and lighting switch in HEAD position, the headlamp washer relay is energized causing the headlamp washer motor to start.

#### «Low washer fluid warning lamp»

- If the headlamp washer fluid is below the specified level when the ignition switch is in the "ON" position, the washer fluid level sensor will be turned on to light the low washer fluid warning lamp.

## REMOTE CONTROLLED MIRROR (See P. 4B-130, 131.)

### OPERATION

- When the remote controlled mirror switch is operated while the ignition key is in "ACC" or "ON" position, current flows through fuse No. ⑤ remote controlled mirror switch, remote controlled mirror, remote controlled mirror switch, and earth, causing the mirror to move.


### TROUBLESHOOTING HINTS

Neither right nor left mirror operates

- 1) Also cigarette lighter does not operate
  - Check multi-purpose fuse No. ⑤.
- 2) Cigarette lighter operates
  - Check remote controlled mirror switch.

## REMOTE CONTROLLED MIRROR

L. H. drive vehicles



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink


Y:Yellow

V:Violet

SB:Sky blue

## REMOTE CONTROLLED MIRROR

R. H. drive vehicles

REMOTE  
CONTROLLED  
MIRROR

Wire colour code

B:Black

LG:Light green

G:Green

I:Blue

W:White

Y:Yellow

SB:Sky blue

BR:Brown

O:Orange


GR:Gray


R:Red

P:Pink

V:Violet

## DEFOGGER





Remarks  
(1) \*4:LHD  
(2) \*5:RHD

**DEFOGGER (See P. 4B-132.)****OPERATION**

- If the defogger switch is turned to "ON" with the ignition switch at the "ON" position, the timer circuit in the ETACS control unit will be operated to keep the transistor "on" for 11 minutes to close the contact point of the defogger relay. When the defogger relay is "on", the defogger and mirror heater will be activated. Moreover, the indicator lamp of the defogger switch is lit to inform that the defogger and mirror heater are activated.
- When 11 minutes have passed, the defogger and mirror heater will stop activating even if the defogger switch is at "ON". When the defogger and mirror heater are activated (the timer is activated), they will also stop activating even if the defogger switch is set at "ON" again.

**TROUBLESHOOTING HINTS**


Phenomenon	Checking method
Mirror heater operates but defogger does not operate.	<ul style="list-style-type: none"> <li>Check the defogger</li> </ul>
Defogger operates but mirror heater does not operate.	<ul style="list-style-type: none"> <li>Check the dedicated fuse No. ⑩.</li> <li>Check the mirror heater.</li> </ul>
Neither defogger nor mirror heater operates.	<ul style="list-style-type: none"> <li>Check the multi-purpose fuse No. ③.</li> <li>Check the defogger relay.</li> <li>Check the defogger switch.</li> <li>Check the defogger switch input signal.</li> <li>Check the ignition switch input signal.</li> </ul>
Illumination lamp of defogger switch does not come on or is dim.	<ul style="list-style-type: none"> <li>Check the illumination lamp bulb.</li> <li>Check the rheostat.</li> </ul>


---

**NOTES**

## RADIO AND TAPE PLAYER


L. H. drive vehicles






## RADIO AND TAPE PLAYER


R. H. drive vehicles






**Wire colour code**  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

## CLOCK





## CIGARETTE LIGHTER




## ANTI-LOCK BRAKE SYSTEM (ABS)

L.H. drive vehicles





Wire colour code  
 B:Black    LG:Light green    G:Green  
 BR:Brown    O:Orange    GR:Gray  
 L:Blue    W:White    Y:Yellow  
 R:Red    P:Pink    V:Violet  
 SB:Sky blue



### Wire colour code

B:Black LG:Light  
DP:Dark

BR:Brown

KX35-AC-R1537A-EC

BR:Brown

© Mitsubishi Motors Corporation Jul. 1994

PHUE9201-C

R:Red

— 1 —

P

— 1 —

Pink

— 1 —

V:VI

— 1 —

10  
let

— 1 —


3B: SKY STUD

— 1 —

**ADDED**

# ANTI-LOCK BRAKE SYSTEM (ABS)


R. H. drive vehicles



ABS  
CONTROL  
UNIT

E-10

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	




Wire colour code  
B:Black  
BR:Brown  
LG:Light green  
O:Orange

G:Green  
GR:Gray

L:Blue  
R:Red


W:White  
P:Pink  
Y:Yellow  
V:Violet

SB:Sky blue



# ELECTRONIC CONTROL SUSPENSION (ECS) SYSTEM

L. H. drive vehicles



C-74

F-19

Wire colour code

B:Black BR:Brown

LG:Light green O:Orange


G:Green GR:Gray

L:Blue  
R:Red


W:White  
P:Pink


Y:Yellow  
V:Violet

SB:Sky blue




# 4B-150 CIRCUIT DIAGRAM — Electronic Control Suspension (ECS) System







## **FRONT SHOCK ABSORBER (LH)**



#### FRONT SHOCK ABSORBER (RH)



## **ELECTRONIC CONTROL SUSPENSION CONTROL UNIT**



**REAR SHOCK  
ABSORBER (LH)**



**REAR SHOCK  
ABSORBER (RH)**



### Wire colour code

Wire colour code  
B:Black LG:Light green G:Green  
BR:Brown O:Orange GR:Gray


L:Blue  
R:Red


W:White Y:Yellow  
P:Pink V:Violet


SB:Sky blue

# ELECTRONIC CONTROL SUSPENSION (ECS) SYSTEM


R. H. drive vehicles









# 4B-156 CIRCUIT DIAGRAM — Electronic Control Suspension (ECS) System





FRONT SHOCK ABSORBER (LH)



FRONT SHOCK ABSORBER (RH)





ELECTRONIC  
CONTROL  
SUSPENSION  
CONTROL UNIT




## ACTIVE AERO SYSTEM

L.H. drive vehicles with theft-alarm system








## ACTIVE AERO SYSTEM

L.H. drive vehicles without theft-alarm system



### Wire colour code


B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GP:Gray

L:Blue  
B:Red

W:White Y:Yellow  
P:Pink V:Violet


SB:Sky blue





## ACTIVE AERO SYSTEM

R.H. drive vehicles with theft-alarm system



### Wire colour code

B:Black  
BB:Brown

BR:Brown

G:Light green

## ①:Orange

G:Green  
GR:Gray

L:Blue


R:Red

W:White  
P:Pink

V:Violet

SB:Sky blue

SB:DRY, B100



### Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray

L:Blue  
R:Red

W:White  
P:Pink


W:White Y:Yellow  
P:Pink V:Violet


SB:Sky blue



## ACTIVE AERO SYSTEM

R. H. drive vehicles without theft-alarm system





#### Wire colour code


B:Black LG:Light  
BR:Brown O:Orange

reen G:Green  
GR:Gray

L:Blue  
R:Red

W:White Y:Yellow  
P:Pink V:Violet


SB:Sky blue



## SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

L. H. drive vehicles

STARTER RELAY IGNITION SWITCH (ST)



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red


W:White

P:Pink

Y:Yellow

V:Violet

SB:Sky blue




**CAUTION**

**CAUTION** • Carefully read and observe the SRS SERVICE PRECAUTIONS (Refer to WORKSHOP MANUAL (Pub. No. PWUE9119) SRS Service Precautions) prior to any service.

## SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

R.H. drive vehicles

STARTER RELAY IGNITION SWITCH(ST)




Wire colour code

KX35-AC-R1546-EC

B:Black  
BR:Brown  
LG:Light green  
O:OrangeG:Green  
GR:GrayL:Blue  
R:RedW:White  
P:PinkY:Yellow  
V:Violet


SB:Sky blue



**CAUTION**  
Carefully read and observe the SRS SERVICE PRECAUTIONS (Refer to WORKSHOP MANUAL (Pub. No. PWUE9119) SRS Service Precautions) prior to any service.

# AUTO-CRUISE CONTROL SYSTEM

## L. H. drive vehicles



#### Wire colour code

B:Black LG:Light green  
BR:Brown O:Orange


G:Green  
GR:Gray


L:Blue  
R:Red


W:White  
P:Pink

Y:Yellow  
V:Violet

SB:Sky blue







## AUTO-CRUISE CONTROL UNIT

G-30

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

D-43

329451M10900C

Wire colour codes  
B:Black LG:Li  
BR:Brown D:D

Wire colour code  
B:Black LG:Light green G:Green L:Blue W:White Y:Yellow BB:Sky blue  
BP:Brown OG:Orange GR:Grey LD:Dad D:Dark R:Red V:Violet


**KX35-AC-R1547B-EC**

BR:Brown

PHILIPS

## AUTO-CRUISE CONTROL SYSTEM

R. H. drive vehicles



Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red


W:White


P:Pink


Y:Yellow

V:Violet

BB:Sky blue





AUTO-CRUISE  
CONTROL UNIT

C-30


1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


D-43

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

## POWER SEAT

L. H. drive vehicles





Wire colour code

B:Black

BR:Brown

LG:Light green

O:Orange

G:Green

GR:Gray

L:Blue

R:Red

W:White

P:Pink


Y:Yellow


V:Violet

SB:Sky blue

## POWER SEAT

R. H. drive vehicles





Wire colour code

B:Black BR:Brown

LG:Light green O:Orange

G:Green GR:Gray


L:Blue R:Red


W:White P:Pink Y:Yellow V:Violet


SB:Sky blue


## THEFT-ALARM SYSTEM

L. H. drive vehicles













## THEFT-ALARM SYSTEM

R. H. drive vehicles









---

## NOTES

## INDEX (In order of connector No.)

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
A	A-01X Headlamp relay	4B-10, 13, 18, 46, 50, 54, 56, 66	2B-4, 6
	A-02X —	4B-10	—
	A-03X —	4B-10	—
	A-04X Radiator fan motor relay (LO)	4B-10, 42, 44, 106, 114	2B-4, 6
	A-05X Tail lamp relay	4B-10, 13, 18, 46, 60, 62	2B-4, 6
	A-06X Horn relay	4B-10, 16, 91, 92, 189, 193	2B-4, 6
	A-07X Radiator fan motor relay (HI)	4B-10, 42, 44, 106, 114	2B-4, 6
	A-08X —	4B-10	—
	A-09X Starter relay	4B-10, 22, 23, 188, 192	2B-4, 6
	A-10X Alternator relay	4B-10, 27	2B-4, 6
	A-11X Storage connector	4B-10, 14, 15, 19, 20, 22, 23, 30, 35, 36, 41, 74, 76, 78, 80, 102, 110, 118, 122, 132, 136, 138, 140, 144, 147, 148, 153, 158, 161, 164, 167, 170, 172, 175, 176, 179, 180, 186, 190	2B-4, 6
	A-12 ABS front speed sensor (RH)	4B-144, 147	2B-4, 6
	A-13 Side turn signal lamp (RH)	4B-83, 85	2B-4, 6
	A-14 Control wiring harness and ECS front shock absorber joint wiring harness (RH) combination	4B-152, 157	2B-4, 6
	A-15 Washer fluid level sensor	4B-123	2B-4, 6
	A-16 Windshield wiper motor	4B-123	2B-4, 6
	A-17 Engine speed detection connector	4B-26	2B-4, 6
	A-18 Fuel pump check connector	4B-31, 37	2B-4, 6
	A-19 Ignition timing adjustment connector	4B-26, 35, 41	2B-4, 6
	A-20 Windshield washer motor	4B-123	2B-4, 6
	A-21 Resistor	4B-33, 39	2B-4, 6
	A-22 Control wiring harness and solenoid valve wiring harness combination	4B-35, 41	2B-4, 6
	A-23 Waste gate solenoid valve	4B-35, 41	2B-4, 6
	A-24 Fuel pressure solenoid valve	4B-35, 41	2B-4, 6
	A-25 Purge control solenoid valve	4B-35, 41	2B-4, 6
	A-26 EGR control solenoid valve	4B-35, 41	2B-4, 6
	A-27 Brake fluid level sensor	4B-97	2B-4, 6
	A-28 Front wiring harness and ECS front shock absorber joint wiring harness (LH) combination	4B-152, 157	2B-4, 6
	A-29 Side turn signal lamp (LH)	4B-83, 85	2B-4, 6
	A-30 Auto-cruise vacuum pump	4B-177, 181	2B-4, 6
	A-31 } Theft-alarm horn	4B-91, 189, 193	2B-4, 6
	A-32 } Theft-alarm horn	4B-91, 189, 193	2B-4, 6
	A-33 ABS front speed sensor (LH)	4B-144, 147	2B-4, 6
	A-34 4WS fluid level sensor	4B-96	2B-4, 6
	A-35 —	—	—
	A-36 Daytime running lamp relay <LHD>	4B-46	2B-4
	A-37 Daytime running lamp control unit <LHD>	4B-47, 60, 67, 112	2B-4
	A-38 } Diode (for headlamp circuit) <RHD>	4B-55, 57	2B-7
	A-39 } Diode (for headlamp circuit) <RHD>	4B-55, 56	2B-7
	A-40 } Diode (for headlamp circuit) <RHD>	4B-55, 56	2B-7
	A-41 } Diode (for headlamp circuit) <RHD>	4B-55, 57	2B-7
	A-42 Resistor <Vehicles with dim-dip lamp>	4B-55, 57	2B-7
	A-43 Joint connector <Vehicles with dim-dip lamp>	4B-55, 56	2B-7
	A-44X Condenser fan motor relay (HI)	4B-10, 43, 45, 107, 115	2B-4, 7
	A-45X —	4B-10	—
	A-46X Magnetic clutch relay	4B-10, 108, 116	2B-4, 7
	A-47X Condenser fan motor relay (LO)	4B-10, 43, 45, 107, 115	2B-4, 7
	A-48 Dual pressure switch	4B-108, 116	2B-4, 7
	A-49 } A/C relay box	4B-43, 45, 107, 115	2B-4, 7
	A-50 } A/C relay box	4B-16, 21, 34, 40, 43, 45, 107, 108, 115, 116	2B-4, 7

## INDEX (In order of connector No.)

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
A	A-51	SRS front impact sensor (LH)	4B-170, 172	2B-4, 7
	A-52	Front turn signal lamp (LH)	4B-83, 85	2B-4, 7
	A-53	Inspection lamp switch	4B-72	2B-5, 7
	A-54	Headlamp (LH: HI)	4B-46, 50, 54, 56	2B-5, 7
	A-55	Headlamp leveling unit (LH)	4B-58	2B-5, 7
	A-56	—	—	—
	A-57	—	—	—
	A-58	—	—	—
	A-59	Condenser fan motor	4B-43, 45, 107, 115	2B-5, 7
	A-60	—	4B-43, 45, 107, 115	2B-5, 7
	A-61	—	4B-91, 92, 189, 193	2B-5, 7
	A-62	Horn	4B-91, 92, 189, 193	2B-5, 7
	A-63	—	4B-91, 92, 189, 193	2B-5, 7
	A-64	—	4B-91, 92, 189, 193	2B-5, 7
	A-65	Fuel pump resistor	4B-31, 37	2B-5, 7
	A-66	Radiator fan motor	4B-42, 44, 106, 114	2B-5, 7
	A-67	Headlamp washer motor	4B-128	2B-5, 7
	A-68	Engine coolant level sensor	4B-42, 44	2B-5, 7
	A-69	Active aero front venturi skirt	4B-160, 163, 166, 169	2B-5, 7
	A-70	—	—	—
	A-71	—	—	—
	A-72	—	—	—
	A-73	Headlamp leveling unit (RH)	4B-58	2B-5, 7
	A-74	Headlamp (RH: HI)	4B-46, 50, 54, 56	2B-5, 7
	A-75	Front turn signal lamp (RH)	4B-83, 85	2B-5, 7
	A-76	SRS front impact sensor (RH)	4B-170, 172	2B-5, 7
	A-77	ABS hydraulic unit	4B-142, 145	2B-5, 7
	A-78	—	4B-142, 145	2B-5, 7
	A-79	Hood switch <Vehicles with theft-alarm system>	4B-188, 192	2B-5, 7
	A-80	Front wiring harness and control wiring harness combination	4B-22, 23, 24, 30, 34, 36, 40, 44, 72, 108, 114, 116, 170, 172, 188, 192	2B-5, 7
	A-81	Dim-dip lamp relay 1 or no connection	4B-55, 57	2B-7
	A-82	Dim-dip lamp relay 2, 3 or jumper connector	4B-54, 56	2B-7
	A-83	—	4B-54, 56	2B-7
	A-84	Diode (for ABS circuit)	4B-142, 145	2B-5, 7
	A-85	No connection	—	2B-5
	A-86	Inspection lamp	4B-72	2B-5, 7
	A-87	ECS front shock absorber (RH)	4B-152, 157	2B-5, 7
	A-88	ECS front shock absorber (LH)	4B-152, 157	2B-5, 7
	A-89	Position lamp (LH)	4B-61, 63	2B-5, 7
	A-90	Position lamp (RH)	4B-61, 63	2B-5, 7
	A-91	Headlamp (LH: LO)	4B-46, 50, 54, 56	2B-5, 7
	A-92	Headlamp (RH: LO)	4B-46, 50, 54, 56	2B-5, 7
	A-93	No connection	—	2B-5, 7
B	B-01	Engine coolant temperature gauge unit	4B-95	2B-8
	B-02	Engine coolant temperature sensor	4B-32, 38	2B-8
	B-03	—	—	—
	B-04	—	—	—
	B-05	Throttle position sensor	4B-32, 38, 149, 154, 175, 179	2B-8
	B-06	Control wiring harness and oil pressure wiring harness combination	4B-35, 41, 95, 98	2B-8
	B-07	Control wiring harness and injector wiring harness combination	4B-33, 39	2B-8
	B-08	Detonation sensor	4B-32, 38	2B-8
	B-09	Injector No. 5	4B-33, 39	2B-8
	B-10	Injector No. 3	4B-33, 39	2B-8
	B-11	Oxygen sensor (LH)	4B-33, 39	2B-8

	Connector No.	Parts name	Circuit diagram page	Wiring diagram page
B	B-12	Injector No. 1	4B-33, 39	2B-8
	B-13	Ignition coil	4B-26	2B-8
	B-14	Noise capacitor	4B-26	2B-8
	B-15	} Alternator	4B-27	2B-8
	B-16		4B-27	2B-8
	B-17	Oxygen sensor (RH)	4B-33, 39	2B-8
	B-18	Magnetic clutch	4B-108, 116	2B-8
	B-19	} Power transistor	4B-26	2B-9
	B-20		4B-26	2B-9
	B-21	} Starter motor	4B-22, 23, 24, 188, 192	2B-9
	B-22		4B-22, 23, 24, 188, 192	2B-9
	B-23	Back-up lamp switch	4B-89	2B-9
	B-24	Fuel pump relay	4B-31, 37	2B-9
	B-25	Air flow sensor (with intake air temperature sensor and atmospheric sensor)	4B-32, 38	2B-9
	B-26	Control wiring harness and battery cable combination	4B-22, 23, 24, 188, 192	2B-9
	B-27	Injector No. 2	4B-33, 39	2B-9
	B-28	Injector No. 4	4B-33, 39	2B-9
	B-29	Injector No. 6	4B-33, 39	2B-9
	B-30	Speed sensor	4B-33, 39, 95	2B-9
	B-31	Idle speed control servo (stepper motor)	4B-33, 39	2B-9
	B-32	Engine oil level sensor	4B-98	2B-9
	B-33	Oil pressure gauge unit	4B-95	2B-9
	B-34	Oil pressure switch	4B-98	2B-9
	B-35	Power steering oil pressure switch	4B-35, 41	2B-9
	B-36	Cam position sensor	4B-32, 38	2B-9
	B-37	Crank angle sensor	4B-32, 38	2B-9
C	C-01	} Body wiring harness (main) and front wiring harness combination	4B-22, 48, 51, 55, 56, 60, 62, 67, 69, 83, 91, 92, 108, 112, 116, 157, 177, 181, 188, 189, 193	2B-10, 12
	C-02		4B-160, 163	2B-10
	C-03		4B-13, 16, 18, 21, 27, 46, 50, 54, 56, 100, 132, 182, 184	2B-10, 12
	C-04X	Door lock power relay	4B-10, 102	2B-10, 12
	C-05X	Rear fog lamp relay	4B-10, 66, 68, 70	2B-10, 12
	C-06X	Defogger relay	4B-10, 21, 132	2B-10, 12
	C-07X	Power window relay	4B-10, 100, 182, 184	2B-10, 12
	C-08	-	-	-
	C-09	} Column switch	4B-48, 51, 55, 57, 60, 62, 67, 69, 71, 83, 85, 128	2B-10, 12
	C-10		4B-122	2B-10, 12
	C-11	-	-	-
	C-12	Control wiring harness and instrument panel wiring harness combination	4B-31, 37, 95, 98, 123, 151, 156, 159, 162, 165, 168, 176, 180	2B-10, 12
	C-13	Body wiring harness (main) and instrument panel wiring harness combination	4B-97, 111, 112, 119, 120, 137, 139, 141, 159, 162, 165, 168, 171, 173, 174, 178	2B-10, 12
	C-14	Blend air damper control motor	4B-113, 121	2B-10, 12
	C-15	Mode selection damper control motor	4B-113, 121	2B-10, 12
	C-16	} A/C control panel	4B-111, 113, 119, 121	2B-10, 12
	C-17		4B-112, 120	2B-10, 12
	C-18	Power transistor (for A/C circuit)	4B-110, 118	2B-10, 12
	C-19	Air-inlet sensor	4B-112, 120	2B-10, 12
	C-20	Air selection damper control motor	4B-111, 119	2B-10, 12
	C-21	} Body wiring harness (main) and control wiring harness combination	4B-30, 34, 35, 36, 40, 41, 42, 89, 106, 108, 116, 123, 149, 154, 175, 179, 180	2B-10, 12
	C-22		4B-31, 37, 89, 170, 172, 175, 179	2B-10, 12

## INDEX (In order of connector No.)

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C-23	Body wiring harness (main) and front wiring harness combination	4B-128	2B-10, 12
C-24		4B-22, 23, 24, 27, 30, 34, 36, 42, 48, 51, 55, 56, 63, 71, 106, 160, 163, 170, 172, 188, 192	2B-10, 12
C-25	Body wiring harness (sub) and front wiring harness combination <LHD>	4B-142	2B-10, 12
C-26		4B-31, 61, 144, 152	2B-10, 12
C-27	Body wiring harness (main) and body wiring harness (sub) combination <LHD>	4B-75, 78, 137, 142, 144, 188	2B-10, 12
C-28	Foot lamp (RH)	4B-74, 76	2B-10, 12
C-29	Body wiring harness (sub) and control wiring harness combination <LHD>	4B-152	2B-10, 12
C-30	Auto-cruise control unit	4B-175, 176, 177, 179, 180, 181	2B-10, 12
C-31	Blower motor	4B-110, 118	2B-10, 12
C-32	Blower motor relay (HI)	4B-110, 118	2B-10, 12
C-33	A/C compressor lock controller	4B-109, 117	2B-10, 12
C-34	Air-thermo sensor	4B-112, 120	2B-10, 12
C-35	Engine coolant temperature sensor	4B-112, 120	2B-11, 12
C-36	Engine control relay	4B-30, 36	2B-11, 12
C-37		4B-109, 110, 111, 112, 113, 117, 118, 119, 120, 121	2B-11, 12
C-38	A/C control unit	4B-34, 40, 109, 110, 111, 113, 117, 118, 119, 121	2B-11, 12
C-39		4B-111, 112, 113, 119, 120, 121	2B-11, 12
C-40	Lighting monitor buzzer	4B-61, 63	2B-11, 13
C-41	Headlamp washer relay	4B-128	2B-11, 13
C-42	Engine oil level relay	4B-98	2B-11, 13
C-43		4B-26, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 108, 116	2B-11, 13
C-44	Engine control unit	4B-26, 30, 31, 32, 34, 35, 36, 37, 38, 40, 41, 42, 44, 106, 108, 114, 116	2B-11, 13
C-45		4B-30, 32, 33, 36, 38, 39, 149, 154, 175, 179	2B-11, 13
C-46	Auto-cruise control relay	4B-177, 181	2B-11, 13
C-47	Steering wheel angle speed sensor	4B-151, 156	2B-11, 13
C-48	Clock spring	4B-91, 92, 175, 179, 189, 193	2B-11, 13
C-49	No connection	4B-34, 87, 143, 148, 177	2B-11
C-50	Stop lamp switch	4B-34, 40, 87, 88, 143, 146, 148, 153, 177, 181	2B-11, 13
C-51	Key reminder switch	4B-22, 23, 74, 76, 103, 158, 163, 164, 169, 186, 190	2B-11, 13
C-52	Ignition switch	4B-15, 20	2B-11, 13
C-53	Clutch pedal switch	4B-175, 179	2B-11, 13
C-54	ETACS control unit	4B-22, 23, 75, 77, 103, 122, 132, 187, 188, 189, 191, 192, 193	2B-11, 13
C-55		4B-75, 77, 91, 103, 122, 132, 186, 187, 188, 189, 190, 191, 192, 193	2B-11, 13
C-56	Foot lamp (LH)	4B-74, 76	2B-11, 13
C-57	Diode (for headlamp circuit) <LHD>	4B-48, 51, 67	2B-11
C-58	—	—	—
C-59	Body wiring harness (main) and front wiring harness combination <RHD>	4B-145, 147	2B-13
C-60	Body wiring harness (main) and control wiring harness combination <RHD>	4B-157	2B-13
C-61	Body wiring harness (main) and body wiring harness (sub) combination <RHD>	4B-77, 80, 138, 165, 168, 169, 192	2B-13
C-62		4B-89, 121	2B-13
C-63		4B-133	2B-13
C-64	Body wiring harness (sub) and front wiring harness combination <RHD>	4B-166, 169	2B-13

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
C-65		4B-4, 5, 14, 19, 22, 23, 30, 35, 36, 41, 66, 68, 70, 74, 76, 78, 80, 87, 88, 91, 102, 110, 118, 122, 132, 136, 138, 140, 143, 144, 146, 147, 148, 153, 158, 161, 164, 167, 170, 172, 176, 180, 186, 189, 190, 193	2B-11, 13
C-66	Front wiring harness and junction block combination	4B-4, 5, 14, 19, 34, 40, 42, 47, 55, 57, 58, 60, 61, 63, 66, 68, 70, 72, 82, 84, 85, 94, 106, 114, 120, 126, 127, 133, 136, 138, 140, 141, 143, 146, 149, 154, 158, 161, 164, 167, 174, 178	2B-11, 13
C-67		4B-4, 5, 14, 15, 19, 20, 22, 23, 30, 35, 36, 41, 74, 76, 78, 80, 102, 110, 118, 122, 132, 136, 138, 140, 144, 147, 148, 153, 158, 161, 164, 167, 170, 172, 175, 176, 179, 180, 186, 190	2B-11, 13
C-68	Instrument panel adapter wiring harness and junction block combination	4B-4, 5, 26, 27, 30, 31, 36, 37, 42, 44, 58, 66, 67, 68, 69, 70, 71, 72, 79, 81, 82, 83, 84, 85, 94, 96, 123, 126, 127, 128, 133, 140, 143, 146, 149, 154, 158, 161, 164, 167, 171, 173, 174, 178, 186, 190	2B-11, 13
C-69	Theft-alarm horn relay	4B-4, 5, 91, 189, 193	2B-11, 13
C-70	Diagnosis connector	4B-35, 41, 75, 77, 78, 80, 103, 111, 119, 122, 132, 144, 147, 150, 155, 159, 162, 165, 168, 171, 173, 176, 180, 188, 192	2B-11, 13
C-71	Blower motor relay	4B-4, 5, 110, 118	2B-11, 13
C-72	Roof wiring harness and junction block combination	4B-4, 5, 74, 76	2B-11, 13
C-73		4B-4, 5, 48, 50, 51, 54, 55, 56, 57, 91, 189, 193	2B-11, 13
C-74		4B-4, 5, 30, 36, 74, 76, 85, 89, 102, 110, 118, 136, 138, 148, 153, 171, 173, 174, 176, 178, 180, 186, 190	2B-11, 13
C-75		4B-4, 5, 48, 51, 55, 57, 60, 62, 66, 67, 68, 69, 70, 71, 91, 102, 128, 136, 138, 183, 185, 189, 193	2B-11, 13
C-76		4B-4, 5, 61, 63, 75, 77, 91, 122, 132, 136, 138, 141, 158, 161, 164, 167, 187, 189, 191, 193	2B-11, 13
C-77	Body wiring harness (main) and junction block combination	4B-4, 5, 22, 23, 74, 76, 79, 81, 83, 85, 102, 126, 127, 130, 131, 136, 138, 141, 158, 161, 164, 167, 186, 190	2B-11, 13
C-78		4B-4, 5, 15, 20, 26, 27, 31, 37, 42, 44, 47, 48, 50, 51, 54, 55, 56, 57, 60, 61, 62, 63, 66, 67, 69, 71, 75, 77, 82, 84, 89, 94, 96, 100, 106, 110, 114, 118, 122, 123, 126, 127, 128, 130, 131, 132, 136, 138, 140, 141, 143, 146, 148, 153, 158, 161, 164, 167, 171, 173, 174, 175, 178, 179, 182, 183, 184, 185, 187, 191	2B-11, 13
C-79		4B-4, 5, 15, 30, 34, 35, 36, 40, 41, 61, 63, 74, 76, 78, 80, 87, 88, 100, 102, 106, 110, 114, 118, 120, 122, 123, 128, 132, 136, 138, 141, 143, 144, 146, 147, 148, 153, 158, 161, 164, 167, 170, 172, 174, 175, 176, 178, 179, 180, 182, 184, 186, 190	2B-11, 13
C-80	—	—	—
C-81	—	—	—
C-82	—	—	—
C-83	No connection	—	2B-11
C-84	—	—	—
C-85	Air bag module (Passenger's side)	4B-170, 172	2B-11, 13
C-86	Front wiring harness and control wiring harness combination	4B-33, 39	2B-11, 13
C-87	Body wiring harness (main) and body wiring harness (sub) combination	—	2B-11, 13
C-88	No connection	—	2B-11, 13

## INDEX (In order of connector No.)

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
D-01	Rear fog lamp switch	4B-66, 68, 70	2B-14, 16
D-02	Front speaker (LH)	4B-137, 139	2B-14, 16
D-03		4B-31, 37, 94, 98, 150, 155	2B-14, 16
D-04		4B-27, 31, 37, 42, 44, 46, 50, 54, 56, 67, 69, 71, 79, 81, 83, 85, 94, 96, 97, 123, 128, 143, 146, 160, 163, 166, 169, 171, 173, 177, 181, 186, 190	2B-14, 16
D-05	Combination meter	4B-27, 42, 44, 67, 69, 71, 83, 85, 94, 98, 123, 128, 160, 163, 166, 169, 171, 173, 177, 181	2B-14, 16
D-06	Defogger switch and ECS switch	4B-133, 150, 155	2B-14, 16
D-07	Hazard switch	4B-82, 84	2B-14, 16
D-08	Clock	4B-140	2B-14, 16
D-09	Combination gauge	4B-31, 37, 95	2B-14, 16
D-10	Diode (for 4WS fluid level warning lamp circuit)	4B-96	2B-14, 16
D-11	Glove box lamp	4B-72	2B-14, 16
D-12	Photo sensor	4B-111, 119	2B-14, 16
D-13	Front speaker (RH)	4B-137, 139	2B-14, 16
D-14	Glove box lamp switch	4B-72	2B-14, 16
D-15	Instrument panel wiring harness and control wiring harness combination	4B-26, 30, 36, 72, 94, 95, 96, 98, 109, 117	2B-14, 16
D-16	Instrument panel wiring harness and body wiring harness (sub) combination	4B-94, 97, 126, 127, 143, 150, 166, 169	2B-14, 16
D-17	Ashtray illumination lamp	4B-141	2B-14, 16
D-18	} Cigarette lighter	4B-141	2B-14, 16
D-19		4B-141	2B-14, 16
D-20	Cigarette lighter illumination lamp	4B-141	2B-14, 16
D-21	Power seat switch	4B-182, 184	2B-14, 16
D-22	Body wiring harness (main) and console wiring harness combination	4B-97, 141, 142, 145	2B-14, 16
D-23	} SRS diagnosis unit	4B-170, 171, 172, 173	2B-14, 16
D-24		4B-170, 172	2B-14, 16
D-25	—	—	—
D-26	SRS diagnosis unit	4B-171, 173	2B-14, 16
D-27	ABS G sensor	4B-142, 145	2B-15, 17
D-28	Parking brake switch	4B-97	2B-15, 17
D-29	Active aero switch	4B-159, 162, 165, 168	2B-15, 17
D-30	} Accessory socket	4B-141	2B-15
D-31		4B-141	2B-15
D-32	Auto-cruise main switch	4B-174, 178	2B-15, 17
D-33	—	—	—
D-34	—	—	—
D-35	} Radio and tape player	4B-136, 137, 138, 139	2B-15, 17
D-36		4B-136, 137, 138, 139	2B-15, 17
D-37	Rear wiper and washer switch	4B-126, 127	2B-15, 17
D-38	Headlamp leveling switch	4B-58	2B-15, 17
D-39	No connection	4B-94	2B-15, 17
D-40	Remote controlled mirror switch	4B-130, 131	2B-15, 17
D-41	Rheostat	4B-95	2B-15, 17
D-42	} Instrument panel wiring harness and body wiring harness (main) combination	4B-79, 81, 82, 84, 130, 155 4B-66, 67, 68, 69, 70, 71, 94, 97, 109, 117, 126, 127, 130, 133, 137, 146, 151, 156, 159, 160, 162, 163, 165, 168, 176, 177, 180, 181, 186, 190	2B-15, 17
D-43		4B-58, 67, 69, 71, 82, 83, 84, 85, 95, 96, 126, 127, 130, 133, 140, 150, 155, 177, 181	2B-15, 17
D-44		4B-58, 67, 69, 71, 82, 83, 84, 85, 95, 96, 126, 127, 130, 133, 140, 150, 155, 177, 181	2B-15, 17

# INDEX (In order of connector No.)

7

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
D	D-45 Instrument panel wiring harness and instrument panel adapter wiring harness combination	4B-26, 27, 30, 31, 36, 37, 42, 44, 58, 66, 67, 68, 69, 70, 71, 72, 79, 81, 82, 84, 85, 94, 96, 123, 126, 127, 128, 133, 140, 143, 146, 149, 154, 158, 161, 164, 167, 171, 173, 174, 178, 186, 190	2B-15, 17
	D-46 Instrument panel wiring harness and front wiring harness combination	4B-27, 42, 44, 46, 47, 50, 54, 56, 58, 66, 68, 70, 72, 83, 95, 96, 97, 98, 128, 143, 146	2B-15, 17
	D-47 —	—	—
	D-48 —	—	—
	D-49 —	—	—
E	D-50 No connection	—	2B-15, 17
	E-01 Body wiring harness (main) and door wiring harness (RH) combination	4B-78, 80, 100, 104, 130, 131, 137, 139, 187, 191	2B-18, 20
	E-02 Door mirror (Passenger's side)	4B-130, 131	2B-18, 20
	E-03 Door speaker (Passenger's side)	4B-137, 139	2B-18, 20
	E-04 Room lamp	4B-74	2B-18, 20
E	E-05 Power window sub switch	4B-100	2B-18, 20
	E-06 Power window motor (Passenger's side)	4B-100	2B-18, 20
	E-07 Door lamp (Passenger's side)	4B-78, 80	2B-18, 20
	E-08 Door key cylinder unlock switch (Passenger's side)	4B-104, 187, 191	2B-18, 20
	E-09 Door lock actuator (Passenger's side)	4B-104, 187, 191	2B-18, 20
	E-10 ABS control unit	4B-142, 144, 145, 147	2B-18, 20
	E-11 ABS resistor	4B-143, 146	2B-18, 20
	E-12 Door switch (Passenger's side)	4B-75, 77, 78, 80, 188, 192	2B-18, 20
	E-13 ABS rear speed sensor (RH)	4B-144, 147	2B-18, 20
	E-14 Rear intermittent wiper relay	4B-126, 127	2B-18, 20
	E-15 ABS rear speed sensor (LH)	4B-144, 147	2B-18, 20
	E-16 Door switch (Driver's side)	4B-61, 63, 75, 77, 78, 80, 103, 188, 192	2B-18, 20
	E-17 Door lock actuator (Driver's side)	4B-104, 187, 191	2B-18, 21
	E-18 Door key cylinder unlock switch (Driver's side) <Vehicles with theft-alarm system>	4B-104, 187, 191	2B-19, 21
	E-19 Door lamp (Driver's side)	4B-78, 80	2B-19, 21
	E-20 Power seat assembly	4B-182, 183, 184, 185	2B-19, 21
	E-21 ECS G sensor	4B-151, 156	2B-19, 21
	E-22 Door speaker (Driver's side)	4B-137, 139	2B-19, 21
E	E-23 Turn signal and hazard flasher unit	4B-82, 84	2B-19, 21
	E-24 Diode (for MPI circuit)	4B-34, 40	2B-19, 21
	E-25 Jumper connector	4B-34	2B-19
	E-26 Body wiring harness (main) and door wiring harness (LH) combination	4B-78, 80, 100, 104, 130, 131, 137, 139, 187, 191	2B-19, 21
	E-27 Door mirror (Driver's side)	4B-130, 131	2B-19, 21
	E-28 Power window main switch	4B-100	2B-19, 21
	E-29 Power window motor (Driver's side)	4B-100	2B-19, 21
	E-30 —	—	2B-21
	E-31 } No connection	—	2B-19
	E-32 }	—	2B-19
	E-33 —	—	—
	E-34 —	—	—
	E-35 —	—	—
	E-36 —	—	—
	E-37 } No connection	—	2B-19, 21
	E-38 }	—	2B-19, 21
F	F-01 Interior temperature sensor	4B-113, 121	2B-22
	F-02 Defogger (+)	4B-133	2B-22
	F-03 Rear wiper motor	4B-126, 127	2B-22
	F-04 Active aero rear spoiler	4B-87, 160, 163, 166, 169	2B-22
	F-05 Defogger (-)	4B-133	2B-22
	F-06 Rear speaker (RH)	4B-137, 139	2B-22

## INDEX (In order of connector No.)

Connector No.	Parts name	Circuit diagram page	Wiring diagram page
F-07	Body wiring harness (sub) <LHD> or (main) <RHD> and ECS rear shock absorber joint wiring harness (RH) combination	4B-152, 157	2B-22
F-08	Luggage compartment lamp	4B-79, 81	2B-22
F-09	Rear combination lamp (RH)	4B-61, 63, 67, 69, 71, 83, 85, 87, 88	2B-22
F-10	Back-up lamp (RH)	4B-89	2B-22
F-11	{ ECS control unit	4B-149, 150, 151, 152, 154, 155, 156, 157	2B-22
F-12		4B-150, 152, 155, 157	2B-22
F-13	Body wiring harness (sub) <LHD> or (main) <RHD> and fuel tank wiring harness combination	4B-31, 37, 94, 97	2B-22
F-14	Rear washer motor	4B-126, 127	2B-22
F-15	Fuel tank	4B-31, 37, 94, 97	2B-22
F-16	Licence plate lamp (RH)	4B-61, 63	2B-22
F-17	Body wiring harness (sub) <LHD> or (main) <RHD> and rear bumper wiring harness combination	4B-61, 63, 89	2B-22
F-18	{ Body wiring harness (main) and body wiring harness (sub) combination	4B-63, 71, 79, 81, 83, 85, 87, 88, 89, 127, 137, 138, 143, 148, 193	2B-22
F-19		4B-67, 69, 148, 149, 150, 151, 152, 156, 157	2B-22
F-20	Licence plate lamp (LH)	4B-61, 63	2B-22
F-21	Luggage compartment lamp switch	4B-79, 81	2B-22
F-22	Tailgate cylinder lock switch <Vehicles with theft-alarm system>	4B-189, 193	2B-22
F-23	Tailgate switch <Vehicles with theft-alarm system>	4B-189, 193	2B-22
F-24	Buck-up lamp (LH)	4B-89	2B-22
F-25	{ Active aero control unit	4B-159, 160, 162, 163, 165, 166, 168, 169	2B-22
F-26		4B-159, 160, 162, 163, 165, 166, 168, 169	2B-22
F-27	Rear combination lamp (LH)	4B-61, 63, 67, 69, 71, 83, 85, 87, 88	2B-22
F-28	Motor antenna control unit	4B-136, 138	2B-22
F-29	Body wiring harness (main) <LHD> or (sub) <RHD> and ECS rear shock absorber joint wiring harness (LH) combination	4B-152, 157	2B-22
F-30	Rear speaker (LH)	4B-137, 139	2B-22
F-31	{ Body wiring harness (main) <LHD> or (sub) <RHD> and tailgate wiring harness combination	4B-133	2B-22
F-32		4B-87, 113, 121, 126, 127, 160, 163, 166, 169	2B-22
F-33	ECS rear shock absorber (RH)	4B-152, 157	2B-22
F-34	ECS rear shock absorber (LH)	4B-152, 157	2B-22

## **INDEX (In order of parts name)**

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
A	Active aero control unit	F-25	4B-159, 160, 162, 163, 165, 166, 168, 169	2B-22
	Active aero front venturi skirt	F-26	4B-159, 160, 162, 163, 165, 166, 168, 169	2B-22
	Active aero rear spoiler	A-69	4B-160, 163, 166, 169	2B-5, 7
	Active aero switch	F-04	4B-87, 160, 163, 166, 169	2B-22
		D-29	4B-159, 162, 165, 168	2B-15, 17
	Air bag module (Passenger's side)	C-85	4B-170, 172	2B-11, 13
	Air flow sensor (with intake air temperature sensor and atmospheric sensor)	B-25	4B-32, 38	2B-9
	Air selection damper control motor	C-20	4B-111, 119	2B-10, 12
	Air-inlet sensor	C-19	4B-112, 120	2B-10, 12
	Air-thermo sensor	C-34	4B-112, 120	2B-10, 12
	Alternator	B-15	4B-27	2B-8
		B-16	4B-27	2B-8
	Alternator relay	A-10X	4B-10, 27	2B-4, 6
	Ashtray illumination lamp	D-17	4B-141	2B-14, 16
	Auto-cruise control relay	C-46	4B-177, 181	2B-11, 13
	Auto-cruise control unit	C-30	4B-175, 176, 177, 179, 180, 181	2B-10, 12
	Auto-cruise main switch	D-32	4B-174, 178	2B-15, 17
	Auto-cruise vacuum pump	A-30	4B-177, 181	2B-4, 6
B	Back-up lamp (RH)	F-10	4B-89	2B-22
	Back-up lamp switch	B-23	4B-89	2B-9
	Blend air damper control motor	C-14	4B-113, 121	2B-10, 12
	Blower motor	C-31	4B-110, 118	2B-10, 12
	Blower motor relay	C-71	4B-4, 5, 110, 118	2B-11, 13
	Blower motor relay (HI)	C-32	4B-110, 118	2B-10, 12
	Body wiring harness (main) <LHD> or (sub) <RHD> and ECS rear shock absorber joint wiring harness (LH) combination	F-29	4B-152, 157	2B-22
	Body wiring harness (main) <LHD> or (sub) <RHD> and tailgate wiring harness combination	F-31	4B-133	2B-22
	Body wiring harness (main) and body wiring harness (sub) combination	F-32	4B-87, 113, 121, 126, 127, 160, 163, 166, 169	2B-22
		C-87	—	2B-11, 13
		F-18	4B-63, 71, 79, 81, 83, 85, 87, 88, 89, 127, 137, 138, 143, 148, 193	2B-22
		F-19	4B-67, 69, 148, 149, 150, 151, 152, 156, 157	2B-22
	Body wiring harness (main) and body wiring harness (sub) combination <LHD>	C-27	4B-75, 78, 137, 142, 144, 188	2B-10, 12
	Body wiring harness (main) and body wiring harness (sub) combination <RHD>	C-61	4B-77, 80, 138, 165, 168, 169, 192	2B-13
		C-62	4B-89, 121	2B-13
		C-63	4B-133	2B-13
	Body wiring harness (main) and console wiring harness combination	D-22	4B-97, 141, 142, 145	2B-14, 16
	Body wiring harness (main) and control wiring harness combination	C-21	4B-30, 34, 35, 36, 40, 41, 42, 89, 106, 108, 116, 123, 149, 154, 175, 179, 180	2B-10, 12
		C-22	4B-31, 37, 89, 170, 172, 175, 179	2B-10, 12
	Body wiring harness (main) and control wiring harness combination <RHD>	C-60	4B-157	2B-13
	Body wiring harness (main) and door wiring harness (LH) combination	E-26	4B-78, 80, 100, 104, 130, 131, 137, 139, 187, 191	2B-19, 21
	Body wiring harness (main) and door wiring harness (RH) combination	E-01	4B-78, 80, 100, 104, 130, 131, 137, 139, 187, 191	2B-18, 20
	Body wiring harness (main) and front wiring harness combination	C-01	4B-22, 48, 51, 55, 56, 60, 62, 67, 69, 83, 91, 92, 108, 112, 116, 157, 177, 181, 188, 189, 193	2B-10, 12

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
B	Body wiring harness (main) and front wiring harness combination	C-02 C-03 C-23 C-24	4B-160, 163 4B-13, 16, 18, 21, 27, 46, 50, 54, 56, 100, 132, 182, 184 4B-128 4B-22, 23, 24, 27, 30, 34, 36, 42, 48, 51, 55, 56, 63, 71, 106, 160, 163, 170, 172, 188, 192	2B-10 2B-10, 12 2B-10, 12 2B-10, 12
	Body wiring harness (main) and front wiring harness combination <RHD>	C-59	4B-145, 147	2B-13
	Body wiring harness (main) and instrument panel wiring harness combination	C-13	4B-97, 111, 112, 119, 120, 137, 139, 141, 159, 162, 165, 168, 171, 173, 174, 178	2B-10, 12
	Body wiring harness (main) and junction block combination	C-74	4B-4, 5, 30, 36, 74, 76, 85, 89, 102, 110, 118, 136, 138, 148, 153, 171, 173, 174, 176, 178, 180, 186, 190	2B-11, 13
		C-75	4B-4, 5, 48, 51, 55, 57, 60, 62, 66, 67, 68, 69, 70, 71, 91, 102, 128, 136, 138, 183, 185, 189, 193	2B-11, 13
		C-76	4B-4, 5, 61, 63, 75, 77, 91, 122, 132, 136, 138, 141, 158, 161, 164, 167, 187, 189, 191, 193	2B-11, 13
		C-77	4B-4, 5, 22, 23, 74, 76, 79, 81, 83, 85, 102, 126, 127, 130, 131, 136, 138, 141, 158, 161, 164, 167, 186, 190	2B-11, 13
		C-78	4B-4, 5, 15, 20, 26, 27, 31, 37, 42, 44, 47, 48, 50, 51, 54, 55, 56, 57, 60, 61, 62, 63, 66, 67, 69, 71, 75, 77, 82, 84, 89, 94, 96, 100, 106, 110, 114, 118, 122, 123, 126, 127, 128, 130, 131, 132, 136, 138, 140, 141, 143, 146, 148, 153, 158, 161, 164, 167, 171, 173, 174, 175, 178, 179, 182, 183, 184, 185, 187, 191	2B-11, 13
		C-79	4B-4, 5, 15, 30, 34, 35, 36, 40, 41, 61, 63, 74, 76, 78, 80, 87, 88, 100, 102, 106, 110, 114, 118, 120, 122, 123, 128, 132, 136, 138, 141, 143, 144, 146, 147, 148, 153, 158, 161, 164, 167, 170, 172, 174, 175, 176, 178, 179, 180, 182, 184, 186, 190	2B-11, 13
	Body wiring harness (sub) <LHD> or (main) <RHD> and ECS rear shock absorber joint wiring harness (RH) combination	F-07	4B-152, 157	2B-22
	Body wiring harness (sub) <LHD> or (main) <RHD> and fuel tank wiring harness combination	F-13	4B-31, 37, 94, 97	2B-22
	Body wiring harness (sub) <LHD> or (main) <RHD> and rear bumper wiring harness combination	F-17	4B-61, 63, 89	2B-22
	Body wiring harness (sub) and control wiring harness combination <LHD>	C-29	4B-152	2B-10, 12
	Body wiring harness (sub) and front wiring harness combination <LHD>	C-25	4B-142	2B-10, 12
		C-26	4B-31, 61, 144, 152	2B-10, 12
	Body wiring harness (sub) and front wiring harness combination <RHD>	C-64	4B-166, 169	2B-13
	Brake fluid level sensor	A-27	4B-97	2B-4, 6
	Buck-up lamp (LH)	F-24	4B-89	2B-22
C	Cam position sensor	B-36	4B-32, 38	2B-9
	Cigarette lighter	D-18	4B-141	2B-14, 16
		D-19	4B-141	2B-14, 16
	Cigarette lighter illumination lamp	D-20	4B-141	2B-14, 16
	Clock	D-08	4B-140	2B-14, 16
	Clock spring	C-48	4B-91, 92, 175, 179, 189, 193	2B-11, 13
	Clutch pedal switch	C-53	4B-175, 179	2B-11, 13

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
C	Column switch	C-09	4B-48, 51, 55, 57, 60, 62, 67, 69, 71, 83, 85, 128	2B-10, 12
	Combination gauge	C-10	4B-122	2B-10, 12
	Combination meter	D-09	4B-31, 37, 95	2B-14, 16
		D-03	4B-31, 37, 94, 98, 150, 155	2B-14, 16
		D-04	4B-27, 31, 37, 42, 44, 46, 50, 54, 56, 67, 69, 71, 79, 81, 83, 85, 94, 96, 97, 123, 128, 143, 146, 160, 163, 166, 169, 171, 173, 177, 181, 186, 190	2B-14, 16
	Combination meter	D-05	4B-27, 42, 44, 67, 69, 71, 83, 85, 94, 98, 123, 128, 160, 163, 166, 169, 171, 173, 177, 181	2B-14, 16
	Condenser fan motor	A-59	4B-43, 45, 107, 115	2B-5, 7
		A-60	4B-43, 45, 107, 115	2B-5, 7
	Condenser fan motor relay (HI)	A-44X	4B-10, 43, 45, 107, 115	2B-4, 7
	Condenser fan motor relay (LO)	A-47X	4B-10, 43, 45, 107, 115	2B-4, 7
	Control wiring harness and ECS front shock absorber joint wiring harness (RH) combination	A-14	4B-152, 157	2B-4, 6
	Control wiring harness and battery cable combination	B-26	4B-22, 23, 24, 188, 192	2B-9
	Control wiring harness and injector wiring harness combination	B-07	4B-33, 39	2B-8
	Control wiring harness and instrument panel wiring harness combination	C-12	4B-31, 37, 95, 98, 123, 151, 156, 159, 162, 165, 168, 176, 180	2B-10, 12
	Control wiring harness and oil pressure wiring harness combination	B-06	4B-35, 41, 95, 98	2B-8
	Control wiring harness and solenoid valve wiring harness combination	A-22	4B-35, 41	2B-4, 6
	Crank angle sensor	B-37	4B-32, 38	2B-9
D	Daytime running lamp control unit <LHD>	A-37	4B-47, 60, 67, 112	2B-4
	Daytime running lamp relay <LHD>	A-36	4B-46	2B-4
	Defogger (+)	F-02	4B-133	2B-22
	Defogger (-)	F-05	4B-133	2B-22
	Defogger relay	C-06X	4B-10, 21, 132	2B-10, 12
	Defogger switch and ECS switch	D-06	4B-133, 150, 155	2B-14, 16
	Detonation sensor	B-08	4B-32, 38	2B-8
	Diagnosis connector	C-70	4B-35, 41, 75, 77, 78, 80, 103, 111, 119, 122, 132, 144, 147, 150, 155, 159, 162, 165, 168, 171, 173, 176, 180, 188, 192	2B-11, 13
	Dim-dip lamp relay 1 or no connection	A-81	4B-55, 57	2B-7
	Dim-dip lamp relay 2, 3 or jumper connector	A-82	4B-54, 56	2B-7
	Dim-dip lamp relay 2, 3 or jumper connector	A-83	4B-54, 56	2B-7
	Diode (for 4WS fluid level warning lamp circuit)	D-10	4B-96	2B-14, 16
	Diode (for ABS circuit)	A-84	4B-142, 145	2B-5, 7
	Diode (for MPI circuit)	E-24	4B-34, 40	2B-19, 21
	Diode (for headlamp circuit) <RHD>	A-38	4B-55, 57	2B-7
		A-39	4B-55, 56	2B-7
		A-40	4B-55, 56	2B-7
		A-41	4B-55, 57	2B-7
	Diode (for headlamp circuit) <LHD>	C-57	4B-48, 51, 67	2B-11
	Door key cylinder unlock switch (Driver's side) <Vehicles with theft-alarm system>	E-18	4B-104, 187, 191	2B-19, 21
	Door key cylinder unlock switch (Passenger's side)	E-08	4B-104, 187, 191	2B-18, 20
	Door lamp (Driver's side)	E-19	4B-78, 80	2B-19, 21
	Door lamp (Passenger's side)	E-07	4B-78, 80	2B-18, 20
	Door lock actuator (Driver's side)	E-17	4B-104, 187, 191	2B-18, 21
	Door lock actuator (Passenger's side)	E-09	4B-104, 187, 191	2B-18, 20
	Door lock power relay	C-04X	4B-10, 102	2B-10, 12
	Door mirror (Driver's side)	E-27	4B-130, 131	2B-19, 21

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
D	Door mirror (Passenger's side)	E-02	4B-130, 131	2B-18, 20
	Door speaker (Driver's side)	E-22	4B-137, 139	2B-19, 21
	Door speaker (Passenger's side)	E-03	4B-137, 139	2B-18, 20
	Door switch (Driver's side)	E-16	4B-61, 63, 75, 77, 78, 80, 103, 188, 192	2B-18, 20
	Door switch (Passenger's side)	E-12	4B-75, 77, 78, 80, 188, 192	2B-18, 20
	Dual pressure switch	A-48	4B-108, 116	2B-4, 7
E	ECS G sensor	E-21	4B-151, 156	2B-19, 21
	ECS control unit	F-11	4B-149, 150, 151, 152, 154, 155, 156, 157	2B-22
		F-12	4B-150, 152, 155, 157	2B-22
	ECS front shock absorber (LH)	A-88	4B-152, 157	2B-5, 7
	ECS front shock absorber (RH)	A-87	4B-152, 157	2B-5, 7
	ECS rear shock absorber (LH)	F-34	4B-152, 157	2B-22
	ECS rear shock absorber (RH)	F-33	4B-152, 157	2B-22
	EGR control solenoid valve	A-26	4B-35, 41	2B-4, 6
	ETACS control unit	C-54	4B-22, 23, 75, 77, 103, 122, 132, 187, 188, 189, 191, 192, 193	2B-11, 13
		C-55	4B-75, 77, 91, 103, 122, 132, 186, 187, 188, 189, 190, 191, 192, 193	2B-11, 13
	Engine control relay	C-36	4B-30, 36	2B-11, 12
	Engine control unit	C-43	4B-26, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 108, 116	2B-11, 13
		C-44	4B-26, 30, 31, 32, 34, 35, 36, 37, 38, 40, 41, 42, 44, 106, 108, 114, 116	2B-11, 13
		C-45	4B-30, 32, 33, 36, 38, 39, 149, 154, 175, 179	2B-11, 13
	Engine coolant level sensor	A-68	4B-42, 44	2B-5, 7
	Engine coolant temperature gauge unit	B-01	4B-95	2B-8
	Engine coolant temperature sensor	B-02	4B-32, 38	2B-8
		C-35	4B-112, 120	2B-11, 12
	Engine oil level relay	C-42	4B-98	2B-11, 13
	Engine oil level sensor	B-32	4B-98	2B-9
	Engine speed detection connector	A-17	4B-26	2B-4, 6
F	Foot lamp (LH)	C-56	4B-74, 76	2B-11, 13
	Foot lamp (RH)	C-28	4B-74, 76	2B-10, 12
	Front speaker (LH)	D-02	4B-137, 139	2B-14, 16
	Front speaker (RH)	D-13	4B-137, 139	2B-14, 16
	Front turn signal lamp (LH)	A-52	4B-83, 85	2B-4, 7
	Front turn signal lamp (RH)	A-75	4B-83, 85	2B-5, 7
	Front wiring harness and ECS front shock absorber joint wiring harness (LH) combination	A-28	4B-152, 157	2B-4, 6
	Front wiring harness and control wiring harness combination	A-80	4B-22, 23, 24, 30, 34, 36, 40, 44, 72, 108, 114, 116, 170, 172, 188, 192	2B-5, 7
		C-86	4B-33, 39	2B-11, 13
	Front wiring harness and junction block combination	C-65	4B-4, 5, 14, 19, 22, 23, 30, 35, 36, 41, 66, 68, 70, 74, 76, 78, 80, 87, 88, 91, 102, 110, 118, 122, 132, 136, 138, 140, 143, 144, 146, 147, 148, 153, 158, 161, 164, 167, 170, 172, 176, 180, 186, 189, 190, 193	2B-11, 13
		C-66	4B-4, 5, 14, 19, 34, 40, 42, 47, 55, 57, 58, 60, 61, 63, 66, 68, 70, 72, 82, 84, 85, 94, 106, 114, 120, 126, 127, 133, 136, 138, 140, 141, 143, 146, 149, 154, 158, 161, 164, 167, 174, 178	2B-11, 13
	Front wiring harness and junction block combination	C-67	4B-4, 5, 14, 15, 19, 20, 22, 23, 30, 35, 36, 41, 74, 76, 78, 80, 102, 110, 118, 122, 132, 136, 138, 140, 144, 147, 148, 153, 158, 161, 164, 167, 170, 172, 175, 176, 179, 180, 186, 190	2B-11, 13
	Fuel pressure solenoid valve	A-24	4B-35, 41	2B-4, 6
	Fuel pump check connector	A-18	4B-31, 37	2B-4, 6
	Fuel pump relay	B-24	4B-31, 37	2B-9

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
F	Fuel pump resistor	A-65	4B-31, 37	2B-5, 7
	Fuel tank	F-15	4B-31, 37, 94, 97	2B-22
G	Glove box lamp	D-11	4B-72	2B-14, 16
	Glove box lamp switch	D-14	4B-72	2B-14, 16
H	Hazard switch	D-07	4B-82, 84	2B-14, 16
	Headlamp (LH: HI)	A-54	4B-46, 50, 54, 56	2B-5, 7
	Headlamp (LH: LO)	A-91	4B-46, 50, 54, 56	2B-5, 7
	Headlamp (RH: HI)	A-74	4B-46, 50, 54, 56	2B-5, 7
	Headlamp (RH: LO)	A-92	4B-46, 50, 54, 56	2B-5, 7
	Headlamp leveling switch	D-38	4B-58	2B-15, 17
	Headlamp leveling unit (LH)	A-55	4B-58	2B-5, 7
	Headlamp leveling unit (RH)	A-73	4B-58	2B-5, 7
	Headlamp relay	A-01X	4B-10, 13, 18, 46, 50, 54, 56, 66	2B-4, 6
	Headlamp washer motor	A-67	4B-128	2B-5, 7
	Headlamp washer relay	C-41	4B-128	2B-11, 13
	Hood switch <Vehicles with theft-alarm system>	A-79	4B-188, 192	2B-5, 7
	Horn	A-61	4B-91, 92, 189, 193	2B-5, 7
		A-62	4B-91, 92, 189, 193	2B-5, 7
		A-63	4B-91, 92, 189, 193	2B-5, 7
		A-64	4B-91, 92, 189, 193	2B-5, 7
	Horn relay	A-06X	4B-10, 16, 91, 92, 189, 193	2B-4, 6
I	Idle speed control servo (stepper motor)	B-31	4B-33, 39	2B-9
	Ignition coil	B-13	4B-26	2B-8
	Ignition switch	C-52	4B-15, 20	2B-11, 13
	Ignition timing adjustment connector	A-19	4B-26, 35, 41	2B-4, 6
	Injector No. 1	B-12	4B-33, 39	2B-8
	Injector No. 2	B-27	4B-33, 39	2B-9
	Injector No. 3	B-10	4B-33, 39	2B-8
	Injector No. 4	B-28	4B-33, 39	2B-9
	Injector No. 5	B-09	4B-33, 39	2B-8
	Injector No. 6	B-29	4B-33, 39	2B-9
	Inspection lamp	A-86	4B-72	2B-5, 7
	Inspection lamp switch	A-53	4B-72	2B-5, 7
	Instrument panel adapter wiring harness and junction block combination	C-68	4B-4, 5, 26, 27, 30, 31, 36, 37, 42, 44, 58, 66, 67, 68, 69, 70, 71, 72, 79, 81, 82, 83, 84, 85, 94, 96, 123, 126, 127, 128, 133, 140, 143, 146, 149, 154, 158, 161, 164, 167, 171, 173, 174, 178, 186, 190	2B-11, 13
	Instrument panel wiring harness and body wiring harness (main) combination	D-42	4B-79, 81, 82, 84, 130, 155	2B-15, 17
		D-43	4B-66, 67, 68, 69, 70, 71, 94, 97, 109, 117, 126, 127, 130, 133, 137, 146, 151, 156, 159, 160, 162, 163, 165, 168, 176, 177, 180, 181, 186, 190	2B-15, 17
		D-44	4B-58, 67, 69, 71, 82, 83, 84, 85, 95, 96, 126, 127, 130, 133, 140, 150, 155, 177, 181	2B-15, 17
	Instrument panel wiring harness and body wiring harness (sub) combination	D-16	4B-94, 97, 126, 127, 143, 150, 166, 169	2B-14, 16
	Instrument panel wiring harness and control wiring harness combination	D-15	4B-26, 30, 36, 72, 94, 95, 96, 98, 109, 117	2B-14, 16
	Instrument panel wiring harness and front wiring harness combination	D-46	4B-27, 42, 44, 46, 47, 50, 54, 56, 58, 66, 68, 70, 72, 83, 95, 96, 97, 98, 128, 143, 146	2B-15, 17
	Instrument panel wiring harness and instrument panel adapter wiring harness combination	D-45	4B-26, 27, 30, 31, 36, 37, 42, 44, 58, 66, 67, 68, 69, 70, 71, 72, 79, 81, 82, 84, 85, 94, 96, 123, 126, 127, 128, 133, 140, 143, 146, 149, 154, 158, 161, 164, 167, 171, 173, 174, 178, 186, 190	2B-15, 17
	Interior temperature sensor	F-01	4B-113, 121	2B-22
J	Joint connector <Vehicles with dim-dip lamp>	A-43	4B-55, 56	2B-7

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
J	Jumper connector	E-25	4B-34	2B-19
K	Key reminder switch	C-51	4B-22, 23, 74, 76, 103, 158, 163, 164, 169, 186, 190	2B-11, 13
L	Licence plate lamp (RH) Licence plate lamp (LH) Lighting monitor buzzer Luggage compartment lamp Luggage compartment lamp switch	F-16 F-20 C-40 F-08 F-21	4B-61, 63 4B-61, 63 4B-61, 63 4B-79, 81 4B-79, 81	2B-22 2B-22 2B-11, 13 2B-22 2B-22
M	Magnetic clutch Magnetic clutch relay Mode selection damper control motor Motor antenna control unit	B-18 A-46X C-15 F-28	4B-108, 116 4B-10, 108, 116 4B-113, 121 4B-136, 138	2B-8 2B-4, 7 2B-10, 12 2B-22
N	No connection  No connection Noise capacitor	A-85 A-93 C-49 C-83 C-88 D-39 D-50 E-30 E-31 E-32 E-37 E-38 B-14	— — 4B-34, 87, 143, 148, 177 — — 4B-94 — — — — — — 4B-26	2B-5 2B-5, 7 2B-11 2B-11 2B-11, 13 2B-15, 17 2B-15, 17 2B-21 2B-19 2B-19 2B-19, 21 2B-19, 21 2B-8
O	Oil pressure gauge unit Oil pressure switch Oxygen sensor (LH) Oxygen sensor (RH)	B-33 B-34 B-11 B-17	4B-95 4B-98 4B-33, 39 4B-33, 39	2B-9 2B-9 2B-8 2B-8
P	Parking brake switch Photo sensor Position lamp (LH) Position lamp (RH) Power seat assembly Power seat switch Power steering oil pressure switch Power transistor  Power transistor (for A/C circuit) Power window main switch Power window motor (Driver's side) Power window motor (Passenger's side) Power window relay Power window sub switch Purge control solenoid valve	D-28 D-12 A-89 A-90 E-20 D-21 B-35 B-19 B-20 C-18 E-28 E-29 E-06 C-07X E-05 A-25	4B-97 4B-111, 119 4B-61, 63 4B-61, 63 4B-182, 183, 184, 185 4B-182, 184 4B-35, 41 4B-26 4B-26 4B-110, 118 4B-100 4B-100 4B-100 4B-10, 100, 182, 184 4B-100 4B-35, 41	2B-15, 17 2B-14, 16 2B-5, 7 2B-5, 7 2B-19, 21 2B-14, 16 2B-9 2B-9 2B-9 2B-10, 12 2B-19, 21 2B-19, 21 2B-18, 20 2B-10, 12 2B-18, 20 2B-4, 6
R	Radiator fan motor Radiator fan motor relay (HI) Radiator fan motor relay (LO) Radio and tape player  Rear combination lamp (LH) Rear combination lamp (RH) Rear fog lamp relay Rear fog lamp switch Rear intermittent wiper relay Rear speaker (LH) Rear speaker (RH)	A-66 A-07X A-04X D-35 D-36 F-27 F-09 C-05X D-01 E-14 F-30 F-06	4B-42, 44, 106, 114 4B-10, 42, 44, 106, 114 4B-10, 42, 44, 106, 114 4B-136, 137, 138, 139 4B-136, 137, 138, 139 4B-61, 63, 67, 69, 71, 83, 85, 87, 88 4B-61, 63, 67, 69, 71, 83, 85, 87, 88 4B-10, 66, 68, 70 4B-66, 68, 70 4B-126, 127 4B-137, 139 4B-137, 139	2B-5, 7 2B-4, 6 2B-4, 6 2B-15, 17 2B-15, 17 2B-22 2B-22 2B-10, 12 2B-14, 16 2B-18, 20 2B-22 2B-22

	Parts name	Connector No.	Circuit diagram page	Wiring diagram page
R	Rear washer motor	F-14	4B-126, 127	2B-22
	Rear wiper and washer switch	D-37	4B-126, 127	2B-15, 17
	Rear wiper motor	F-03	4B-126, 127	2B-22
	Remote controlled mirror switch	D-40	4B-130, 131	2B-15, 17
	Resistor	A-21	4B-33, 39	2B-4, 6
	Resistor <Vehicles with dim-dip lamp>	A-42	4B-55, 57	2B-7
	Rheostat	D-41	4B-95	2B-15, 17
	Roof wiring harness and junction block combination	C-72	4B-4, 5, 74, 76	2B-11, 13
	Room lamp	E-04	4B-74	2B-18, 20
S	SRS diagnosis unit	D-23	4B-170, 171, 172, 173	2B-14, 16
	SRS front impact sensor (LH)	D-24	4B-170, 172	2B-14, 16
	SRS front impact sensor (RH)	D-26	4B-171, 173	2B-14, 16
	Side turn signal lamp (LH)	A-51	4B-170, 172	2B-4, 7
	Side turn signal lamp (RH)	A-76	4B-170, 172	2B-5, 7
	Speed sensor	A-29	4B-83, 85	2B-4, 6
	Starter motor	A-13	4B-83, 85	2B-4, 6
	Starter relay	B-30	4B-33, 39, 95	2B-9
	Steering wheel angle speed sensor	B-21	4B-22, 23, 24, 188, 192	2B-9
	Stop lamp switch	B-22	4B-22, 23, 24, 188, 192	2B-9
	Storage connector	A-09X	4B-10, 22, 23, 188, 192	2B-4, 6
		C-47	4B-151, 156	2B-11, 13
T		C-50	4B-34, 40, 87, 88, 143, 146, 148, 153, 177, 181	2B-11, 13
		A-11X	4B-10, 14, 15, 19, 20, 22, 23, 30, 35, 36, 41, 74, 76, 78, 80, 102, 110, 118, 122, 132, 136, 138, 140, 144, 147, 148, 153, 158, 161, 164, 167, 170, 172, 175, 176, 179, 180, 186, 190	2B-4, 6
	Tail lamp relay	A-05X	4B-10, 13, 18, 46, 60, 62	2B-4, 6
	Tailgate cylinder lock switch <Vehicles with theft-alarm system>	F-22	4B-189, 193	2B-22
	Tailgate switch <Vehicles with theft-alarm system>	F-23	4B-189, 193	2B-22
	Theft-alarm horn	A-31	4B-91, 189, 193	2B-4, 6
		A-32	4B-91, 189, 193	2B-4, 6
W	Theft-alarm horn relay	C-69	4B-4, 5, 91, 189, 193	2B-11, 13
	Throttle position sensor	B-05	4B-32, 38, 149, 154, 175, 179	2B-8
	Turn signal and hazard flasher unit	E-23	4B-82, 84	2B-19, 21
	Washer fluid level sensor	A-15	4B-123	2B-4, 6
	Waste gate solenoid valve	A-23	4B-35, 41	2B-4, 6
	Windshield washer motor	A-20	4B-123	2B-4, 6
	Windshield wiper motor	A-16	4B-123	2B-4, 6